

11/12

MULTIMETER

USERS MANUAL

For the benefit and convenience of its customers, Fluke Corporation (Fluke) has reproduced this copy of a manual which is no longer in production. This manual has not been edited or updated since the revision date shown on the *lower left hand corner of the first page*. Fluke will not be liable for any claims, losses or damages of any kind incurred by any user arising from use of this manual.




PN 900191


July 1991 Rev.2, 12/99

©1991, 1993, 1999 Fluke Corporation, All rights reserved. Printed in U.S.A.
All product names are trademarks of their respective companies.

FLUKE®

CONTENTS**PAGE**


READ FIRST: SAFETY INFORMATION	4
SYMBOLS	5
DISPLAY	6
OPERATING FEATURES	7
STANDBY MODE	8
[] INPUT RANGES	8
Autoranging	9
Manually Selecting a Range	9
MEASURING VOLTAGE	10
TESTING CONTINUITY AND MEASURING RESISTANCE	12
TESTING DIODES	14
 CHEK [™] AND HOW TO USE IT	16
DISABLING  CHEK WITH FUNCTION LOCK	17

CONTENTS	PAGE
[H] MEASURING CAPACITANCE	18
[M] USING MIN MAX FUNCTIONS (Fluke 12 Only)	20
Recording Minimum and Maximum Readings (Fluke 12 Only)	20
Recording Minimum and Maximum Readings with Elapsed Time (Fluke 12 Only)	22
Capturing Continuity Intermittents with Continuity Capture™ (Fluke 12 Only)	24
TURNING BEEPER OFF	26
MAINTENANCE	26
 Replacing the Battery	26
Replacing the Test Leads	26
Service and Parts	27
Accessories	27
SPECIFICATIONS	27
SERVICE CENTERS	31

READ FIRST: SAFETY INFORMATION

This meter has been designed and tested in accordance with IEC Publication 1010. To ensure that the meter is used safely, follow all safety and operating instructions in this manual. If the meter is not used as described in this manual, the safety features of the meter might be impaired.

⚠ Warning


To avoid false readings, which could lead to possible electric shock or personal injury, replace the battery as soon as the battery indicator () appears.

- Do not use the meter if the meter or test leads look damaged, or if you suspect that the meter is not operating properly.
- Turn off power to the circuit under test before cutting, unsoldering, or breaking the circuit. Small amounts of current can be dangerous.
- Do not apply more than 600V rms between a terminal and earth ground.
- Use caution when working above 60V dc or 30V ac rms. Such voltages pose a shock hazard.
- When using the probes, keep your fingers behind the finger guards on the probes.
- Disconnect the live test lead before disconnecting the common test lead.

SYMBOLS

The following international electrical symbols are used in this manual:

 Important Safety Information in Manual

 Not Applicable to Identified Model

~ AC

≡ DC

 Diode

 Capacitor

 Ground

 Double Insulation

DISPLAY




Figure 1. Display

OPERATING FEATURES




Figure 2. Operating Features

STANDBY MODE

In Standby mode, the display goes blank to preserve battery life. The meter beeps and enters Standby if it is ON but inactive for more than 45 minutes. Press any pushbutton to resume operation. Standby is not allowed if the meter is in the MIN MAX mode.

[⊙] INPUT RANGES

The input range determines the highest value the meter will measure. Most functions have more than one range (see SPECIFICATIONS). If the range is too low, the display shows OL (overload). If the range is too high, the display will show fewer digits of resolution.

Autoranging

The meter defaults to autorange when you turn it on. In autorange, the meter selects the range automatically.

Manually Selecting a Range

The meter also has a manual range mode. In manual range, you select and lock the meter in a range. To manually select a range:

1. Press [0]. The meter is locked in the range it is in, and 0 is displayed. In manual range, \checkmark CHEK is disabled.
2. Press [0] to step through the ranges. NOTE: The 4000 mV range, which can only be entered in manual range, is convenient when using accessories.
3. To return to autorange, press [0] for 2 seconds (until 0 is no longer displayed), or change the measurement function.

MEASURING VOLTAGE

1. Insert the test leads in the jacks.
2. To select a voltage function, put the slide-switch in the middle position. See Figure 3.

To toggle between dc and ac, press [≡].

3. Touch the probes to the test points, and read the display. The meter beeps an Overload Alert™ when OL (overload) is displayed.

In manual range, you can toggle the meter between a high or low input impedance mode by moving the slide-switch between the voltage and continuity/ohms positions. (See "✓CHECK AND HOW TO USE IT".) In the continuity/ohms position, the input impedance of the meter is 2 k Ω , and LoZ is displayed to indicate that the meter is in the low input impedance mode. In the volts position, the input impedance is 5 M Ω in ac and 10 M Ω in dc.






Figure 3. Measuring Voltage

TESTING CONTINUITY AND MEASURING RESISTANCE

1. Insert the test leads in the jacks, and turn off power to the circuit under test. External voltage across the components causes invalid readings.
2. Put the slide-switch in the continuity/ohms position (Figure 4).

To toggle between the continuity/diode and ohms functions, press .
3. Touch the probes to the test points.
4. In ohms, read the resistance on the display.

In continuity test, the beeper sounds continuously if continuity exists (resistance $< 25\Omega$). Opens and shorts longer than $250 \mu\text{s}$ are detected. On the Fluke 12, short-to-open and open-to-short transitions can be captured and visually displayed. See “Capturing Continuity Intermittents”.

If the meter detects a voltage greater in magnitude than about 4.5V and the meter is not in the manual range mode, the meter automatically changes to the voltage measurement function. (See “ CHECK AND HOW TO USE IT”.)




Figure 4. Continuity and Resistance Measurements

TESTING DIODES

1. Insert the test leads in the jacks.
2. Put the slide-switch in the continuity/ohms position. The meter selects either the continuity/diode (|)|) \rightarrow +) or ohms (Ω) function.

If ohms is selected, press [=] to toggle to the continuity/diode function. To toggle the beeper on or off in continuity/diode test, press [⊙]. |)|) is displayed when the beeper is enabled.

3. Touch probes to the diode (Figure 5A). A forward-voltage drop of about 0.6V (typical for a silicon diode) causes the meter to beep once.
4. Reverse probes (Figure 5B). If the diode is good, OL is displayed. If the diode is shorted (Figure 5C), the beeper sounds continuously in at least one direction.

If the diode is open, OL is displayed in both directions.




Figure 5. Testing Diodes

ⓈCHEK AND HOW TO USE IT

ⓈCHEK is a subset of the continuity/ohms function. In **ⓈCHEK**, the meter is designed to automatically display an ac or dc voltage when the meter detects a voltage greater in magnitude than about 4.5V and the meter is not in the manual range mode. **THIS WILL NOT HARM THE METER.** **ⓈCHEK** is always enabled (and **Ⓢ** is displayed) when the meter is in the continuity/ohms function unless the meter is in one of the following:

- The manual range mode (i.e., **Ⓢ** is displayed)
- The MIN MAX mode (i.e., **Ⓢ** is displayed)
- The capacitance function (i.e., μF is displayed)

⚠ Warning





Repetitive transients on a dc bus will cause ⓈCHEK to select ac volts, even though a hazardous dc voltage may be present. To avoid a misleading display and possible electric shock, manually select the proper volts function for measurements on these circuits.

In **ⓈCHEK**, the meter has a low input impedance ($\sim 2\text{ k}\Omega$). When a voltage is displayed, **LoZ** is also displayed to remind you of this, and the beeper momentarily sounds a **ⓈCHEK Alert™**. To disable the **ⓈCHEK Alert** in the ohms function, press and hold down **[=]** while turning the meter on.

Use **ⓈCHEK** only on power supplies and other power sources that have a low output impedance. Do not use **ⓈCHEK** to measure voltage in electronic circuitry unless a $2\text{K}\Omega$ load will not damage the circuit. See on † page 30.




DISABLING WITH FUNCTION LOCK

To lock the meter in either the continuity/diode or ohms function, and disable :

1. Put the slide-switch in the continuity/ohms position. The meter selects the continuity/diode or ohms function. Press  to toggle between the continuity/diode and ohms functions.
2. Press  to put the meter in manual range.  is displayed. The meter is locked in the selected function and  is disabled.

In continuity/diode test, press  to toggle the beeper on and off.

In ohms, press  to manually select a range.

To remove the function lock and reenable , press  for 2 seconds, press , or move the slide-switch.

[⇄] MEASURING CAPACITANCE

First, turn off power to the circuit, and disconnect and discharge the capacitor.

1. Insert test leads, and move the slide-switch to ⇄. (See Figure 6.)
2. Press [⇄]. The capacitance function is selected and μF is displayed.
3. Touch the probes to the capacitor. When measuring polarized capacitors, be sure to connect the positive to **+** and the negative to COM. Capacitor dielectric absorption can cause measurement errors. If more discharge is necessary, the meter displays "dISC" while the capacitor is discharging.

To exit capacitance, Press [⇄] or [≡], or move the slide-switch to another position.





Figure 6. Measuring Capacitance

[M] USING MIN MAX FUNCTIONS

Recording Minimum and Maximum Readings (Fluke 12 Only)

MIN MAX records the highest and lowest measurements taken. MIN MAX cannot be used when the meter is measuring capacitance. In the MIN MAX mode, autoranging, Standby, and  *CHEK* are disabled.

1. Insert the test leads, and put the meter in volts or ohms.
2. Connect the leads to the circuit.
3. Press **[M]** to enter MIN MAX. **M** is displayed, and autorange is disabled. When the reading changes more than about 50 digits, the meter beeps a short Input Change Alert™. When a new minimum or maximum is recorded, the meter beeps a longer MIN MAX Alert™.
4. Press **[M]** to cycle through maximum, minimum, and present readings (see Figure 7). To exit MIN MAX and erase the stored readings, press **[M]** for 2 seconds or change the measurement function.




Figure 7. Displaying Minimum and Maximum Reading

Recording Minimum and Maximum Readings with Elapsed Time (Fluke 12 Only)

The MIN MAX with elapsed-time mode records the time (in hours and minutes) between when MIN MAX was entered and the last high and low was recorded. Time is kept to 99:59. OL is displayed for longer times.

1. To enable the MIN MAX elapsed-time clock, hold **[M]** down while moving the slide-switch from OFF to the volts or continuity/ohms position.
2. Insert the test leads, and put the meter in volts or ohms.
3. Connect the leads to the circuit.
4. Press **[M]** to select MIN MAX. **M** is displayed, and time is set to 00:00.
5. Press **[M]** to step through the display sequence shown in Figure 8.
6. To exit, press **[M]** for 2 seconds, or change the measurement function.




Figure 8. Maximum and Minimum Reading with Elapsed Time

Capturing Continuity Intermittents with Continuity Capture (Fluke 12 Only)


When testing continuity, the meter can capture intermittents as short as 250 μ s, and display them as open-to-short and short-to-open transitions.

1. Put the slide-switch in the continuity/ohms position.
2. Connect the leads to the circuit.
3. Press [M]. The display shows the initial condition (either an open or short) as shown in Figure 9, and M is displayed.


If the meter detects a transition, it beeps and the display captures the transition (see Figure 9). Subsequent transitions cause the meter to beep, but the display does not change.

4. Press [M] to reset the display to the present condition and resume capture mode.
5. To exit, press [M] for 2 seconds or change measurement function.


SHORT



OPEN



SHORT-TO-OPEN
TRANSITION



OPEN-TO-SHORT
TRANSITION

Figure 9. Open-to-Short and Short-to-Open Transitions

TURNING BEEPER OFF

To disable all beeper functions, press and hold down [Ⓢ] for 2 seconds while turning the meter on.

MAINTENANCE

⚠ Warning

To avoid electrical shock or damage to the meter, do not get water inside the case. Remove the test leads and any input signals before opening the case.

Periodically wipe the case with a damp cloth and detergent. Do not use abrasives or solvents.

Replacing the Battery

The meter uses a 9V battery (NEDA 1604 or IEC 6F22). To replace the battery, remove the four screws from the back of the meter and lift off the front. Remove the battery from case bottom.

Replacing the Test Leads

The meter uses double-insulated test leads. When replacing the test leads, order Fluke PN 855742 only.

Service and Parts

This meter should be serviced only by a qualified service technician. To order the service manual (PN 900824) and other parts or for service information, in the USA call 1-800-825-9810. Outside the USA, contact the nearest Fluke service center (see back of manual).

Accessories

When using accessories, put the slide-switch in the volts position, and manually select the 4000 mV range for ease of reading.

SPECIFICATIONS

This meter complies with Part 15 of FCC Rules. Operation is subject to the following conditions: (1) This meter may not cause harmful interference, and (2) this meter must accept any interference received, including interference that may cause undesired operation.

Accuracy is specified for a period of one year after calibration, at 18°C to 28°C (64°F to 82°F) with relative humidity to 90%. AC conversions are ac-coupled, average responding, and calibrated to the rms value of a sine wave input. Accuracy Specifications are given as:

\pm ([% of reading] + number of least significant digits)]

Maximum Voltage Between any Terminal and Earth Ground

600V rms

Display 3 3/4-digits, 4000 counts, updates 4/sec**Operating Temperature** -10°C to 50°C**Storage Temperature** -30°C to 60°C indefinitely (to -40°C for 100 hrs)**Temperature Coefficient** 0.1 x (specified accuracy)/°C
(<18°C or >28°C)**Relative Humidity** 0% to 90% (-10°C to 35°C)
0% to 70% (35°C to 50°C)**Battery Type** 9V, NEDA 1604 or IEC 6F22**Battery Life** 650 continuous hours with alkaline
450 continuous hours with carbon-zinc**Shock, Vibration** 1 meter shock. Per MIL-T-28800D for a Class 3 Instrument**Size (HxWxL)** 1.35 in x 2.75 in x 5.55 in
(3.46 cm x 7.05 cm x 14.23 cm)**Weight** 10 oz (286 g)**Safety** Designed to Protection Class II requirement of
UL1244, ANSI/ISA-S82, CSA C22.2 No 231, and VDE 0411,
and IEC 1010 overvoltage category III.**EMI Regulations** Complies with FCC Part 15, Class B, and VDE 0871B.

Function	Range	Resolution	Accuracy (50 to 400 Hz)
V_{\sim}	4000mV*	1mV	$\pm(1.9\%+3)$
	4.000V	0.001V	$\pm(1.9\%+3)$
	40.00V	0.01V	$\pm(1.9\%+3)$
	400.0V	0.1V	$\pm(1.9\%+3)$
	600V	1V	$\pm(1.9\%+3)$
V_{DC}	4000mV*	1mV	$\pm(0.9\%+2)$
	4.000V	0.001V	$\pm(0.9\%+2)$
	40.00V	0.01V	$\pm(0.9\%+1)$
	400.0V	0.1V	$\pm(0.9\%+1)$
	600V	1V	$\pm(0.9\%+1)$
Ω	400.0 Ω	0.1 Ω	$\pm(0.9\%+2)$
	4.000 k Ω	0.001 k Ω	$\pm(0.9\%+1)$
	40.00 k Ω	0.01 k Ω	$\pm(0.9\%+1)$
	400.0 k Ω	0.1 k Ω	$\pm(0.9\%+1)$
	4.000 M Ω	0.001 M Ω	$\pm(0.9\%+1)$
	40.00 M Ω	0.01 M Ω	$\pm(1.5\%+3)$
fC	1.000 μ F	0.001 μ F	$\pm(1.9\%+2)$
	10.00 μ F	0.01 μ F	$\pm(1.9\%+2)$
	100.0 μ F	0.1 μ F	$\pm(1.9\%+2)$
	10000 μ F	1 μ F	$\leq 1000 \mu$ F $\pm(1.9\% + 2)$ $> 1000 \mu$ F $\pm(10\% + 90)$ Typical
	$\rightarrow $	2.000V	0.001V

* The 4000 mV range can only be entered in manual range mode. Use the 4000 mV range with accessories.

† The beeper is guaranteed to come on at $<25\Omega$ and turn off at $>250\Omega$. The meter detects opens or shorts of 250 μ s or longer.

Function	Overload Protection*	Input Impedance (Nominal)	Common Mode Rejection Ratio (1 k Ω Unbalance)	Normal Mode Rejection
V_{DC}	600V dc	>10 M Ω <100 pF † C_{CHEK} & LoZ = >2 k Ω <200 pF	>100 dB at dc, 50 Hz, or 60 Hz	>50 dB at 50 Hz or 60 Hz
V_{AC}	600V rms	>5 M Ω <100 pF † C_{CHEK} & LoZ = >2 k Ω <200 pF (ac-coupled)	>60 dB at dc 50 or 60 Hz	
Ω				
		Open Circuit Test Voltage	Full Scale Voltage To 4.0 MΩ	Short Circuit Current
	600V rms	<1.5V dc	<450 mV dc	<1.5V dc
\rightarrow	600V rms	2.4-3.0V dc	2.400V dc	0.95 mA(typical)

*3 x 10⁶ V Hz Maximum

† \approx 2k Ω with input voltage up to 50V. Impedance will increase with input voltage to >300 k Ω at 600V.

MIN MAX Recording Accuracy and Response Time

Specified accuracy of the measurement function \pm 12 digits for changes >200 ms in duration (\pm 40 digits in ac). Typical 100 ms response to 80%.

MIN MAX Recording with Elapsed Time

Elapsed Time	Resolution	Accuracy
0 to 100 hours (99:59)	1 minute	0.3% typical

Continuity Capture

Detects opens or shorts of 250 μ s or longer

USA

Washington
TEL: 1-800-825-9810

INTERNATIONAL**Argentina**

Coasin S.A.
Virrey del Pino 4071 DEP E-1
1430 CAP FED
Buenos Aires
TEL: 54 1 522-5248
FAX: 54 1 551-1767

Australia

Phillips Customer Support
Scientific and Industrial
23 Lakeside Drive
Tally Ho Technology Park
East Burwood
Victoria 3151

Phillips Customer Support
Scientific and Industrial
Block F, Centrecourt
34 Waterloo Road
North Ryde, N.S.W. 2113
TEL: 61 2 888-8222
FAX: 61 2 888-0440

Austria

Fluke Austria GmbH
Unternehmensbereich Prof. Systeme
Guthel Schoder
Gasse 10
A-1102 Wein
TEL: 43 222-60101x1299
FAX: 43 222-603-2165

Belgium

Fluke Belgium N.V./S.A.
T&M Customer Support
80, Rue des Deux Gares
B-1070 Brussels
TEL: 32 2 525-7037
FAX: 32 2 525 6483

Canada

Fluke Electronics Canada Inc.
400 Britannia Road East, Unit #1
Mississauga, Ontario
L4Z 1X9
TEL: 416 890-7600
FAX: 416 890 6866

Chile

Intronsa Inc.
Casilla 16150
Santiago 9
TEL: 56 2 232-1886, 232-4308
FAX: 56 2 232-2694

China

Fluke Service Center
Room 2111 Scite Tower
Jianguomenwai Dajie
Beijing 100004, PRC
TEL: 86 1 512-3435 or 6351
FAX: 86 1 512-3437

Colombia

Sistemas E Instrumentacion, Ltda.
Carrera 21, NO. 39A-21, OF. 101
Ap. Aereo 29583
Bogota
TEL: 57 1 287-5424
FAX: 57 1 287-2248

Costa Rica

Electronic Engineering, S.A.
P.O. Box 4300-1000
San Jose
TEL: 506 53-3759
FAX: 506 25-1286

Denmark

Fluke Denmark A/S
T&M Customer Support
Strandlodsvej 4B
DK 2300
Copenhagen
TEL: 45 32 882531
FAX: 45 32 883939

Ecuador

Proteco Coasin Cia., Ltda.
P.O. Box 17-03-228-A
Av. 12 de Octubre
2449 y Orellana
Quito
TEL: 593 2 230283 or 520005
FAX: 593 2 561980

Egypt

Phillips Egypt
10, Abdel Rahman el Rafei St.
el. Mohandessin
P.O. Box 242
Dokki Cairo
TEL: 20 2 490922

Finland

Fluke Finland Oy
Sinikalliontie 3
P.O. Box 11
SF-02631 ESPOO
TEL: 358 0 50261
FAX: 358 0 529558

France

Fluke France S.A.
T&M Customer Support
105 Rue de Paris BP 62
93002 Bobigny, Cedex
TEL: 33 1 4942-8049
FAX: 33 1 4942-8155

Germany

Fluke GmbH
Service VSF
Unternehmensbereich Elektronik
 fuer Wissenschaft und Industrie
Oskar-Messter-Strasse 18
D-8045 Ismaning/Munich
TEL: 49 89 9605260
FAX: 49 89 9605270

Greece

Phillips S.A. Hellenique
15,25th March Street
177 78 Tavros
10210 Athens
TEL: 30 1 489-4911
FAX: 30 1 331-5180

Hong Kong

Schmidt & Co (H.K.) Ltd.
1st Floor
323 Jaffe Road
Wanchai
TEL: 852 9223-5623
FAX: 852 834-1848

Ireland, Republic of

Fluke U.K. LTD.
Customer Support
Colonial Way
Watford
Hertfordshire WD2 4TT U.K.
TEL: 44 923-240511
FAX: 44 923-225067

India

Hinditron Services Pvt. Inc.
33/44A Raj Mahal Vilas Extension
8th Main Road
Bangalore 560 080
TEL: 91 812 345-734
FAX: 91 812 345-022

Hinditron Services Pvt. Ltd
1st Floor, 17-B,
Mahal Industrial Estate
Mahakali Road, Andheri East
Bombay 400 093
TEL: 91 22 633-0043
FAX: 91 22 837-0087

Hinditron Services Pvt. Ltd.
204-206 Hemkunt Tower
98 Nehru Place
New Delhi 110 019
TEL: 91 11 643-3675
FAX: 91 11 642-9118

Hinditron Services Pvt. Ltd.
Field Service Center
Emerald Complex 1-7-264
5th Floor
114 Sarojini Devi Road
Secunderabad 500 003
TEL: 91 842-844033

Indonesia

P. T. Daeng Brothers
Phillips House
Jl. Rasuna Said Kav. 3-4
Jakarta 12950
TEL: 62 21 520 1122
FAX: 62 21 520 5189

Israel

R.D.T Electronics Engineering, Ltd
P.O. Box 58013
Tel Aviv 61580
TEL: 972-3-548-3737
FAX: 972-3-492190

Italy

Fluke S.R.L.
T&M Customer Support
Via G. Casati 23
20052 Monza
TEL: 39-39-203-6525
FAX: 39-39-203-6621



Japan

Fluke Corporation
Sumitomo Higashi Shinbashi Bldg.
1-1-11 Hamamatsucho
Minato-ku
Tokyo 105
TEL: 81 3 3434-0181
FAX: 81 3 3434-0170

Korea

B&P International Co., Ltd.
Geopung Tocon A-1809
203-1 Nonhyun-Dong
Kangnam-Ku
Seoul 135-010
Korea
TEL: 82 02 546-1457
FAX: 82 02 546-1458

IL MYOUNG, INC.

780-46, Yeongsam-Dong
Youngdong P.O. Box 1486
Kangnam-Ku
Seoul KOREA
TEL: 82 2 552-8582-4
FAX: 82 2 553-0388

Malaysia

Mecomb Malaysia Sdn. Bhd.
P.O. Box 24
46700 Petaling Jaya
Selangor
TEL: 60 3 774-3422
FAX: 60 3 774-3414

Mexico

Mexel Mexicana De Electronica
Industrial, S.A. De C.V.
Diagonal No. 27
Col. Del Valle
C.P. 03100, Mexico D.F.
TEL: 52 5 682-8040
FAX: 52 5 687-8695

Mexicana De Electronica
Industrial, S.A.
Av. Porvenir No. 8608
Centro C. San Martin Local 6
CD. Jaurez
TEL: 16-23-02-35
FAX: 16-23-02-35

Netherlands

Fluke Europe B.V.
Science Park
Eindhoven 5110
P.O. Box 1186
5602 BD Eindhoven
TEL: 31 40 644-265
FAX: 31 40 644-260

Fluke Netherland B.V.
Technische Service Prof. Act.
Hurksestraat, 2C
Gebouw HBR
5652 AJ Eindhoven
TEL: 31 40 723-220
FAX: 31 40 723-337

New Zealand

Phillips Customer Support
Scientific & Industrial
Private Bag 41904
St. Lukes, 2 Wagener Place
Mt. Albert, Auckland 3 New
Zealand
TEL: 64 9 894-4160
FAX: 64 9 849-7814

Norway

Fluke Norway A/S
Sandstuveien 70
Postboks 1 Manglerud
N 0680 OSLO 6
TEL: 47 2 748-408
FAX: 47 2 741-907

Peru

Importaciones &
Representaciones
Electronicas S.A.
JR. Pumacahua 955
Lima 11 Peru
TEL: 51 14 23-5099
FAX: 51 14 27-1324

Philippines

Spark Electronics Corp.
P.O. Box 610, Greenhills
Metro Manila 1502
TEL: 63 2 700-621
FAX: 63 2 721-0491

Portugal

Phillips Portuguese S.A.
IE Division - T & M Department
Apartado 300
2795 LINDA-A-VELHA
TEL: 351 1 410-1000
FAX: 351 1 410-7838 or 7986

Republic of South Africa

South African Phillips (Pty) Ltd.
P. O. BOX 7703
Johannesburg 2000
TEL: 27 11 889-3578
FAX: 27 11 889-3279

Singapore, Republic of

Fluke Singapore Pte. Ltd.
460 Alexandra Road
#27-03 PSA Building
Singapore 0511
TEL: 65-276-5161
FAX: 65-276-5759

Spain

Fluke Ibérica
T&M Customer Support
Depto. Tecnico Instrumentacion
c/Martinez Villergas 2
28027 Madrid
TEL: 34 1 326-7146
FAX: 34 1 326-0668

Sweden

Fluke Sweden AB
T&M Customer Support
Tegeluddsvaegen 1
S-11584 Stockholm
TEL: 46 8 782-1300
FAX: 46 8 667-4781

Switzerland

Fluke Switzerland AG
T&M Customer Support
Riedstrasse 12
Postfach 360
CH-8953 Dietikon
TEL: 41 1 745-2244
FAX: 41 1 745-2240

Taiwan

Schmidt Electronics Corp.
5th Floor, Cathay Min Sheng
Commercial Building,
344 Min Sheng East Road
Taipei
TEL: 886 2 501-3468
FAX: 886 2 502-9692

Thailand

Measuretronix Ltd.
2102/31 Ramkamhang Road
Bangkok 10240
TEL: 66 2 375-2733, 375-2734
FAX: 66 2 374-9965

Turkey

Turk Phillips Ticaret A.S.
Inonu Caddesi 78/80
Posta Kutusu 504-Beyoglu
Istanbul
TEL: 90 1 143-5891

United Kingdom

Fluke U.K. LTD.
Customer Support
Colonial Way
Watford
Hertfordshire WD2 4TT
TEL: 44 923-240511
FAX: 44 923-225067

Uruguay

Coasin Uruguaya S.A.
Casilla de Correo 1400
Libertad 2529
Montevideo
TEL: 598 2 789-015
FAX: 598 2 797-338

Venezuela

Coasin C.A.
Calle 9 Con Calle 4, Edif. Edinurbi
Apartado de Correos Nr-70.136
Los Ruices
Caracas 1070-A
TEL: 58 2 241-0309, 241-1248
FAX: 58 2 241-1939