

AMDin / KROMU

Ground Watchdog Aid a Location 5.C. (0.V).

Sound Board

- 1) Link Pin 10 of I.D. to +5.V.
- 2) Cut track Between Pins 1+2 on 4.E.
- 3) Cut track (or lift Pins up ^{18' - (2532)} of Sockets 5.C. 5.D (5.G).
₍₂₇₃₂₎
- 4) Link Together and to Soldered Blob above. 280
that runs (track does) between Pins 1+2 on 4.F.
- 5) ON 4.E As follows (under Board)
 - 1) Pin 8 link to Pin 14
 - 2) Cut track to Pin 14.
 - 3) Link Pin 15 to track that
went to Pin 14

* N.B THAT Program Board is linked for 2716/2732 Depending on
Program Being used

2716 STRAIGHT LIGHT

2732 FROM SOCKET 1001 MISS ONE (every alternate)

SOUND PROMS AM5C - AM5D (2532's)

PROG PROMS AM1-8 (2716's)

CHAR. PROMS AM5F - AM5H (2716's)