

1. Cut track on top from pin 8 to pin 13 7410
2. Cut track on under side from pin 2 to pin 13
3. cut track on under side from pin 6 to pin 9.
4. Cut track on under side from pin 8.

5. Join pins 3, 4 and 5
6. Join pins 1, 2 and 8.

Join pin 22, of all ROMS to pin 3 7410

Join pin 19, of Row A to pin 19 of B

Join pin 12 of Row C to pin 18 of Row C

Join pin (19) of Row C to pin (19) of Row D
to pin 13 of 7410.

Join pin 13 of 7410 to AH pin 11.

Join pin 11 of 7410 to 9M pin 6

Join pin 20 of Row C to pin 20 of Row D to pin 11 of 7408

Join pin 8 of 7410 to pin 12 of 7408

Join pins 7, 13 and 14 of 7410 to 7, 13 and 14 of 7408.