

Rock-Ola CD Jukebox Electronic Assembly Part Numbers

	S-4 SYSTEM	S-4A SYSTEM	S-5A SYSTEM	S-6A SYSTEM	SYBERSONIC	ADV. SYBERSONIC
Model Name	Laser 2000, Mirage	Trilogy	Gala, Rocket, Legend, Nostalgic Series with Black Electronics and CDM-4 Industrial Player	Anniversary Legend, Rocket II, Nostalgic Series with Black Electronics and CDM-12 Player	Legend 7000, Rocket III and Nostalgic Series with Red Electronics	Legend 7000B, Intrigue, Rocket III, Intrigue, Comet and Nostalgic Series with Orange Electronics
Model Number	2000, 3000	4000	5000, 5500, 6000, CD-4, CD-6, CD-8	6000-1, 5500-1, CD-4, CD-6, CD-8	7000, 7000-1, 7500. CD-4, CD-6, CD-8	7000B, 7000-1B, 7000-2B, 7000-3BH, 8000, 8000-1 through 8000-5, CD-4B, CD-6B, CD-8B
Amplifier Assy	58180-A	56180-1A	56180-1A	56180-1A	70002-A/70002-1A*	70038-A/70038-1A**
Pre-Amp Board	56235-A	56630-A	56630-A	56630-1A	58438-2A	59132-A/59132-1A**
Latest Amp Software					58823-2.3	59204-4.3
Power Driver PCB	56095-A	56095-A	56095-A	56095-A	58440-A	58440-A
Output Transistor	48931-02	48931-02	48931-02	48931-02	58912	58912
Computer Assy	56210-A	56210-2A	57000-2A	58534-A	70003-A	70003-1A
Computer PCB	56215-A	56215-2A	57001-A	57001-A	58399-A	58399-1A
Latest Software	56236-03/ 56237-03	56753-01	56999-5.8	58535-6.5	58824-3.9	58824-6.04
Power Supply Assy	56205-A	56205-A	56205-1A	56205-1A	70029-A	70029-1A
Power Supply PCB	56257-A	56257-A	56257-1A	56257-1A	58270-A	58270-1A
Mechanism Assy	56130-A	56130-1A	56130-1A/ 57185-A	58715-2A	58689-1A	58689-2A
OEM Player Type	CDM-3 #	CDM-3/CDM-4HD#	CDM-4 Industrial #	CDM-12 =	CDM-12 =	CD-Pro/CD-Pro II
CD Player	56255-A #	56255-A/56255-1A#	57067-A #	58414-1A =	58414-1A =	59241-1A/59241-2A
Mech Control PCB	55180-A	55180-A	55180-A Gala 5000 56995-A All Others	56995-A		
CD Interface Assy	56129-A #	56129-A #	56129-A/ 57066-A			
CD Interface PCB	56195-A #	56195-A #	56877-A #	58451-1A		
CD Power Supply	56089	56089	56873-A	58549-1A		
Player Update Kit	02406-02	02406-02	02419-01 Gala 5000 02420-01 All Others			

*70002-A has Red heat sink, 70002-1A has silver heat sink. Mounting plate P/N 59212 required for 70002-1A in place of 70002-A
CDM-3, CDM-4HD and CDM-4 Industrial players and Interfaces are no longer available. Order a Player Update Kit.
= CDM-12 Players are no longer available for sale. Order P/N 59241-2A for purchases.
** 70038-1A uses 59132-1A Pre-Amp PCB. New parts used in production approx. Feb '99

Rock-Ola CD Jukebox Electronic Assembly Part Numbers

	DIGITRAC	DIGITAL SYBERSONIC	DIGITAL DIGITRAC	HIDE AWAY	TABLETOP	DIGITAL CD
Model Name	Fireball, Rock, Lyric	Digital Intrigue	Digital Fireball, Vivo			
Model Number	A, B, C, C-1	8000-6	D, E	8050	R-91	9000
Amplifier Assy	70038-1A	70111-A	70111-A	70038-1A	60097-A	70135-A
Pre-Amp Board	59132-1A	60441-A	60441-A	59132-1A	59895-A	60441-A
Latest Amp Software	59204-4.3	59647.6.03	59647.6.03	59204-4.3	59204-9.06	59647-6.03
Power Driver PCB	58440-A	60442-A	60442-A	58440-A	59964-A	60442-A
Output Transistor	58912	60003	60003	58912	60003	60003
Computer Assy	70003-1A	70003-1A	70003-1A	70003-1A	70003-1A	70003-2A
Computer PCB	58399-1A	58399-1A	58399-1A	58399-1A	58399-1A	58399-1A
Latest Software	58824-6.20	58824-6.20	58824-6.20	58824-6.20	58824-6.20	58824-6.20
Power Supply Assy	70029-1A	70111-A	70111-A	70029-1A	60096-A	70135-A
Power Supply PCB	58270-1A	60435-A	60435-A	58270-1A	59898-A	60435-A
Power Supply Xfmr	58623-A	60037-A	60037-A	58623-A	60037-A	60037-A
Auxiliary Amp		70110-A	70110-A			See note below
Auxiliary Amp PCB		60429-A	60429-A			
Auxiliary Amp Xfmr		60432-A	60432-A			
Mechanism Assy	59570-6A	58689-2A	59570-6A	58689-2A	58689-2A	58689-2A
OEM Player Type	CD-Pro II	CD-Pro II	CD-Pro II	CD-Pro II	CD Pro II	CD Pro II
CD Player	59816-A ***	59241-2A	59816-A	59241-2A	59241-2A	59241-2A
Mech Control PCB	59319-1A with V2.5 Software		59319-1A with V2.5 Software			

Note: Auxiliary Amplifier not available for use with Digital CD Model 9000