

Electronics Division
Box 1246
1501 Webster Street
Dayton, Ohio 45401
Telephone (513) 223-8161

Operating Instructions

For Model

282A, 283B

SEA WOLF II

MIDWAY

| | | SL2 | | | | START 2 | | | SR2 | | | 5 V |
|----------|------------|----------------------|---------------------------------------|----------|---|-------------------|-----|-----|-----------------|------|----------|--------|
| LLP X | SL1 | X SL5 X SL4 | SL3 | LRP X | x | X START 1 X | RLP | SR1 | SR5 x SR4 | SR3 | RRP | ON OF |
| | SL6 | X | SL7 | | | COIN | | SR6 | × | SA 7 | | POWER |
| | * . | | * * * * * * * * * * * * * * * * * * * | | | x | | × | f fr | x | x | ÓN OFF |

- 1. Install the 283B card into the program B connector, number side up.
- 2. Connect the two molex connectors to the Mother Board.
- 3. Connect the alligator clip to the ground strap coming from the test fixture.
- 4. Set monitor selector switch, SW-7 on game board, to ON for black and white video.
- 5. Install the 282A card into the program A connector, number side up.
- 6. Connect the three Molex connectors to the game board.
- 7. Connect speakers to the speaker leads.
- 8. Slide the 5V switch to ON.
- 9. Slide the Power switch to ON.
- 10. The switch on the 283B card is reset.
- 11. Press COIN to coin the game.
 Press START 1 for a one player game.
 Press START 2 for a two player game.
- 12. SR-5 fires the right torpedo

Combinations of SR-I through SR-7, except SR-5, aim the right torpedo.

SL-5 fires the left torpedo.

Combinations of SL-1 through SR-7, except SL-5, aim the left torpedo.