

## Parts and Operating Manual



*Bally*

MIDWAY MFG. CO.

10750 W. Grand Avenue  
Franklin Park, Illinois 60131  
U.S.A.



Phone: (312) 451-1360

Cable Address: MIDCO

Telex No.: 72-1596

**WARNING**

**THIS GAME MUST BE GROUNDED. FAILURE TO DO SO MAY RESULT IN DESTRUCTION TO ELECTRONIC COMPONENTS.**

**WARNING:** This equipment generates, uses, and can radiate radio frequency energy and if not used in accordance with the instructions manual, may cause interference to radio communications. It has been tested and found to comply with the limits for a CLASS A computing device pursuant to SUBPART J of PART 15 of FCC RULES, which are designed to provide reasonable protection against such interference when operated in a commercial environment. Operation of this equipment in a residential area is likely to cause interference in which case the user at his own expense will be required to take whatever measures may be required to correct the interference.

ELECTRICAL BULLETIN: FOR ALL APPARATUS COVERED BY THE CANADIAN STANDARDS ASSOCIATION (CSA) STANDARD C22.2 NO. 1, WHICH EMPLOYS A SUPPLY CORD TERMINATED WITH A POLARIZED 2-PRONG ATTACHMENT PLUG.

CAUTION: TO PREVENT ELECTRIC SHOCK DO NOT USE THIS (POLARIZED) PLUG WITH AN EXTENSION CORD, RECEPTACLE OR OTHER OUTLET UNLESS THE BLADES CAN BE FULLY INSERTED TO PREVENT BLADE EXPOSURE.

ATTENTION: POUR PREVENIR CHOCS ELECTRIQUES NE PAS UTILISER CETTE FICHE POLARISEE AVEC UN PROLONGATEUR. UNE PRISE DE COURANT OU UNE AUTRE SORTIE DE COURANT, SAUF SI LES LAMES PEUVENT ETRE INSEREES A FOND SANS EN LAISSER AUCUNE PARTIE A DECOUVERT.

***Bally*/MIDWAY**  
T.M.

*Invites You To Use*

**OUR TOLL FREE NUMBERS FOR  
SERVICE INFORMATION CONCERNING THIS GAME, OR ANY  
OTHER BALLY/MIDWAY™ GAME YOU NOW HAVE ON LOCATION.**

**CALL US FOR PROMPT, COURTEOUS  
ANSWERS TO YOUR PROBLEMS.**

**Continental U.S. 800-323-7182  
Illinois Only 1-800-942-0497**

© COPYRIGHT MCMLXXXIII BY BALLY/MIDWAY CO. ALL RIGHTS RESERVED.

NO PART OF THIS PUBLICATION MAY BE REPRODUCED BY ANY MECHANICAL, PHOTOGRAPHIC, OR ELECTRONIC PROCESS, OR IN THE FORM OF A PHONOGRAPHIC RECORDING, NOR MAY IT BE TRANSMITTED, OR OTHERWISE COPIED FOR PUBLIC OR PRIVATE USE, WITHOUT PERMISSION FROM THE PUBLISHER. THIS MANUAL IS FOR SERVICE USE ONLY, AND NOT FOR GENERAL DISTRIBUTION. FOR PERMISSION REQUESTS, WRITE: MIDWAY MFG. CO., 10750 W. GRAND AVE., FRANKLIN PARK, IL 60131

Printed in U.S.A.

## TABLE OF CONTENTS

DESCRIPTION	PAGE
Introduction .....	1-1
<b>I. Location and Setup</b>	
Inspection.....	1-3
Installation.....	1-5
Self-Test .....	1-5
Game Volume Adjustment Control .....	1-6
Option Switch Setting .....	1-6
<b>II. Game Operation</b>	
Self-Test Mode .....	2-1
Attract Mode.....	2-4
Ready-To-Play Mode.....	2-6
Play Mode .....	2-7
Two Player Operation.....	2-8
<b>III. Maintenance and Repair</b>	
Cleaning .....	3-1
Fuse Replacement .....	3-1
Opening the Control Panel .....	3-2
Removal of Main-Display-Glass and T.V. Bezel .....	3-2
T.V. Monitor Replacement.....	3-3
Printed Circuit Board Replacement .....	3-3
Opening the Attraction Panel .....	3-4
Servicing the Black Light Above Control Console .....	3-5
Servicing the Fluorescent Light Behind the Front Service Panel .....	3-5
<b>IV. Illustrated Parts Breakdown</b>	
No. 639 - Kosmik Krooz'r - Front.....	4-2
No. 639 - Kosmik Krooz'r - Front - Parts List .....	4-3
No. 639 - Kosmik Krooz'r - Header Fluorescent Light Assy. and Black Light Assy. ....	4-5
No. 639 - Kosmik Krooz'r - Header Fluorescent Light Assy. & Black Light Assy. - Parts List...	4-5
No. 639 - Kosmik Krooz'r - Rear Access .....	4-6
No. 639 - Kosmik Krooz'r - Rear Access - Parts List.....	4-7
No. 639 - Kosmik Krooz'r - Ship Assy. ....	4-8
No. 639 - Kosmik Krooz'r - Ship Assy. - Parts List .....	4-9
No. 639 - Kosmik Krooz'r - Analog Control Assy. ....	4-10
No. 639 - Kosmik Krooz'r - Analog Control Assy. - Parts List.....	4-11
No. 639 - Kosmik Krooz'r - Knob & Shaft - Encoder Disc Assy.....	4-12
No. 639 - Kosmik Krooz'r - Knob & Shaft - Encoder Disc Assy. - Parts List.....	4-13
Kosmik Krooz'r - Power Chassis Assy. - 70VA, 115V.....	4-14
Kosmik Krooz'r - Power Chassis Assy. - 70VA, 115V. - Parts List.....	4-15
Front Door Assy. - U.S.A. 25¢ .....	4-16
Front Door Assy. - U.S.A. 25¢ - Parts List .....	4-17
<b>V. Technical Troubleshooting</b> .....	5-1
Introduction .....	5-1
General Suggestions .....	5-1
Harness Component Troubleshooting .....	5-1
Transformer and Line Voltage Problems .....	5-2
A Glossary of Microprocessor Terms .....	5-3
Introduction to the Z80 CPU.....	5-3
General Purpose Registers .....	5-4
Arithmetic and Logic Unit (ALU) .....	5-4
Instruction Register and CPU Control .....	5-4
Z80 CPU Pin Description .....	5-4
MCR 11 System P.C. Board Jumper Options.....	5-7

## TABLE OF CONTENTS

DESCRIPTION	PAGE
<b>VI. T.V. Monitor Manual</b> .....	6-1
Introduction .....	6-1
Symptom Diagnosis.....	6-2
Guide to Schematic Symbols .....	6-3
Troubleshooting .....	6-5
Theory of Operation.....	6-6
Differences Between Monitors.....	6-8
Controls You May Not Touch .....	6-9
Parts Interchangeability .....	6-9
Picture Tube Interchangeability .....	6-10
Wells Gardner Monitor Schematic - 19" .....	6-12
Wells Gardner Monitor Replacement Parts List .....	6-13
Electrohome Monitor Schematic - 19" .....	6-14
Electrohome Monitor Replacement Parts List.....	6-15
Electrohome Monitor Schematic - 13" .....	6-16
Electrohome Monitor Replacement Parts List .....	6-17
Zenith Monitor - Sweep Board Schematic .....	6-18
Zenith Monitor - Sweep Board Replacement Parts List .....	6-19
Zenith Monitor Main Board Schematic .....	6-20
Zenith Monitor Main Board Replacement Parts List .....	6-21
Zenith Monitor - CRT Socket Board Replacement Parts List.....	6-22
Zenith Monitor - CRT Socket Board Schematic .....	6-23
Zenith Monitor Width Step Assy. Schematic .....	6-24
Zenith Monitor Interconnect for Video Game Schematic .....	6-25
<b>VII. Coin Door Maintenance</b> .....	7-1
Metal Coin Acceptor Mechanisms .....	7-1
Plastic Coin Acceptor Mechanisms .....	7-3
<b>VIII. Schematics and Wiring Diagrams</b>	
Wiring Diagram - Upright .....	8-1
125VA Power Supply P.C.B. - Component Layout.....	8-2
125VA Power Supply P.C.B. - Schematic .....	8-3
Dual Power Amp P.C.B. - Component Layout.....	8-4
Dual Power Amp P.C.B. - Schematic .....	8-5
Optical Encoder P.C.B. - Component Layout .....	8-6
Optical Encoder P.C.B. - Schematic .....	8-7
Super CPU P.C.B. - Component Layout .....	8-8
Super CPU P.C.B. - Schematic.....	8-9
Video Generator P.C.B. - Component Layout .....	8-10
Video Generator P.C.B. - Schematic.....	8-11
Super Sound I/O P.C.B. - Component Layout.....	8-12
Super Sound I/O P.C.B. - Schematic .....	8-13
Analog Joystick P.C.B. - Component Layout.....	8-14
Analog Joystick P.C.B. - Schematic .....	8-15
Solid State Relay P.C.B. - Component Layout .....	8-16
Solid State Relay P.C.B. - Schematic .....	8-17
Sensor P.C.B. - Component Layout.....	8-18
Sensor P.C.B. - Schematic .....	8-19
125VA Power Chassis - Schematic .....	8-20

## TABLE OF FIGURES

FIGURE		PAGE
1-1	Installing the Footstool.....	1-3
1-2	Location of Serial No., Interlock Switch, On/Off Switch, & Major Sub-Assemblies.....	1-4
1-3	Interlock Switch Operation.....	1-5
1-4	Game Volume Adjustment Control.....	1-6
1-5	Option Switch Location.....	1-6
1-6	Option Switch Settings.....	1-7
2-1	Self Test Mode - Menu.....	2-1
2-1a	Self Test Mode - Sounds.....	2-2
2-1b	Self Test Mode - Player Input.....	2-2
2-1c	Self Test Mode - Bookkeeping.....	2-2
2-1d	Self Test Mode - Time Report.....	2-2
2-1e	Self Test Mode - Score Report.....	2-3
2-1f	Self Test Mode - Setup Options.....	2-3
2-1g	Self Test Mode - Channel Test.....	2-3
2-2	Location of Hardware Master Reset Switch.....	2-4
3-1	Location of Fuses.....	3-1
3-2	Opening the Control Panel.....	3-2
3-3	Removal of Main Display Glass & T.V. Bezel.....	3-2
3-4	Removing Monitor - Upright.....	3-3
3-5	Replacing P.C.B.'s.....	3-3
3-6	Opening the Attraction Panel.....	3-4
3-7	Replacing Fluorescent Tube Starter.....	3-4
3-8	Servicing Center Auxiliary Lighting.....	3-5
7-1	Removing and Replacing the Coin Acceptor.....	7-1
7-2	Cleaning the Metal Coin Acceptor.....	7-2
7-3	Lubricating the Metal Coin Acceptor.....	7-2
7-4	Opening the Plastic Coin Acceptor.....	7-3
7-5	Changing the Plastic Coin Acceptor to Accept American or Canadian Quarters.....	7-4

# Kozmik Krooz'r

## IMPORTANT NOTE

DO NOT plug in your new game yet. Before you do anything to your game, we recommend that you read SECTIONS I and II of this manual completely. It will not take more than a few minutes and it may be very helpful.

## Introduction

Your NEW GAME is for one or two players. There is ONLY one model: the "UPRIGHT". When the two player mode is selected on the Upright model, the players take turns at the controls to guide their player through the game course.

When playing this game, you are the controlling force. It is up to you to direct your player successfully through the game course. Your job is to give guidance and provide offensive and defensive strategy to enable your player to overcome all obstacles.

Your opponents will use every trick in the book, and may even invent a few new ones, to overcome your various strategies and eliminate your player(s). You really have to keep a close eye on them at all times.

As your skill level increases, you will notice that your opponent's offensive abilities greatly increase. Any advantages you once had at the beginning of the game will gradually be reduced until they are completely gone.

Bonus players may or may not be awarded depending on the options the game owner has selected. The point values of all items are listed below.

## Major Features

Your game has been provided with a new improved Power Chassis designed to help reduce electrical interference with other equipment.

It is also equipped with a detailed self-diagnostic package. This includes the following abilities: 1) The game has OWNER/OPERATOR selected variable levels of difficulty so game play can be tailored to player skill level in his area; 2) There is a new and easy to use diagnostic package featuring: a complete ROM/RAM check with bad chip location information read out on the monitor screen; the capability to check each of the game's different sounds **INDIVIDUALLY**; provision for checking each control and switch **SEPARATELY**; a full function Bookkeeping mode; an entire options list that can be set from the front console with **NO NEED** to crawl inside the back of the cabinet and look for tiny switches located on P.C. boards; a sound system test; and a "PRE-SET" category that can return **ALL** information in the Bookkeeping mode to zero and/or all operator selected options back to factory recommended settings; and 3) The game is equipped with a rechargeable battery so that it won't forget where it was the night before at closing — even if you turn it off. It will "remember" this information for up to two weeks.

## Game Objective

The object of the game is to **HAVE FUN** and survive as long as possible while constantly improving your skills and advancing to the highest rack that you can. As you do this, each following rack of the game will have more and greater obstacles for you to overcome, and will in general be harder to complete.

<b>DESCRIPTION</b>	<b>POINTS AWARDED</b>	<b>NOTES</b>
RAM SHIP	100	
SHOOTER SHIP	200	
STRIKE SHIP	200	
SCOUT SHIP	300	
SPEED DEMON	2500	APPEARS IN ALL RACKS
SPACE MINE	100	
FORMATION FIGHTER	100	
MINE LAYER	200	
SPY SHIP	300	

**Assigned Point Values**

# I. Location and Setup

## INSPECTION:

1. Remove the game from its shipping crate.
2. Inspect the entire outside of it for any signs of damage.
  - Any scratches?, dents?, cracks?
  - Any broken controls?
  - Any broken glass or plastic?
  - Just look it over closely and make a note of any signs of damage.
3. Remove the shipping cleats from the bottom of the cabinet.
  - UPRIGHT MODELS ONLY:** In order to help prevent easy theft of your game, you may wish to remove the Caster Wheel Assemblies from the bottom of your cabinet at this time.
4. Install the four levelers, one at each corner of the cabinet.
  - Level the cabinet.
5. After you have installed the game's Leg Levelers, if desired, you may now install the game's FOOTSTOOL. See Figure 1-1. This is accomplished by:

- MAKING SURE NO POWER IS GOING TO THE GAME.**
- Removing the FOOTSTOOL mounting hardware from its bag.
- Install the FOOTSTOOL'S Leg Levelers and set them to approximately the same height as those you just installed to each of the game cabinet's corners.
- Open the coin box door.
- Install the FOOTSTOOL mounting bolts and washers as shown below.
  - NOTE:** The FOOTSTOOL is equipped with one factory installed "T" nut for **EACH** mounting bolt.
- Start all four FOOTSTOOL mounting bolts into their respective "T" nuts **BEFORE** tightening.
- Tighten the four FOOTSTOOL mounting bolts **EVENLY!**
- Close the coin door and make any final adjustments necessary to the FOOTSTOOL'S Leg Levelers so that they will solidly support the weight of anyone who stands on the FOOTSTOOL.




Figure 1-1 Installing the Footstool



6. Open the cabinet and inspect the inside of the game for any signs of damage. See Figure 1-2.
  - Also check to make sure all plug-in connectors on the wire harness are firmly seated.

**NOTE:** ALL connectors or plugs are keyed so they will only go together when all pins are properly lined up.

  - Replug any connectors found unplugged. DO NOT FORCE PLUGS ONTO CONNECTORS. DO NOT FORCE PLUGS TOGETHER. If it won't go on easily, assuming the keys are lined up, it either does not belong there or is damaged.
  - Make sure all printed circuit boards (P.C.B.'s) are firmly seated in their connectors. See Figure 1-2. These connectors are also keyed. The

P.C.B.'s will only go into them one way without being damaged.

- Note the location of the game's serial number. See Figure 1-2.
- Check all major subassemblies to be sure they are mounted securely. These are called out in Figure 1-2.

Power supply.  
Control panel.  
T.V. monitor.  
Other P.C.B.'s and/or P.C.B. rack, etc.  
Power Chassis Assembly.

7. Make a note of any problems that can't be easily corrected.
8. Call your distributor and/or service man about your problem list.




Figure 1-2 Location of Serial No., Interlock Switch, & Major Sub-Assemblies

## INSTALLATION

### 1. Location requirements:

- Power:**
  - Domestic 110 V @ 60 Hz
  - Foreign 200 V to 240 V @ 50 Hz
- Temperature:** 32° to 100° F (0° to 38° C)
- Humidity:** Not over 95% relative
- Space required:**
  - Upright 25"x40" (63x102cm)
- Game height:**
  - Upright 72" (183cm)

### 2. Voltage Selection:

Your game is designed to work properly on the line voltage where you are located. Check your line voltage with a meter to determine what its value is. Then check the power input wires to the main power supply transformer on your game to be sure they are connected to taps which correspond to your line voltage value.

If the power input wires to the main power supply transformer are not connected to taps which correspond to your local line voltage, move them to the proper taps.

If the line voltage in your area falls outside the upper or lower limits of the range of inputs covered by the main power supply transformer, **DO NOT PLUG YOUR GAME IN** until you have talked with your distributor and/or service man and obtained a solution to this problem. Otherwise you could damage your game.

### 3. Interlock and power ON/OFF switches. See Figure 1-2.

- To help prevent the possibility of getting an electric shock while working inside the game cabinet, interlock switches have been installed at each cabinet access door (this **DOES NOT** include the coin door in the Upright models).
- When any access door is opened, the interlock switch installed there turns off all power to the game.
- Check each interlock switch for proper operation.

After checking the line voltage in your area and determining that the input wires to the main power supply transformer of your game are connected properly — or — after obtaining a solution to your over or under voltage problem from your distributor and/or your service man, plug the game into your A.C. wall outlet.

The game ON/OFF switches for all models are located as shown in Figure 1-2. Turn the game on and allow it to warm up a few minutes.

Slowly open each access door to the game (this does not include the coin door on the Upright models).

As the door is opened approximately 1" (2.54cm) the power to the game should go off (the T.V. monitor, all the lights, and all sounds will stop).

If this does not happen, check the interlock switch by this door to see if it has broken loose from its mounting or if it is stuck in the "ON" position.

If the switch is found to be bad, turn the game off, unplug it, and replace the interlock switch. When done, plug the game back into the wall outlet, close the access door, and turn the game back on.

After the game has warmed up, repeat the above interlock switch test.

When the interlock switch is working properly and turns the power to the game off, power may be restored to the game with the access door(s) open. Take hold of the interlock switch plunger and **gently** pull it out to its fully extended position. **THIS IS TO BE USED ONLY FOR SERVICING THE GAME.** See Figure 1-3.




Figure 1-3 Interlock Switch Operation

## SELF-TEST

Your new game will Self-Test itself to see if it has any bad parts. The information it receives while testing itself will be shown on the T.V. monitor. Some information can also be heard through the game's speaker system. See the SELF-TEST section for a more detailed description of this function.

When there is a bad result according to the Self-Test, call your distributor and/or service man to have the trouble fixed unless it is something you can do yourself (such as replace a bad RAM or ROM chip).

## GAME VOLUME ADJUSTMENT CONTROL

See Figure 1-4.

The game volume control pot is just inside the cabinet, not far from the coin door frame. There is only one pot. For adjustment, it may be reached through the coin door.

To make the sounds louder, turn the pot clockwise as you face it (↻).

To make the sounds **less** loud, turn the pot counter-clockwise as you face it (↺).

## OPTION SWITCH SETTINGS

To change the most common option switch settings, you **DO NOT** have to take the game apart or go into the cabinet and hunt for tiny switches on P.C. boards. These most common options can be changed from the main console of the game while it is in the Self-Test mode. The Self-Test switch is located just inside the cabinet not far from the coin door frame as you face it.

When changing any options, **ALWAYS** perform the Self-Test and play the game to be sure the ones selected are working properly. Of course, when you must change one of the switches that is located on one of the game's P.C. boards, it is also recommended that you perform the Self-Test and play the game to be sure the switches have worked properly and that no switches were accidentally moved that were not meant to be. (These switches are small and this can happen.)




Figure 1-4 Game Volume Adjustment Control

The P.C. Board option switch settings, and what they will make the game do are shown in Figure 1-6. These switches are **MAINLY INTENDED** for use by a technician who is checking and/or performing tests on the game. See Figure 1-5 for option switch locations.

**NOTE:** In order to set the option switches located on the game's P.C. Boards, these Boards need not be removed from their card rack.




Figure 1-5 Option Switch Locations

KOZMIK KROOZ'R																															
OPTION SWITCH SETTINGS																															
<b>SWITCH NO. 1 — AT B3 — LOCATED ON SOUND I/O P.C. BOARD</b>																															
<b>DURING GAME PLAY:</b>	<table style="width: 100%; border-collapse: collapse;"> <tr> <td style="width: 10%;"><b>SW#1</b></td> <td style="width: 10%;"><b>SW#2</b></td> <td style="width: 10%;"><b>SW#3</b></td> <td style="width: 10%;"><b>SW#4</b></td> <td style="width: 10%;"><b>SW#5</b></td> <td style="width: 10%;"><b>SW#6</b></td> <td style="width: 10%;"><b>SW#7</b></td> <td style="width: 10%;"><b>SW#8</b></td> <td style="width: 10%;"><b>SW#9</b></td> <td style="width: 10%;"><b>SW#10</b></td> </tr> <tr> <td>NOT USED</td> <td>NOT USED</td> <td>NOT USED</td> <td>NOT USED</td> <td>NOT USED</td> <td>NOT USED</td> <td>NOT USED</td> <td>NOT USED</td> <td>NOT USED</td> <td>NOT USED</td> </tr> <tr> <td>USED</td> <td>USED</td> <td>USED</td> <td>USED</td> <td>USED</td> <td>USED</td> <td>USED</td> <td>USED</td> <td>USED</td> <td>USED</td> </tr> </table>	<b>SW#1</b>	<b>SW#2</b>	<b>SW#3</b>	<b>SW#4</b>	<b>SW#5</b>	<b>SW#6</b>	<b>SW#7</b>	<b>SW#8</b>	<b>SW#9</b>	<b>SW#10</b>	NOT USED	NOT USED	NOT USED	NOT USED	NOT USED	NOT USED	NOT USED	NOT USED	NOT USED	NOT USED	USED	USED	USED	USED	USED	USED	USED	USED	USED	USED
<b>SW#1</b>	<b>SW#2</b>	<b>SW#3</b>	<b>SW#4</b>	<b>SW#5</b>	<b>SW#6</b>	<b>SW#7</b>	<b>SW#8</b>	<b>SW#9</b>	<b>SW#10</b>																						
NOT USED	NOT USED	NOT USED	NOT USED	NOT USED	NOT USED	NOT USED	NOT USED	NOT USED	NOT USED																						
USED	USED	USED	USED	USED	USED	USED	USED	USED	USED																						
COCKTAIL TABLE UPRIGHT	ON OFF																														
FREEZE VIDEO **NORMAL OPERATION	ON OFF																														
<b>SWITCH NO. 3 — AT D14 — LOCATED ON SOUND I/O P.C. BOARD</b>																															
**NORMAL OPERATION SOUND I/O DIAGNOSTIC MODE	<table style="width: 100%; border-collapse: collapse;"> <tr> <td style="width: 25%;"><b>SW#1</b></td> <td style="width: 25%;"><b>SW#2</b></td> <td style="width: 25%;"><b>SW#3</b></td> <td style="width: 25%;"><b>SW#4</b></td> </tr> <tr> <td>OFF</td> <td></td> <td></td> <td></td> </tr> <tr> <td>ON</td> <td></td> <td></td> <td></td> </tr> </table>	<b>SW#1</b>	<b>SW#2</b>	<b>SW#3</b>	<b>SW#4</b>	OFF				ON																					
<b>SW#1</b>	<b>SW#2</b>	<b>SW#3</b>	<b>SW#4</b>																												
OFF																															
ON																															
**NORMAL OPERATION RAM/ROM TEST INDICATES TEST RESULTS VIA YELLOW LED ON SOUND I/O BOARD: <b>FAST FLASH = BAD ROM</b> <b>SLOW FLASH = BAD RAM</b>	OFF ON																														
**NORMAL OPERATION OSCILLATOR TEST	OFF ON																														
**NORMAL OPERATION FILTER TEST	OFF ON																														
<p>* NO EFFECT IF SW#1 OF SWITCH NO. 3 IS IN THE "OFF" POSITION.</p> <p>** INDICATES FACTORY RECOMMENDED SETTINGS.</p>	<p>PART NO. <b>M051-00639-A014</b></p>																														

THE REMAINDER OF YOUR NEW GAME'S MOST COMMON OPTION SETTINGS ARE CONDUCTED DURING THE **MACHINE SETUP** PORTION OF THE SELF-TEST MODE AND WILL BE COVERED IN DETAIL IN THAT SECTION OF YOUR MANUAL.

**Figure 1-6 Option Switch Settings**

## II. Game Operation

### SELF TEST MODE

The Self-Test mode is a special mode for checking game play statistics as well as game switches and computer functions. It is the easiest and best way to check for proper operation of the entire game.

**NOTE:** Putting the game into Self-Test **WILL NOT** cause the game to erase any CREDITS it has in its memory when the Self-Test mode is entered.

You may begin a Self-Test at any time by sliding the Self-Test switch to the "ON" position after the power to the game is on (the Self-Test switch is located just inside the cabinet coin door frame as you face it). When this is done, the game will react as follows:

1. If the game is in the Attract mode when the Self-Test switch is moved to the "ON" position, it will finish the sequence and then go into the Self-Test mode. This is illustrated by the display of the Self-Test Mode Menu on the monitor screen.
2. If the game is in the Ready-To-Play mode or the Play mode when the Self-Test switch is slid to the "ON" position, it **WILL NOT** go into the Self-Test mode until **AFTER** the game is over. At this point, the game will go into the Self-Test mode. Again, this is illustrated by the display of the Self-Test Mode Menu on the monitor screen.
3. The fastest way to enter the Self-Test mode is to slide the Self-Test switch to the "ON" position and then activate the "TILT" switch located on the back side of the coin door just below the lock mechanism. The game will then **IMMEDIATELY** go into the Self-Test mode.

The Self-Test mode has eight (8) major categories as illustrated by Figure 2-1.

1. It is easy to select what category you want to enter. By following the ON SCREEN instructions, the Cursor at the left of the screen can be moved UP or DOWN until it is in front of the category you want to test.
2. After the Cursor has been positioned, follow the ON SCREEN instructions again, and the monitor screen will display the test category you have selected.

**NOTE:** There is one exception to this. If you select the "PRE-SET" category on the Self-Test Mode Menu, **EVERYTHING**, I repeat — **EVERYTHING** — including **ALL** information in the "BOOKKEEPING" mode, and **ALL operator selected options**, will be set back to zero ("0") and to the factory recommended settings — **respectively**.




Figure 2-1 Self-Test — Menu

Once you are **IN** one of the Self-Test mode categories, FOLLOW THE **ON-SCREEN INSTRUCTIONS TO COMPLETE THE TEST**.

3. The next group of Figures show the **CORRECT** screen presentation for **EACH** category of the Self-Test mode.

During the SELF DIAGNOSTICS section of the Self-Test mode, you will **first** see a cross hatch pattern on the screen for about 1/2 second. **Second**, you will see a lot of different colored bars shown on the monitor screen. These bars will be UNpainted one at a time from the top down. **Third**, you will see the screen painted Red, Blue, and Green in bars from the top down. **Fourth**, all the different colored bars you saw "**Second**" are displayed again. And **fifth**, the different colored bars are replaced by an exit message. If you do not exit, the test will repeat itself. This feature was designed into the game to enable over-night testing for an intermittent hardware problem.

If the SELF DIAGNOSTICS find one or more bad ROM or RAM chips: instead of going through what is described above, the game will give you a written message as to which parts are bad. This message includes their I.D.'s and their P.C. Board locations.

During the SOUNDS section of the Self-Test mode, the game will give a display which looks like that shown in Figure 2-1a.

- In this category, each of the game's separate sounds can be checked individually in any order — or — you can tell the game to check them all in order.

During the PLAYER INPUT section of the Self-Test mode, the game will give a display which looks like that shown in Figure 2-1b.

- In this category, each of the game's player operated controls — including the coin switches on the back side of the coin door — may be checked individually. A game sound will be heard as each switch/control is actuated. If no game

sound is heard, that switch/control is either not working, miswired, or disconnected. Check it out thoroughly.

During the BOOKKEEPING section of the Self-Test mode, the game will give a display which looks like that shown in Figure 2-1c.

- In this category a basic bookkeeping function is performed. And with the selection of the "TIME REPORT" and the "SCORE REPORT", detailed breakdowns of game times and scores may be obtained.

In the TIME REPORT and SCORE REPORT sections of the BOOKKEEPING mode, the game will give displays which look like those shown in Figures 2-1d and 2-1e respectively.




Figure 2-1a Self-Test — Sounds




Figure 2-1c Self-Test — Bookkeeping




Figure 2-1b Self-Test — Player Inputs




Figure 2-1d Self-Test — Time Report

SCORE REPORT	
0 TO 5000 PTS	14
5000 TO 10000 PTS	13
10000 TO 20000 PTS	24
20000 TO 40000 PTS	16
40000 TO 70000 PTS	3
70000 TO 100000 PTS	1
100000 TO 150000 PTS	0
150000 TO 200000 PTS	0
200000 TO 250000 PTS	0
OVER 250000 PTS	0

Figure 2-1e Self-Test — Score Report

During the SETUP OPTIONS section of the Self-Test mode, the game will give a display which looks similar to that shown in Figure 2-1f.

- In this category, all common game options may be changed from the control console: coins per credit, credits per base, bonus base(s) awarded at, difficulty level --, and so on.

SETUP OPTIONS	
COIN CHUTE 1	
*1 COINS FOR	
*1 CREDITS	
COIN CHUTE 2	
*1 COINS FOR	
*1 CREDITS	
*1 CREDITS FOR	
*3 BASES	
1ST EXTRA BASE AT	
*20000 POINTS	
ADDITIONAL BASE EVERY	
*20000 POINTS	
*3 DIFFICULTY LEVEL	

\* = Factory recommended settings.

Figure 2-1f Self-Test — Set-Up Options

#### DIFFICULTY LEVEL EXPLANATION:

The Difficulty Level setting has a range of 1 to 9. With 1 being the easiest level of play and 9 being the most difficult level of play. We recommend that a setting of 3 be used as a beginning point.

Game play can then be made **MORE** difficult or **LESS** difficult, according to the skill levels attained by the players in your area.

#### CHANNEL TEST:

During the CHANNEL TEST section of the Self-Test mode, the game will give a display which looks like that shown in Figure 2-1g.

- In this category, the game conducts a test of its SOUND SYSTEM.

Once you enter the CHANNEL TEST section of the Self-Test mode, the game automatically tests Channels 1 through 6 giving a tone for each one as it checks it. After the 6th Channel is tested, the game automatically repeats the test until exited. It then goes back to the Self-Test Mode Menu.

During the GRID DISPLAY section of the Self-Test mode, the game shows a white cross hatch pattern on the monitor screen. This is for alignment and/or test purposes. This pattern will remain on the monitor screen until exited. The game will then go back to the Self-Test Mode Menu.

To leave the Self-Test mode, simply slide the Self-Test switch to the "OFF" position at **ANY** time. The game will then run through the ROM/RAM test display after which normal game functions will return to the monitor screen.

CHANNEL TEST	
CHANNEL 1	
CHANNEL 2	
CHANNEL 3	
CHANNEL 4	
CHANNEL 5	
CHANNEL 6	

Figure 2-1g Self-Test — Channel Test

#### RACK ADVANCE:

The game can be made to advance through the various racks by beginning a game **and THEN** sliding the Self-Test switch to the "ON" position. After this has been done, each time you depress the ONE PLAYER BUTTON the game will advance one rack.

When you reach the desired rack, slide the Self-Test switch to the "OFF" position. (If you leave the Self-Test switch in the "ON" position, the game will go into the Self-Test mode when you are finished playing.)

### CROSS HATCH PATTERN:

A cross hatch pattern is shown on the screen when power is first turned on to the game, when the TILT Switch is actuated, and during the "SELF DIAGNOSTIC" portion of the Self-Test mode, and during the "GRID DISPLAY" portion of the Self-Test mode.

This pattern may be kept on the screen for adjustment purposes as described earlier.

When you are finished using the cross hatch pattern, simply exit at the GRID DISPLAY to return to the Self-Test Mode Menu.

### HARDWARE MASTER RESET SWITCH:

There are two of these little red switches, one on the Sound I/O Board and one on the CPU Board, located as shown in Figure 2-2.

The function of each of these switches — when pressed — is to make the game think it has **JUST** been turned on. They set up an "initial power-up" condition.

We **DO NOT** recommend that you indiscriminately press **EITHER** of these switches. They should **ONLY** be used if there is a major problem encountered while testing the P.C. Boards.




Figure 2-2 Location of Hardware Master Reset Switch

---

### ATTRACT MODE


1. The Attract mode starts:

- Just after power has been turned on to the game. (Self-Test switch is in the "OFF" position.)
- After a Self-Test has been completed and there are no more credits left in the game's memory.
- After a play has been finished, the score was not high enough to put the game into the High


Score/Initial mode, and there are no more credits left in the game's memory.

- After the High Score/Initial mode when there are no more credits left in its memory.
- In the Attract mode, the game will give the following displays **centered** on the monitor screen:







Attract Mode Display 1




Attract Mode Display 4




Attract Mode Display 2




Attract Mode Display 5




Attract Mode Display 3




Attract Mode Display 6



Attract Mode Display 7




Attract Mode Display 8




Attract Mode Display 9

- No matter where the game is in the Attract mode sequence, it will immediately go to the following display as soon as a game has been paid for.



Ready to Play Mode Display 1



Ready to Play Mode Display 2

## READY-TO-PLAY MODE

1. The Ready-To-Play mode starts when enough coins have been accepted for a 1 or 2 player game.
2. The Ready-To-Play mode ends when either the "1 PLAYER" or the "2 PLAYER" push button is pressed.
3. In the Ready-To-Play mode, the game will give the above displays **centered** on the monitor screen.
4. If no START button is pressed, the displays will remain indefinitely as shown above.

## PLAY MODE


1. The Play mode begins when either the "1 PLAYER" or "2 PLAYER" start button is pressed.
2. The Play mode ends when all of your SHIPS have been eliminated. When this happens, "GAME OVER" is written across the center of the monitor screen.
3. **ON THE SCREEN:** The game is made up of 20 racks which increase in difficulty as you go along. After the 20th rack has been completed, the game repeats the basic format for rack #1 but adds some additional obstacles that were not there the first time you played it.

At the beginning of each rack, the game tells which player is up.

Also indicated in each rack is that rack's number, the number of players (1 or 2), a running total of the player's score(s), time left on shield, and the highest game score to date.

4. **PLAY BEGINS:** Your SHIP appears at the bottom of the screen, after all other objects have appeared. Play then begins for your SHIP. Your SHIP is protected for the first few seconds after it has appeared. This is indicated by its flickering image — protection ends when the image solidifies.
5. **ENEMY SHIPS/MINES/SPEED DEMONS, ETC.:** Initially, you will experience only one type of attacker at any one time per rack. In later racks, you will have several different types of attackers per rack coming at you at any one time. The characteristics of each attacker are different. All the Enemy SHIPS/MINES/SPEED DEMONS, ETC. listed in the scoring table will eventually appear during the game course. Certain ones only appear in the higher, more difficult, racks; and/or, if you spend too much time in any one rack. As your abilities improve, you'll find out which these are.

6. **BLACK HOLE:** The BLACK HOLE is one of those little surprises I was telling you about above. It appears if you should spend too much time in any one rack — or — when your skills have improved enough to reach the upper racks. When it latches on to your SHIP, it will take it all over the screen for about 15 seconds. During this time you still are able to fire your SHIP'S weapon and to use your shield, but you have **NO** control over your direction on the screen.
7. **SMART BOMBS:** These appear randomly as atom-like shapes and move randomly over the screen. While doing this they alternate colors between green and blue. If shot when they are green, they will explode and wipe out everything on the screen EXCEPT your SHIP. If shot when they are blue, nothing happens. Also, touching them with your SHIP at any time will cause **NO** problems.
8. **MISSILE FIRE:** This is done by pulling the trigger of your joy stick. Pull and release — one missile is fired. Pull and hold — four missiles are fired — short pause — four more missiles are fired, and so on.
9. **MISSILE AIMING:** Rotating the knob on the left side of the control panel will aim your SHIP'S launcher in any of 8 directions.
10. **SHIELD:** Your SHIP'S shield is activated by pushing down on the MISSILE AIMING knob. The shield does not last very long so be careful how you use it. It can only be recharged by guiding your SHIP inside the mother ship through one of its rotating ports. Your shield time is displayed at the bottom center of the screen.
11. **SHIP:** Your SHIP can move LEFT, RIGHT, UP, and DOWN on the screen. Its movements are controlled by the joy stick on the game's control panel.




Display of "On-Screen" Graphics During Game Play

12. **KOZMIK JUNK YARD:** This is a BONUS RACK. It appears every fifth rack (5th, 10th, 15th, 20th, etc.). You **CANNOT** loose a SHIP here. There are four parts scattered throughout the junk yard for you to pick up before the time limit runs out. If you get all four, you can get an extra SHIP awarded to you.

There are hazards in the junk yard that can slow you down. The chief one of these is the trails of space turbulence caused by passing asteroids. You cannot maneuver across them. There is also a talking inhabitant of the junk yard that will detect your presence and bend your ear if you get too close to his residence. And once this happens, you won't be able to get away until he's done talking.


13. **BONUS SHIPS:** These can be awarded to the player as he reaches or passes certain pre-selected point values. This feature is adjustable by the game's Owner/Operator.
14. **PLAY ENDS:** When your last SHIP is eliminated, "GAME OVER" is written across the center of the monitor screen.
15. **HIGH SCORE/INITIAL MODE:** If your score was high enough to become one of the ten best scores, the game will go into the High Score/Initial mode immediately after the above display. If your score is not high enough to cause the game to go into the High Score/Initial mode, it will either go to the Attract mode (if there are no more credits left in its memory) or into the Ready-To-Play mode (if there are still credits left in its memory). In the High Score/Initial mode the game gives a display which looks like that shown below.



**High Score/Initial Mode**

Follow the ON-SCREEN instructions to enter your initials next to your score in the league of the best ten players to date.

When you've printed out your last initial, move the cursor opposite the "END" word and activate the same control you did to enter your initials. This tells the game you are through printing out your initials. The game will then give the following RANKINGS display showing your score opposite your ranking and your initials. See below.



**Rankings Display**

**NOTE:** If you don't tell the game you are through printing out your initials as instructed above, the game will automatically go into the RANKINGS display after a short wait.

After the High Score/Initial mode, the game will either go to the Attract mode (if there are no more credits left in its memory) or into the Ready-To-Play mode (if there are still credits left in its memory).

16. Most of the above holds true in the "2 PLAYER" mode also. But there are a few minor differences.

## TWO PLAYER OPERATION

The Upright models all have two player operation.

In the two player mode, the rules of play are the same as in the single player mode. There are some additional rules, however.

1. The players must take turns at the controls.
2. Your turn lasts until:
  - A. Your SHIPS are ALL eliminated.
  - B. Your SHIPS have ALL entered the mother ship.

### **SHIP ELIMINATED — OTHERS REMAINING IN RESERVE**

- The game stops and your next SHIP is displayed on the screen.
- Game play then resumes for you.

### **YOUR LAST SHIP ENTERS THE MOTHER SHIP**

- Your SHIPS are returned to you and bonus points for each returned SHIP are displayed on screen.
- Next, the game indicates the other PLAYER is up, that player's pattern and SHIP appear on the monitor screen, and game play begins for that PLAYER.
- This PLAYER'S turn will last until either ALL his SHIPS are eliminated or until they all enter the mother ship.

### **SHIP ELIMINATED — NO OTHERS REMAINING IN RESERVE**

- Game displays: "PLAYER \_\_\_\_" "GAME OVER" on the monitor screen.
- Next, if your score was high enough, the game will go into the HIGH SCORE/INITIAL mode. After this, it will indicate that the remaining PLAYER is up, that player's pattern and SHIP appear on the monitor screen, and game play begins for him.
- If your score was not high enough to cause the game to go into the HIGH/SCORE INITIAL mode, it will indicate that the remaining PLAYER is up, that player's pattern and SHIP appear on the monitor screen, and game play begins for him.

### **LAST PLAYER'S SHIP ELIMINATED — NO OTHERS REMAINING IN RESERVE**

- Game displays: "PLAYER \_\_\_\_" "GAME OVER" on the monitor screen.
- Next, if your score was high enough, the game will go into the HIGH SCORE/INITIAL mode and then either to the Attract mode (if there are no more credits left in its memory) or into the Ready-To-Play mode (if there are still credits left in its memory).
- If your score was not high enough to cause the game to go into the HIGH SCORE/INITIAL mode, the game will either go to the Attract mode (if there are no more credits left in its memory) or into the Ready-To-Play mode (if there are still credits left in its memory).

# III. Maintenance and Repair

Your **NEW** game needs certain types of maintenance to keep it in good working order. **CLEAN**, well **MAINTAINED** games **attract players** and **EARN MORE PROFITS**.

The most important thing for you to remember is to run the Self-Test **EVERY TIME** you collect money from the coin box. **JUST LOOKING** at your game **WILL NOT** tell you if all its controls and inside parts are working correctly. The Self-Test will inform you whether or not your game is working the way it should.

The second most important thing you should remember is to clean the outside of the game and coin acceptor mechanisms on a regular basis.

## CLEANING

The outside of the game cabinet plus the metal can be cleaned with any non-abrasive household cleaner. However, the front of the T.V. monitor tube and **both sides** of all other glass and plastic on or in the game **MUST** be cleaned with anti-static cleaner **ONLY**. For cleaning the coin acceptors: hot soapy water may be used on the plastic ones and any household cleanser may be used on the metal ones. If you wish, special coin machine cleaners that leave no residue may be purchased from your distributor.

DO NOT dry-wipe any of the plastic panels. This is because any dust that was on them can scratch their surfaces. If this has happened, anyone looking through this type of damaged plastic would feel he was looking at the game through a fog. This fogging damage **CANNOT** be repaired or reversed. The **ONLY** solution is to **replace** the damaged piece of plastic.

## FUSE REPLACEMENT

This game contains several fuses located as shown in Figure 3-1.

### 1. UPRIGHT MODEL:

As viewed from the back, facing the cabinet, with the rear access door(s) removed; the fuses are located on the Power Chassis and the Power Supply P.C. Board.

Replace fuses **ONLY** with the type and size listed in the Illustrated Parts Breakdown Section of your manual.

See the T.V. Monitor Manual (available on request from your distributor or the monitor manufacturer) and/or the T.V. Troubleshooting Section of this manual for information on these fuses.




Figure 3-1 Location of Fuses

## OPENING THE CONTROL PANEL

### 1. UPRIGHT MODEL: See Figure 3-2.

- The control panel is held in place by a nylon retaining strap and three latches, one on each side and one in the center at its back edge.

They are spring loaded to provide constant positive pressure on their latch plates.

They can be reached through the coin door **AFTER turning power to the game off.**

To release the latches, lift up and toward the front center of the control panel.

Once they are released, unhook them from their latch plates.

- To remove the control panel:

Raise it up and tilt it toward you until you can see the cable and nylon retaining strap behind it.

Cradling the control panel between yourself and the cabinet, disconnect it from its cabling and nylon retaining strap.




Figure 3-2 Opening the Control Panel

The control panel is now free and can be removed.

- To reinstall the control panel, reverse this procedure.

## REMOVAL OF THE MAIN-DISPLAY-GLASS AND/OR THE T.V. BEZEL ASSEMBLY

### 1. UPRIGHT MODEL:

- **Turn the power to the game off** and remove the screws which secure the glass clamping plate in position. See Figure 3-3.

- Lift out the glass clamping plate. This frees the main-display-glass so it can be lifted up.

- By putting your finger in the hole in the middle of the main-display-glass support, you can lift it up and out.

- To reinstall the main-display-glass and glass clamping plate, reverse this procedure.




Figure 3-3 Removing the Main-Display-Glass & T.V. Bezel

## T.V. MONITOR REPLACEMENT

**CAUTION:** High voltages may exist in any television unit, even with the power disconnected. Use **EXTREME CAUTION** and do not touch electrical parts or the T.V. yoke area with your hands or with metal objects held in your hands!

In addition, **BE SURE TO USE HEAVY GLOVES** when handling the monitor. You could cut your hands on the metal T.V. chassis without such protection.

**DANGER:** The T.V. monitor **DOES NOT** contain an isolation transformer on its chassis (it is mounted instead on the floor of the cabinet). When servicing the monitor on a test bench, **YOU MUST ISOLATE THE MONITOR FROM AC VOLTAGE WITH AN ISOLATION TRANSFORMER.**

1. **UPRIGHT MODEL:** See Figure 3-4.

- Turn power off to the game.
- Open the rear access doors.
- Completely disconnect the T.V. monitor from all its cabling. **DON'T FORGET THE CHASSIS GROUND WIRE.**
- With the removal of only four bolts, the T.V. monitor will be loose.

**CAUTION:** BE SURE to support the T.V. monitor from the rear while removing the four bolts so it will not slip.




Figure 3-4 Removing the Monitor

- The monitor mounting bars slide on top of and against two metal guides mounted to the cabinet's right and left sides. The monitor is removed by sliding it out the back of the cabinet. See Figure 3-4.
- To reinstall the T.V. monitor, reverse this procedure.
- After replacing the T.V. monitor, be sure to run the game Self-Test.

## PRINTED CIRCUIT BOARD (P.C.B.) REPLACEMENT

1. **UPRIGHT MODEL:** See Figure 3-4.

- Turn the power to the game off.
- Unlock and open the rear access door(s).
- Disconnect all cabling from the P.C. boards and lift them out of their card rack.
- Disconnect the linear power supply board from all its cabling, remove the P.C.B. support(s) indicated in Figure 3-5, and slide the linear power supply board out the back of the cabinet.
- To reinstall the above P.C.B.'s, reverse this procedure.

**NOTE:** P.C.B.'s are all keyed and will **ONLY** fit into their connectors one way without forcing them. The plugs on the cable harness which connect it to the P.C.B.'s are also keyed and will **ONLY** go onto their connectors one way without forcing them.




Figure 3-5 Removing the P.C.B.'s



## OPENING THE ATTRACTION PANEL

### 1. UPRIGHT MODEL:

- Turn the power to the game off.
- Opening the attraction panel:  
Remove the screws which secure the top bracket in place. (They are on its top side.) See Figure 3-6.  
Remove the top bracket and slide up the attraction panel. This exposes the speakers, fluorescent tube, and their mountings.  
To reinstall the attraction panel, reverse this procedure.
- The fluorescent light tube may be replaced at this time. **BE CAREFUL NOT TO DROP IT.**

**WARNING: If you drop a fluorescent tube and it breaks, IT WILL IMplode! Shattered glass can fly six (6) feet or more from the implosion. Use care when replacing any fluorescent tube.**


- Replacing the fluorescent light tube starter. See Figure 3-7.

#### **Be sure the power to the game has been turned off.**

Grasp the starter (it is on the back of the mounting bracket), give it a quarter turn, and remove it from its socket.

To replace the fluorescent light tube starter, reverse this procedure.

- Removing the speaker(s):  
The attraction panel **MUST** be removed first. This will enable you to reach all the necessary areas where cables **MUST** be disconnected.  
Disconnect the speaker(s) from all their cabling.  
Remove the screws which secure the speaker grill to the cabinet.




**Figure 3-6 Opening the Attraction Panel**

The speaker attachment nuts and bolts may now be removed and the speaker(s) taken out of the cabinet through the hole in the front of the game where the attraction panel was mounted.

To reinstall the speaker(s) and speaker grill, reverse this procedure.

- Replacement of the fluorescent tube mounting bracket assembly.  
Disconnect it from its power cable.  
Remove the screws which secure it to the cabinet.  
To reinstall the fluorescent tube mounting bracket, reverse this procedure.



**Figure 3-7 Replacing Fluorescent Tube Starter**

## SERVICING THE BLACK LIGHT ABOVE CONTROL CONSOLE

### 1. UPRIGHT MODEL:

- Turn the power to the game off and remove the screws which secure the glass clamping plate in position. See Figure 3-8

Lift out the glass clamping plate.

Remove the screws which secure the bottom of the black light shield to the front service panel.

BE SURE you support the black light shield as you remove these screws so it will not fall on the floor. The black light tube may be replaced at this time. BE CAREFUL NOT TO DROP IT.

**WARNING: If you drop a black light tube and it breaks, IT WILL IMplode! Shattered glass can fly six (6) feet or more from the implosion. Use care when replacing any black light tube.**

To reinstall the black light shield, reverse this procedure.

- Replacing the black light tube starter. See Figure 3-7.

**NOTE:** The main-display-glass **MUST** be removed in order to do this. See "Upright Model" procedure.

**Be sure the power to the game has been turned off.**

Grasp the starter (it is on the back of the mounting bracket, just inside the frame for the main-display-glass), give it a quarter turn, and remove it from its socket.

To replace the black light tube starter, reverse this procedure.

## SERVICING THE FLUORESCENT LIGHT BEHIND THE FRONT SERVICE PANEL

- Remove the front service panel.

**Turn the power to the game off.**

**NOTE:** In order to do this, the following items **MUST** be removed first, in this order, to make room: 1) the main-display-glass glass clamping plate; 2) the black light shield; and 3) the control panel. See the appropriate sections of this manual for removal instructions.

Remove the screws at the top of the front service panel which secure it to the cabinet.

Tilt it back to clear the black light and lift it up and out as shown in Figure 3-8.

To reinstall the front service panel, reverse this procedure.

- The fluorescent light tube may be replaced at this time. BE CAREFUL NOT TO DROP IT.

**WARNING: If you drop a fluorescent tube and it breaks, IT WILL IMplode! Shattered glass can fly six (6) feet or more from the implosion. Use care when replacing any fluorescent tube.**

- Replacing the black light tube starter. See Figure 3-7.

**Be sure the power to the game has been turned off.**

Grasp the starter (it is on the back of the mounting bracket, give it a quarter turn, and remove it from its socket.

To replace the fluorescent light tube starter, reverse this procedure.





Figure 3-8 Servicing Center Auxiliary Lighting

## **IV. Illustrated Parts Breakdown**

NO. 639 — KOZMIK KROOZ'R — FRONT



**NO. 639 — KOZMIK KROOZ'R — FRONT — PARTS LIST**

*ORDER BY PART NUMBER ONLY*


<b>ITEM</b>	<b>PART NO.</b>	<b>DESCRIPTION</b>
1	0639-00909-00XF	DISPLAY HEADER
2	A639-00030-0000	HEADER FLUOR. LIGHT ASSY.
3	0537-00903-0066	GLASS CHANNEL — 5-7/8" LG. (2 REQ'D.)
4	0537-00903-0004	GLASS CHANNEL — 22-1/4" LG.
5	0574-00903-0100	HEADER RETAINING BRKT.
6	0639-00111-00XF	RETAINER GRILL
	0017-00101-0138	#8 x 5/8 TORX TAMPER RESISTANT BLK. SCR. (16 REQ'D.)
7	0017-00003-0430	6" x 9" SPEAKER — 4 OHM, 10W. (2 REQ'D.)
	0017-00101-0127	#8-32 x 1-1/2 CARRIAGE BOLT (8 REQ'D.)
	0017-00103-0061	#8-32 HEX NUT W/SEMS (8 REQ'D.)
	A639-00055-0000	SPEAKER CABLE ASSY.
8	0639-00907-00XF	MAIN VIEWING GLASS
9	0537-00903-0068	GLASS CHANNEL — 17" LG. (2 REQ'D.)
10	0537-00903-0034	GLASS CHANNEL — 23" LG.
11	0639-00102-00XF	DISPLAY GLASS RETAINER BRKT.
12	0639-00100-00XF	LAMP PROTECTOR MTG. BRKT.
13	0639-00902-0000	LAMP PROTECTOR
	0017-00101-0138	#8 x 5/8 TORX TAMPER RESISTANT BLK. SCR. (10 REQ'D.)
14	A639-00031-0000	BLACK LIGHT ASSY.
15	A639-00054-0000	ACCESS PANEL ASSY.
16	A639-00041-0000	OVERLAY TO WELDMENT ASSY.
	A639-00042-0000	CONTROL SHELF WELDMENT ASSY.
	0639-00919-0000	DECORATIVE OVERLAY
	0639-00124-0100	CONTROL SHELF MTG. BRKT. — LEFT
	0639-00124-0200	CONTROL SHELF MTG. BRKT. — RIGHT
	0555-00901-0000	PLASTIC LOCATING PIN (4 REQ'D.)
	0017-00009-0534	BASSICK CLAMP (3 REQ'D.)
	0017-00101-0141	#8 x 11/16 UNSLOT. HEX HD. SCR. (12 REQ'D.)
	0639-00127-0000	CONTROL SHELF LOCK BRKT.
17	A639-00034-0000	KNOB & SHAFT ASSY.
	A639-00043-0000	OPTICAL ENCODER DISC ASSY.
18	A628-00032-0000	GRIP W/SWITCH ASSY.
	A639-00023-0000	ANALOG CONTROL ASSY.
	A089-00020-0000	CONTROL GRIP CABLE ASSY. — 16" LG.
	A639-00008-0000	CONTROL SHELF CABLE ASSY.
19	0017-00042-0260	PUSH BUTTON ASSY. — WHITE (2 REQ'D.)
	0017-00032-0093	PUSH BUTTON SWITCH W/HOLDER (2 REQ'D.)
	0017-00103-0054	5/8-11 PAL NUT (2 REQ'D.)
20	0639-00920-0200	DECAL — LEFT SIDE
	0639-00920-0100	DECAL — RIGHT SIDE (NOT SEEN)
21	A090-00300-11BK	U.S.A. 25¢ DOUBLE COIN DOOR ASSY.
	A982-00015-0000	COIN DOOR CABLE ASSY.

**NO. 639 — KOZMIK KROOZ'R — FRONT — PARTS LIST (Continued)**

*ORDER BY PART NUMBER ONLY*

ITEM	PART NO.	DESCRIPTION
22	0090-00002-04BK 0017-00101-0121  0950-00004-0000 A950-00006-0000 0950-00105-0000 0950-00104-0000 0950-00101-0000 0950-00900-0000 0950-00103-0000 0017-00101-0142 0017-00104-0014 0017-00103-0018	LARGE COIN DOOR FRAME #6-32 x 5/16 PHIL. TRS. HD. SCR. (3 REQ'D.) (MOUNTS COIN DOOR TO FRAME) COIN BOX ASSEMBLY COIN BOX CRADLE ASSY. COIN BOX COVER COIN BOX HANDLE COIN DEFLECTOR (2 REQ'D.) LARGE PLASTIC COIN BOX COIN BOX DIVIDER — OPTIONAL 1/4-20 x 1-3/8 BLACK RND. HD. BOLT (4 REQ'D.) 7/8" DISH WASHER (4 REQ'D.) 1/4-20 HEX NUT (4 REQ'D.)
23	A639-00032-0000 0639-00910-0000	STEP STOOL ASSY. STEP STOOL MAT
24	0017-00102-0048 0017-00103-0026	3/8-16 x 2" LEG LEVELERS (4 REQ'D.) 3/8-16 LEG LEVELER HEX NUTS (4 REQ'D.)

**NO. 639 — KOZMIK KROOZ'R — UPRIGHT  
HEADER FLUORESCENT LIGHT ASSY. & BLACK LIGHT ASSY.**




**NO. 639 — KOZMIK KROOZ'R — UPRIGHT  
HEADER FLUORESCENT LIGHT ASSY. & BLACK LIGHT ASSY. — PARTS LIST**

*ORDER BY PART NUMBER ONLY*

ITEM	PART NO.	DESCRIPTION
1	0639-00113-0000	HEADER FLUORESCENT BRKT.
1	0639-00107-0000	BLACK LIGHT BRKT.
2	0017-00003-0043	18" COOL WHITE FLUOR. LIGHT LAMP
2	0017-00003-0095	18" BLACK LIGHT LAMP
3	0017-00003-0445	LAMP LOCKS (2 REQ'D.)
4	0017-00031-0036	FLUORESCENT SOCKET (2 REQ'D.)
5	0017-00003-0412	FLUORESCENT STARTER HOLDER W/LEADS
	0017-00101-0573	#6-32 x 1/2 PHIL. RND. HD. M.S. (4 REQ'D.)
	0017-00104-0009	#6 EXT. WASHER (4 REQ'D.)
6	0017-00003-0019	FLUORESCENT STARTER
7	0017-00003-0026	BALLAST
	0017-00101-0598	#8-32 x 5/16 SLT. HEX HD. SCR. (4 REQ'D.)
8	A961-00042-0000	LINE FILTER ASSY.

NO. 639 — KOZMIK KROOZ'R — REAR ACCESS







**NO. 639 — KOZMIK KROOZ'R — REAR ACCESS — PARTS LIST**

*ORDER BY PART NUMBER ONLY*

ITEM	PART NO.	DESCRIPTION
1	A945-00038-0000	ON-OFF SWITCH & PLATE ASSY.
2	0894-00913-0000	RECESSED HAND LIFT (2 REQ'D.)
3	0017-00101-0138	#8 x 5/8 TORX TAMPER RESISTANT BLK. SCR. (12 REQ'D.)
3	0017-00003-0339	ELECTROHOME — 19" COLOR DUAL SYNC HORIZ. MTG. MONITOR (OR)
3	0017-00003-0439	WELLS-GARDNER — 19" COLOR DUAL SYNC HORIZ. MTG. MONITOR (OR)
3	0017-00003-0454	ZENITH — 19" COLOR DUAL SYNCH HORIZ. MTG. MONITOR
4	0550-00100-0000	MONITOR RAIL (2 REQ'D.)
	0555-00901-0000	PLASTIC LOCATING PIN (4 REQ'D.)
	0017-00101-0141	#8 x 11/16 UNSLOT HEX HD. M.S. (8 REQ'D.)
	0017-00102-0066	1/4-20 x 3/4 UNSLOT. HEX HD. BOLT (4 REQ'D.)
	0017-00104-0014	7/8" DISH WASHER (4 REQ'D.)
5	0639-00908-0000	MONITOR BEZEL
6	0639-00901-0000	CURVED GLASS MIRROR
	0639-00112-00XF	MIRROR HOLD DOWN BRKT. (2 REQ'D.)
7	0639-00905-0000	DEEP SPACE SCENERY
8	A639-00045-0000	SHIP ASSEMBLY — NOT SEEN
	A639-00039-0000	ADJUSTMENT BRKT. ASSY.
9	A639-00037-0000	SPOT LIGHT ASSY. — NOT SEEN (2 REQ'D.)
10	A088-00016-0000	INTERLOCK SWITCH & SPRING BRKT. ASSY. (2 REQ'D.)
11	A084-90509-C000	SOLID STATE RELAY P.C. BOARD ASSY.
12	A082-90910-E000	DUAL POWER AMP P.C. BRD. ASSY.
	0017-00042-0014	1/8" SNAP BUSHING (4 REQ'D.)
	0017-00101-0751	#5-40 x 1/4 PHL. RND. HD. M.S. (4 REQ'D.)
13	A082-90412-D000	POWER SUPPLY P.C. BOARD ASSY.
	0624-00902-0100	P.C. SUPPORT BRKT. — 12" LG. (2 REQ'D.)
	0624-00902-0500	P.C. SUPPORT BRKT. — 6-1/2" LG. (2 REQ'D.)
	0317-00102-0000	P.C. MTG. BRACE BRKT. (4 REQ'D.)
	0017-00101-0141	#8 x 11/16 UNSLOT HEX HD. M.S. (12 REQ'D.)
	0017-00104-0037	#8 FLAT WASHER (12 REQ'D.)
14	A639-00005-0000	CARD RACK W/BOARDS ASSY.
	A084-90010-A639	C.P.U. P.C. BOARD ASSY.
	A084-91399-A639	VIDEO/GENERATOR P.C. BOARD ASSY.
	A084-91483-A639	SOUND I/O P.C. BOARD ASSY.
	A639-00060-0000	SHIELD & BARRIER ASSY.
	A639-00059-0000	INNER SHIELD & SPACER ASSY.
	A639-00061-0000	OUTER SHIELD & SPACER ASSY.
	0017-00101-0134	#6-32 x 1/4 PHIL. RND. HD. M.S. (8 REQ'D.)
	0017-00101-0153	#6-32 x 1" PHIL. RND. HD. M.S. (4 REQ'D.)
15	A945-00020-0000	POWER CHASSIS ASSY. — 125VA., 115V.
16	A961-00007-0000	CASTER ASSY. (2 REQ'D.)
17	A945-00019-0000	LINE CORD ASSY.
		<b>ADDITIONAL PARTS LIST</b>
	A097-00008-0000	BACK DOOR LOCK ASSY. (2 REQ'D.)
	0017-00009-0490	5-5/8" SQR. VENT GRILL — BACK DOOR (4 REQ'D.)
	A639-00010-0000	MASTER CABLE W/BRKT. ASSY.
	A639-00012-0000	HIGH VOLTAGE CABLE ASSY.
	A941-00008-0000	LOW VOLTAGE CABLE ASSY.
	A337-00018-0000	VIDEO SIGNAL CABLE ASSY.

NO. 639 — KOZMIK KROOZ'R — SHIP ASSEMBLY




**NO. 639 — KOZMIK KROOZ'R — SHIP ASSEMBLY — PARTS LIST**

*ORDER BY PART NUMBER ONLY*

<b>ITEM</b>	<b>PART NO.</b>	<b>DESCRIPTION</b>
1	0639-00918-0000	KOZMIK KROOZ'R
2	0639-00929-0000	COCKPIT
	0639-00927-0000	DECAL (3 REQ'D.)
3	0639-00912-0000	CANOPY
	A639-00051-0000	KOZMIK KROOZ'R BODY ASSY. (FIRST 3 ITEM NO'S.)
4	0017-00101-0159	#4 x 1/2 PHIL. RND. HD. BLACK SCREW (3 REQ'D.)
5	0017-00042-0327	PLASTIC GROMMET (3 REQ'D.)
6	0639-00917-0000	KOZMIK KROOZ'R MTG. BASE
7	A080-91478-B639	LAMP P.C. MTG. BOARD
8	0017-00031-0051	WEDGE BASE SOCKET W/LEAD
9	0017-00031-0046	WEDGE BASE SOCKET (2 REQ'D.)
10	0017-00003-0463	WEDGE BASE LAMP — 14V. (3 REQ'D.)
11	0017-00101-0001	#4 x 1/4 PHIL. PAN HD. SCR. (4 REQ'D.)
12	0639-00710-00XF	SPINDLE
13	0017-00100-0031	5/16" E-RING (2 REQ'D.)
14	0017-00100-0025	1/4" E-RING (2 REQ'D.)
15	0017-00104-0094	PLASTIC FLAT WASHER (3 REQ'D.)
16	0017-00103-0069	5/16-24 HEX NUT (2 REQ'D.)
17	0639-00914-0000	GEAR
18	A639-00047-0000	GEAR & FLAG ASSY.
19	A639-00038-0000	ADAPTOR ASSY.
20	A639-00040-0000	MTG. BRKT. ASSY.
21	A084-91434-D639	SENSOR P.C. BRD. ASSY.
22	0017-00042-0326	PLASTIC GROMMET (2 REQ'D.)
23	0017-00101-0014	#6 x 1/2 SLT. HEX HD. SCR. (2 REQ'D.)
24	0639-00923-0000	P.C. BRD. SHIELD
25	A639-00056-0000	MOTOR & CONNECTOR ASSY.
26	0017-00101-0528	#5-40 x 3/4 PHIL. RND. HD. M.S. (2 REQ'D.)
27	0639-00118-00XF	MTG. BRKT.
28	0639-00121-00XF	ADJUSTER
29	0010-00603-0000	EXTENSION SPRING (2 REQ'D.)
30	0017-00101-0665	#10-32 x 7/8 UNSLOT. HEX HD. WHZ. BOLT.
31	0017-00101-0656	#10-32 x 1/2 SLT. PAN HD. SCREW (2 REQ'D.)
	A639-00039-0000	ADJUSTMENT BRKT. ASSY. (ITEMS 27 THRU 31)

NO. 639 — KOZMIK KROOZ'R — ANALOG CONTROL ASSY.




NO. 639 — KOZMIK KROOZ'R — ANALOG CONTROL ASSY. — PARTS LIST

ORDER BY PART NUMBER ONLY

ITEM	PART NO.	DESCRIPTION
1	0873-00900-0400	CONTROL GRIP — LEFT
2	0873-00900-0300	CONTROL GRIP — RIGHT
3	0639-00926-0000	LENS
4	0628-00906-0000	TRIGGER
5	A628-00028-0000	LEAF SWITCH ASSY.
	0020-00202-0000	SWITCH PLATE
	0017-00101-0528	#5-40 x 3/4 PHIL. RND. HD. M.S. (2 REQ'D.)
	0873-00123-00XF	SWITCH MTG. BRKT.
	0017-00101-0083	#4-20 x 3/8 PHIL. PAN HD. SCR. (2 REQ'D.)
6	0017-00101-0149	#10-32 x 3/8 TORX TAMPER RESISTANT BUTTON HD. SCREW (5 REQ'D.)
7	A639-00025-0000	TUBING & PIVOT PIN — PINNING ASSY.
	0628-00921-0000	SLEEVE — NOT SEEN
8	0628-00904-0000	SLIDE
9	0873-00113-00XF	BUMPER MTG. BRKT.
10	0639-00903-0000	BUMPER — 8 POSITION
11	0017-00101-0615	#8-32 x 3/8 SLT. PAN HD. M.S. (4 REQ'D.)
12	A639-00020-0000	CENTERING BRKT. WELD ASSY.
13	0628-00905-0000	GROMMET
14	0017-00104-0034	FLAT WASHER
15	0017-00103-0082	7/16-14 NYLON INSERT LOCKING NUT
16	0639-00700-00XF	ACTUATING PIN
17	0873-00706-00XF	PIVOT BUSHING
18	0017-00100-0015	5/32 E-RING
19	0017-00101-0799	#10-32 x 3/8 SLT. HEX HD. SCREW (4 REQ'D.)
20	0017-00103-0081	#10-32 HEX NUT W/SEMS (4 REQ'D.)
21	0017-00101-0598	#8-32 x 5/16 SLT. HEX HD. SCR. (10 REQ'D.)
22	0639-00108-0000	WEAR PLATE BRKT.
23	0639-00906-0000	WEAR PLATE
24	A639-00013-0000	SLIDE & MTG. BRKT. RIVET ASSY.
25	A084-91458-E000	ANALOG JOYSTICK P.C. BRD. ASSY.
26	A639-00014-0000	ACTUATING BRKT. ASSY. — UPPER
27	A639-00015-0000	ACTUATING BRKT. ASSY.
28	0069-264XX-XBYX	CORE (2 REQ'D.)
	0017-00103-0002	#4-40 HEX NUT (2 REQ'D.)
29	0010-00268-0000	EXTENSION SPRING (2 REQ'D.)
30	0639-00701-00XF	P.C. MTG. POST (4 REQ'D.)
31	0017-00101-0755	#6-32 x 5 SLT. PAN HD. M.S. (8 REQ'D.)
32	A089-00020-0000	CONTROL GRIP CABLE ASSY. — 16" LG.
	0010-00266-0100	SPRING EXTENSION STRAIN RELIEF
	0017-00021-0299	2 PIN CONNECTOR

NO. 639 — KOZMIK KROOZ'R — KNOB & SHAFT — ENCODER DISC ASSY.




**NO. 639 — KOZMIK KROOZ'R — KNOB & SHAFT — ENCODER DISC ASSY. — PARTS LIST**

*ORDER BY PART NUMBER ONLY*

<b>ITEM</b>	<b>PART NO.</b>	<b>DESCRIPTION</b>
1	A639-00034-0000 0639-00925-0000	KNOB & SHAFT ASSY. KNOB INSERT LABEL
2	0017-00100-0050	1/2" E-RING (2 REQ'D.)
3	0017-00104-0045	FLAT WASHER
4	0017-00104-0079	PLASTIC WASHER
5	A639-00035-0000	BEARING TO BUSHING ASSY.
6	0639-00704-00XF	MAIN SHAFT
7	A639-00048-0000	SENSOR DISC ASSY.
8	0017-00101-0791	#8-32 x 1/4 HEX CUP SET SCREW (2 REQ'D.)
9	0639-00705-00XF 0639-00911-0000	STOP STUD ROLLER SLEEVE
10	0639-00114-0000	SWITCH MTG. BRKT.
11	0017-00101-0124	#6 x 1/4 UNSLOT. HEX HD. M.S. (4 REQ'D.)
12	A639-00058-0000	LEAF SWITCH ASSY.
13	0020-00202-0000 0017-00101-0527	SWITCH PLATE #5-40 x 5/8 PHIL. RND. HD. SCR. (2 REQ'D.)
14	0531-00106-0000	P.C. MTG. BRKT.
15	0017-00101-0586	#8-32 x 3/16 SLT. PAN HD. M.S. (2 REQ'D.)
16	A084-91482-A000	OPTICAL ENCODER P.C. BRD. ASSY.
17	0017-00042-0072	PLASTIC GROMMET (4 REQ'D.)
18	0017-00101-0018	#6 x 3/4 SLT. HEX HD. WD. SCR. (4 REQ'D.)

KOZMIK KROOZ'R — POWER CHASSIS ASSY. — 125VA., 115V.






**KOZMIK KROOZ'R — POWER CHASSIS ASSY. — 125 VA., 115V. — PARTS LIST**

**ORDER BY PART NUMBER ONLY**

ITEM	PART NO.	DESCRIPTION
1	0945-00104-00XF	CHASSIS
2	A945-00029-0000	MTG. PLATE & BARRIER ASSY.
3	0945-00107-01XF	STRAP (2 REQ'D.)
4	0017-00101-0123	#8 x 1/4 UNSLOT. HEX HD. SCR. (12 REQ'D.)
5	MT00-00101-A000	ISOLATION TRANSFORMER W/O SHIELD ASSY. — 115V., 50/60 HZ.
	0017-00103-0061	#8-32 HEX NUT W/SEMS (4 REQ'D.)
6	MT00-00099-A000	POWER TRANSFORMER ASSY. — 115V., 60 HZ.
	0017-00103-0084	#6-32 HEX NUT W/SEMS (4 REQ'D.)
7	0175-181T4-GXJK	CAPACITOR — 3.5 M.F., 440V.
8	0017-00009-0535	CLAMP
	0017-00101-0565	#6-32 x 7/16 SLT. PAN HD. SCR.
	0017-00103-0084	#6-32 HEX NUT W/SEMS
9	0017-00101-0067	#6 x 3/8 PHIL. PAN HD. SCR. (11 REQ'D.)
	0945-00103-00XF	PARTITION — LOCATED UNDER CHASSIS (NOT SEEN)
10	0945-00902-0000	SNAP BUSHING (3 REQ'D.)
11	0017-00021-0297	2 POSITION CONNECTOR
12	A945-00030-0100	CONNECTOR & CABLE ASSY. #1
13	A945-00030-0200	CONNECTOR & CABLE ASSY. #2
14	A945-00021-0000	CONVENIENCE OUTLET ASSY.
15	0017-00101-0573	#6-32 x 1/2 PHIL. RND. HD. SCR. (2 REQ'D.)
	0017-00103-0084	#6-32 HEX NUT W/SEMS (2 REQ'D.)
	A945-00025-0000	FILTER ASSEMBLY — 125V. — UNDER CHASSIS (NOT SEEN)
16	0017-00021-0510	TERMINAL STRIP
17	0017-00101-0140	#4-40 x 5/16 PHIL. PAN HD. SCR. (2 REQ'D.)
18	0017-00003-0263	SLO-BLO FUSE — 4A., 250V.
19	0017-00003-0005	FUSE — 2A., 250V.
	0017-00003-0444	QUICK CONN. FUSEHOLDER (2 REQ'D.) — FOR ABOVE FUSES
20	0945-00816-1902	CAPACITOR — 100,000 M.F.
21	0945-00816-1901	CAPACITOR — 55,000 M.F.
	0017-00104-0107	#10 FLAT WASHER (4 REQ'D.)
	0017-00103-0081	#10-32 HEX NUT W/SEMS (4 REQ'D.)
22	0017-00009-0422	CLAMP (2 REQ'D.)
	0017-00101-0758	#8-32 x 3/4 PHIL. RND. HD. SCREW (2 REQ'D.)
	0017-00103-0061	#8-32 HEX NUT W/SEMS (2 REQ'D.)
23	0017-00101-0067	#6 x 3/8 PHIL. PAN HD. SCR. (6 REQ'D.)
24	0945-00904-0000	5 POSITION FUSE HOLDER
	0017-00003-0263	SLO-BLO FUSE — 4A., 250V.
	0017-00003-0217	SLO-BLO FUSE — 2.5A., 250V. (2 REQ'D.)
	0017-00003-0007	SLO-BLO FUSE — 3A., 250V. (2 REQ'D.)
	0945-00903-0000	FUSE HOLDER BARRIER
	A945-00022-0000	HEATSINK & DIODE ASSY.
	0017-00101-0067	#6 x 3/8 PHIL. PAN HD. SCR. (2 REQ'D.)
25	0017-00101-0780	#6 x 1/2 PHIL. PAN HD. SCREW (2 REQ'D.)
	0017-00021-0629	5 POSITION TERMINAL STRIP — (UNDER CHASSIS)
	A945-00019-0000	LINE CORD ASSY. — 115V. (NOT SHOWN)
26	A945-00030-0500	CONNECTOR & CABLE ASSY.
27	0017-00101-0660	#10-32 x 3/4 PAN HD. SCREW
	0017-00104-0107	#10 FLAT WASHER
	0017-00103-0081	#10-32 HEX NUT W/SEMS

FRONT DOOR ASSEMBLY — U.S.A. 25¢



**FRONT DOOR ASSEMBLY — U.S.A. 25¢ — PARTS LIST**

*ORDER BY PART NUMBER ONLY*

<b>ITEM</b>	<b>PART NO.</b>	<b>DESCRIPTION</b>
1	0090-00002-04BK	DOUBLE ENTRY COIN DOOR FRAME
2	0017-00101-0121	#6-32 x 5/16 PHIL. TRS. HD. SCR. (3 REQ'D.)
3	A090-00073-02BK	DOUBLE ENTRY COIN DOOR W/DRESS PLATE
4	0017-00101-0123	#8 x 1/4 UNSLOT. HEX HD. SCREW (12 REQ'D.)
5	0017-00007-0019	KEY HOOK
6	0017-00103-0059	PUSH NUT (4 REQ'D.)
7	0090-00912-0000	COIN ENTRY PLATE — 25¢ (2 REQ'D.)
8	A097-00005-0000	DOOR LOCK & KEY W/SCREW & NUT (OR)
8	A097-00006-0000	DOOR LOCK & KEY W/SCREW & NUT
9	0090-00128-00XF	DOOR TILT SWITCH BRKT.
10	0017-00005-0225	DOOR CAM
11	A090-00095-0000	DOOR TILT SWITCH
12	0090-00126-03XF	SWITCH BACK-UP PLATE
13	0017-00101-0525	#5-40 x 9/16" PHIL. HD. M.S. (2 REQ'D.)
	A090-00096-0000	DOOR TILT SWITCH & BRKT. ASSY. (ITEMS 9 & 11 THRU 13)
14	0090-00903-9500	25¢ WINDOW (2 REQ'D.)
15	0090-00143-00XF	COIN PLEX RETAINER
16	0017-00003-0219	12 VOLT LAMP — G.E. #194 (2 REQ'D.)
17	0017-00031-0048	WEDGE SOCKET W/BRKT. (2 REQ'D.)
18	A090-00100-0000	BRKT. ASSY.
19	0017-00103-0084	#6-32 HEX NUT W/SEMS (4 REQ'D.)
20	A090-00089-0000	COIN METER W/DIODE
21	0017-00101-0124	#6 x 1/4 UNSLOT. HEX HD. SCR. (4 REQ'D.)
25	0090-00911-0000	INSULATOR (2 REQ'D.)
26	A090-00112-0000	COIN CHUTE & TOP ASSY. (2 REQ'D.)
27	0010-00134-0000	SPRING
28	0010-00181-0000	SPRING
29	0017-00007-0083	1/8 x 1-5/8 ROLL PIN
30	0090-00129-00XF	PIVOT POST
31	0090-00167-00XF	PIVOT LEVER
32	0090-00182-00XF	REJECT LEVER
33	0017-00100-0018	E-RING
	A090-00088-0000	REJECT LEVER ASSY. (2 REQ'D.) (ITEMS 30 THRU 33)
34	A090-00105-0000	COIN ACCEPTOR FRAME ASSY. (2 REQ'D.)
35	0017-00005-0003	COIN ACCEPTOR W/STRING CUTTER (2 REQ'D.) (OR)
35	0017-00005-0211	COIN ACCEPTOR W/ANTI STRING DEVICE (2 REQ'D.) (OR)
35	0017-00005-0214	COIN ACCEPTOR W/STRING CUTTER (2 REQ'D.)
36	A090-00064-0000	ANTI-PENNY DEVICE
37	0017-00101-0099	#6 x 1/4 SLT. HEX HD. M.S. (2 REQ'D.)
38	0090-00162-00XF	COIN SWITCH MTG. BRKT.
39	0017-00005-0203	COIN SWITCH CHUTE
40	0017-00005-0195	COIN SWITCH
41	0010-00599-0000	COIN SWITCH WIRE
42	0017-00007-0015	PUSH-ON RING
	A090-00059-0400	COIN SWITCH & WIRE ASSY. (ITEMS 40 THRU 42)
43	0017-00101-0147	#4-40 x 3/4 PHIL. PAN. HD. M.S. (2 REQ'D.)
	A090-00077-0000	COIN GUIDE & SWITCH ASSY. (ITEMS 38 THRU 43)

# V Technical Troubleshooting

## Introduction

The most common problems occur in harness components such as the coin acceptor, player controls, interconnecting wiring, etc. The TV monitor and PCB computer cause their share of problems too, but not as much as the harness and its component parts. TV monitor troubleshooting will not be covered here because it is covered in that section of this manual.

As you already know, the PCB computer is a complex device with a number of different circuits. Some circuits remain basically the same among games, but overall there are a great many differences between them. PCB troubleshooting procedures, therefore, can be lengthy and will differ greatly among games. However, some basic Z-80 CPU information is involved in this section.

## General Suggestions

The first step in any troubleshooting procedure is correctly identifying the malfunction's symptoms. This includes not only the circuits or features malfunctioning, but also those still operational. A carefully trained eye will pick up other clues as well. For instance, a game in which the computer functions fail completely just after money was collected may have a quarter shorting the PCB traces. Often, an experienced troubleshooter will be able to spot the cause of the problem even before opening the cabinet.

After all the clues are carefully considered, the possible malfunctioning areas can be narrowed down to one or two good suspects. Those areas can be examined by a process of elimination until the cause of the malfunction is discovered.

## Harness Component Troubleshooting

Typical problems falling in this category are coin and credit problems, power problems and failure of individual features.

### NO GAME CREDIT

For example, your prospective player inserts his quarter and is not awarded a game. The first item to check is if the quarter is returned. If the quarter is returned, the malfunction most certainly lies in the coin acceptor itself. First, use a set of test coins (both old and new) to ascertain that the player's coin is not undersize or underweight. If your test coins are also returned, coin acceptor servicing is indicated. Generally, the cause of this particular problem is a maladjusted magnet gate. Normally, this will mean slightly closing the magnet gate a little by turning the adjusting screw out a bit (see section on coin acceptor for more details).

If the quarter is not returned and there is no game credit, the cause of the malfunction may be in one of several areas. First try operating the coin return button; if the coin is returned, the problem is most likely in the magnet gate. Enlarge the gap according to the coin acceptor service procedures. If this does not cure the problem, remove the coin acceptor, clean it and perform the major adjustment procedure.

If the trapped coin is not returned when the wiper lever is actuated, you may have an acceptor jammed by a slug, gummed up with beer, a jammed coin chute, or mechanical failure of the acceptor mechanism. In this case, first check for the slug that will generally be trapped against the magnet. If so, simply remove the slug and test the acceptor. If the chute is blocked, remove the acceptor and remove the jammed coins. If there is actual failure of the acceptor, remove the unit and repair as indicated in the coin acceptor service procedures.

If the coin is making its way through the acceptor (that is, falling into the coin box), yet there is still no game credit, you either have a mechanical failure of the coin switch or electrical failure of the coin and credit circuits. The first place to begin is by checking the coin switch. Most of these switches are the make/break variety of micro switch, which is checked by testing for continuity between the NO, NC, and C terminals. When not actuated, the NC and C terminals should be continuous and the NO terminal open. When operated, the NO and C terminals should close and the NC should be open. If the coin switch checks out, examine the connections to the terminals to make sure there is good contact. If necessary, use the continuity tester and check from the terminal lug on the switch to the associated PCB trace. This will tell you if there is a continuous line all the way to the credit circuit.

If the coin switch wires do not check out, the problem is in the computer — most likely in the coin and credit circuitry.

If you do get game credit when a coin is deposited, but the game will not start when the start switch is pressed, you may have a problem in the start switch, the interconnecting wiring or in the computer. First check the switch. If the switch is OK, proceed to check the wiring. Again, make sure you go from the terminal lug on the switch to the PCB trace. This way, you will check the terminal contact as well as PCB edge connector contact. If the wiring is continuous, proceed to check the PCB credit circuit. If not, check each section of the wiring, until the discontinuity is located. If the wiring is OK, the problem must lie in the computer.

## Transformer and Line Voltage Problems

Your machine must have the correct line voltage to operate properly. If the line voltage drops too low, a circuit in the computer will disable game credit. The point at which the computer will fail to work will vary some from game to game, but no game will work on line voltage that drops below 105 VAC.

Low line voltage may have many causes. Line voltage normally fluctuates a certain amount during the day as the total usage varies. Peak usage times occur mainly at dawn or dusk, so if your machine's malfunction seems to be related to the time of day, this may be a factor. A large load connected to the same line as the game (such as a large air conditioner or other device with an exceptionally large motor) may drop the line voltage significantly when starting up. This drop can result in an intermittent credit problem. In addition, poor connections in the location wiring, plug, or line cord may also cause a significant drop in power. Cold solder joints in the game's harness, especially in areas like the transformer connections, interlock switch, or fuse block, may also produce the same results, although probably on a more permanent basis.

Sometimes location owners (especially in bars) replace light switches with dimmer rheostats, and the game is sometimes on the same line. Obviously, the voltage available to the game is going to drop dramatically when the dimmer is turned.

In any case, the way to check for correct line voltage is with your VOM. Set the VOM to 250 VAC and stick the probes in the wall receptacle. If it's OK here, check the transformer primary connections. If you do not get 117 VAC, examine the solder joints on the transformer, fuse block, and interlock switch. If you do get 117 VAC, the problem must be either in the transformer, harness connections, or in the PCB power supply.

If you suspect the transformer, check its secondaries with the VOM set to 50 VAC and correlate the readings with the legend on the side of the transformer. The transformer must also be correctly grounded, so check the ground potential as well, especially if there is a hum bar rolling up or down the TV screen.

## HARNESS PROBLEMS

Other harness problems include blowing fuses and malfunctioning controls. The repeating blown-fuse problem can sometimes be quite exasperating to solve, for short circuits have the tendency to occur in areas almost impossible to find. First, try inserting a new fuse, as old fuses age and blow without cause. If the new one also blows, you definitely have a short.

The best way to approach this problem is by turning the power off and disconnecting devices that may be causing the problem, such as the TV, transformer, and PCB. Disconnect the devices by pulling off their connectors, but do not allow them to touch. If necessary, insulate them with small pieces of electrical tape. Then, connect your VOM across the terminals of the fuse block (all electrical power shut off), and set it to one of the resistance scales. This will save blowing a fuse each time you want to check the circuit.

If the VOM reveals that disconnecting the devices removed the short, reconnect the devices one by one until the short returns. The last device connected is the one that is at fault. If the VOM reads a short even after the devices are disconnected, the fault must lie in the harness itself, and only patient exploration will reveal its location. First, carefully examine all the wiring, looking for terminals that may be touching, metal objects such as coins shorting connections or burned insulation. If necessary, use the VOM to check each suspected wire.

## MALFUNCTIONING CONTROLS

One of the most common problems here is a bad potentiometer. Typically, a bad pot will cause the image to jump as it reaches a certain point. The only cure for this one is to install a new pot.

If a feature that is operated by a switch (for example, joysticks, foot pedals, control panel buttons) does not operate at all, check the switch with a VOM or continuity tester to verify its operation. If the switch does not check out, replace it. If the switch is OK, you should suspect the input to the switch from the PCB. In this case, get out the harness and logic schematics and check to see what kind of input it is. In many cases, the input will be +5 VDC. If so, use the VOM to check its presence. Normally, the switch is used to pull a +5 VDC line LOW to GND or to pull a LOW line HIGH. If the PCB output is missing, check the wire length from the PCB. If you find the signal at the PCB trace, the wire length or connection is at fault. If not, begin exploring the PCB using the logic schematics.

# A Glossary of Microprocessor Terms

**MICROPROCESSOR** — one or several microcircuits that perform the function of a computer's CPU. Sections of the circuit have arithmetic and comparative functions that perform computations and executive instructions.

**CPU** — central-processing unit. A computing system's "brain", whose arithmetic, control and logic elements direct functions and perform computations. The microprocessor section of a microcomputer is on one chip or several chips.

**PROM** — programmable read-only memory. User permanently sets binary on-off bits in each cell by selectively fusing or not fusing electrical links. Non-erasable. Used for low-volume applications.

**EPROM** — erasable, programmable, read-only memory. Can be erased by ultraviolet light bath, then reprogrammed. Frequently used during design and

development to get programs debugged, then replaced by ROM for mass production.

**ROM** — read-only memory. The program, or binary on-off bit pattern, is set into ROM during manufacture, usually as part of the last metal layer put onto the chip. Nonerasable. Typical ROM's contain up to 16,000 bits of data to serve as the microprocessor's basic instructions.

**RAM** — random-access memory. Stores binary bits as electrical charges in transistor memory cells. Can be read or modified through the CPU. Stores input instructions and results. Erased when power is turned off.

**LSI** — large scale integration. Formation of hundreds or thousands of so-called gate circuits on semiconductor chips. Very large scale integration (VLS) involves microcircuits with the greatest component density.

**MOS** — metal-oxide semiconductor. A layered construction technique for integrated circuits that achieves high component densities. Variations in MOS chip structures create circuits with speed and low-power requirements, or other advantages (static will damage a MOS chip).

---

## Introduction to the Z-80 CPU

The term "microcomputer" has been used to describe virtually every type of small computing device designed within the last few years. This term has been applied to everything from simple "microprogrammed" controllers constructed out of TTL MSI up to low end minicomputers with a portion of the CPU constructed out of TTL LSI "bit slices." However, the major impact of the LSI technology within the last few years has been with MOS LSI. With this technology, it is possible to fabricate complete and very powerful computer systems with only a few MOS LSI components.

The Zilog Z-80 family of components can be configured with any type of standard semiconductor memory to generate computer systems with an extremely wide range of capabilities. For example, as few as two LSI circuits and three standard TTL MSI packages can be combined to form a simple controller. With additional memory and I/O devices a computer can be constructed with capabilities that only a minicomputer could previously deliver.

New products using the MOS LSI microcomputer are being developed at an extraordinary rate. The Zilog Z-80 component set has been designed to fit into this market through the following factors:

1. The Z-80 is fully software compatible with the popular 8080A CPU.
2. Existing designs can be easily converted to include the Z-80.
3. The Z-80 component set is at present superior in both software and hardware capabilities to any other microcomputer system on the market today.
4. For increased throughput the Z80A operating at a 4 MHz clock rate offers the user significant speed advantages.

Microcomputer systems are extremely simple to construct using Z-80 components. Any such system consists of three parts:

1. **CPU (Central Processing Unit)**
2. **Memory**
3. **Interface Circuits to peripheral devices**

The CPU is the heart of the system. Its function is to obtain instructions from the memory and perform the desired operations. The memory is used to contain instructions and in most cases data that is to be processed. For example, a typical instruction sequence may be to read data from a specific peripheral device, store it in a location in memory, check the parity and write it out to another peripheral device. Note that the Zilog component set includes the CPU and various general purpose I/O device controllers, while a wide range of memory devices may be used from any source. Thus, all required components can be connected together in a very simple manner with virtually no other external logic.

## General Purpose Registers

There are two matched sets of general purpose registers, each set containing six 8-bit registers that may be used individually as 8-bit registers or as 16-bit register pairs by the programmer. One set is called BC, DE and HL while the complementary set is called BC', DE' and HL'. At any one time the programmer can select either set of registers to work with through a single exchange command for the entire set. In systems where fast interrupt response is required, one set of general purpose registers and an accumulator/flag register may be reserved for handling this very fast routine. Only a simple exchange command need be executed to go between the routines. This greatly reduces interrupt service time by eliminating the requirement for saving and retrieving register contents in the external stack during interrupt or subroutine processing. These general purpose registers are used for a wide range of applications by the programmer. They also simplify programming, especially in ROM based systems where little external read/write memory is available.

## Arithmetic & Logic Unit (ALU)

The 8-bit arithmetic and logical instructions of the CPU are executed in the ALU. Internally the ALU communicates with the registers and the external

data bus on the internal data bus. The type of functions performed by the ALU include:


<b>Add</b>	Left or right shifts or rotates (arithmetic and logical)
<b>Subtract</b>	Increment
<b>Logical AND</b>	Decrement
<b>Logical OR</b>	Set bit
<b>Logical Exclusive OR</b>	Reset bit
<b>Compare</b>	Test bit

## Instruction Register and CPU Control

As each instruction is fetched from memory, it is placed in the instruction register and decoded. The control sections performs this function and then generates and supplies all of the control signals necessary to read or write data from or to the registers, control the ALU and provide all required external control signals.

## Z-80 CPU Pin Description

The Z-80 CPU is packaged in an industry standard 40 pin Dual In-Line Package. The I/O pins are shown in the below figure and the function of each is described.



**A<sub>0</sub>-A<sub>15</sub>****(Address Bus)**

Tri-state output, active high. A<sub>0</sub>-A<sub>15</sub> constitute a 16-bit address bus. The address bus provides the address for memory (up to 64K bytes) data exchanges and for I/O device data exchanges. I/O addressing uses the 8 lower address bits to allow the user to directly select up to 256 input or 256 output ports. A<sub>0</sub> is the least significant address bit. During refresh time, the lower 7 bits contain a valid refresh address.

**D<sub>0</sub>-D<sub>7</sub>****(Data Bus)**

Tri-state input/output, active high. D<sub>0</sub>-D<sub>7</sub> constitute an 8-bit bidirectional data bus. The data bus is used for data exchanges with memory and I/O devices.

**M<sub>1</sub>****(Machine Cycle one)**

Output, active low. M<sub>1</sub> indicates that the current machine cycle is the OP code fetch cycle of an instruction execution. Note that during execution of 2-byte op-codes, M<sub>1</sub> is generated as each op code byte is fetched. These two byte op-codes always begin with CBH, DDH, EDH or FDH. M<sub>1</sub> also occurs with IORQ to indicate an interrupt acknowledge cycle.

**MREQ****(Memory Request)**

Tri-state output, active low. The memory request signal indicates that the address bus holds a valid address for a memory read or memory write operation.

**IORQ****(Input/Output Request)**

Tri-state output, active low. The IORQ signal indicates that the lower half of the address bus holds a valid I/O address for a I/O read or write operation. An IORQ signal is also generated with an M<sub>1</sub> signal when an interrupt is being acknowledged to indicate that an interrupt response vector can be placed on the data bus. Interrupt Acknowledge operations occur during M<sub>1</sub> time while I/O operations never occur during M<sub>1</sub> time.

**RD****(Memory Read)**

Tri-state output, active low. RD indicates that the CPU wants to read data from memory or an I/O device. The addressed I/O device or memory should use this signal to gate data onto the CPU data bus.

**WR****(Memory Write)**

Tri-state output, active low. WR indicates that the CPU data bus holds valid data to be stored in the addressed memory or I/O device.

**RFSH****(Refresh)**

Output, active low. RFSH indicates that the lower 7 bits of the address bus contain a refresh address for dynamic memories and the current MREQ signal should be used to do a refresh read to all dynamic memories.

**HALT****(Halt state)**

Output, active low. HALT indicates that the CPU has executed a HALT software instruction and is awaiting either a non maskable or a maskable interrupt (with the mask enabled) before operation can resume. While halted, the CPU executes NOP's to maintain memory refresh activity.

**WAIT****(Wait)**

Input, active low. WAIT indicates to the Z-80 CPU that the addressed memory or I/O devices are not ready for a data transfer. The CPU continues to enter wait states for as long as this signal is active. This signal allows memory or I/O devices of any speed to be synchronized to the CPU.

**INT****(Interrupt Request)**

Input, active low. The Interrupt Request signal is generated by I/O devices. A request will be honored at the end of the current instruction if the internal software controlled interrupt enable flip-flop (IFF) is enabled and if the BUSRQ signal is not active. When the CPU accepts the interrupt, an acknowledge signal (IORQ during M<sub>1</sub> time) is sent out at the beginning of the next instruction cycle. The CPU can respond to an interrupt in three different modes that are described in detail in section 5.4 (CPU Control Instructions).

**NMI****(Non-Maskable Interrupt)**

Input, negative edge triggered. The non maskable interrupt request line has a higher priority than INT and is always recognized at the end of the current instruction, independent of the status of the interrupt enable flip-flop. NMI automatically forces the Z-80 CPU to restart to location 0066H. The program counter is automatically saved in the external stack so that the user can return to the program that was interrupted. Note that continuous WAIT cycles can prevent the current instruction from ending, and that a BUSRQ will override a NMI.

**RESET**

Input, active low. RESET forces the program counter to zero and initializes the CPU. The CPU initialization includes:

- 1) Disable the interrupt enable flip-flop



- 2) Set Register I = 00H
- 3) Set Register R = 00H
- 4) Set Interrupt Mode 0

During reset time, the address bus and data bus go to a high impedance state and all control output signals go to the inactive state.

**BUSRQ**  
**(Bus Request)**

Input, active low. The bus request signal is used to request the CPU address bus, data bus and tri-state output control signals to go to a high impedance state so that other devices can control these buses. When BUSRQ is activated, the CPU will set these

buses to a high impedance state as soon as the current CPU machine cycle is terminated.

**BUSAK**  
**(Bus Acknowledge)**

Output, active low. Bus acknowledge is used to indicate to the requesting device that the CPU address bus, data bus and tri-state control bus signals have been set to their high impedance state and the external device can now control these signals.

**CLK**  
**(Clock)**

Single phase TTL level clock which requires only a 330 ohm pull-up resistor to +5 volts to meet all clock requirements.

## MCR II SYSTEM P.C. BOARD JUMPER OPTIONS

VIDEO GENERATOR P.C. BOARD									
MANUFACTURER	EPROM NO.	JW#1	JW#2	JW#3	JW#4	JW#5	JW#6	JW#7	JW#8
MOTOROLA	68764	#	*	*	#	*	*	*	*
	68766	#	*	*	#	*	*	*	*
INTEL	2764	*	#	#	*	#	*	*	#
T. I.	2564	#	*	*	#	*	#	#	*
SUPER C.P.U. P.C. BOARD									
JUMPER OPTIONS FOR PROGRAM ROMS ONLY									
MANUFACTURER	EPROM NO.	JW#2	JW#4	JW#5	JW#6	JW#7	JW#18	JW#19	
MOTOROLA	68764	#	#	*	#	*	*	#	
	68766	#	#	*	#	*	*	#	
T. I.	2564	#	#	*	#	*	*	#	
INTEL	2764	*	*	#	*	#	#	*	
JUMPER OPTIONS FOR BACKGROUND ROMS ONLY									
MANUFACTURER	EPROM NO.	JW#10	JW#11	JW#12	JW#13	JW#14	JW#15	JW#16	JW#17
MOTOROLA	68764	*	#	*	#	*	#	#	*
	68766	*	#	*	#	*	#	#	*
T. I.	2564	*	#	*	#	*	#	#	*
INTEL	2764	#	*	#	*	#	*	*	#
SOUND I/O P. C. BOARD									
MANUFACTURER	EPROM NO.	JW#1	JW#2						
NUMEROUS MFR'S	2532	*	#						
NUMEROUS MFR'S	2732	#	*						

- \* = CUT JUMPER WIRES WHERE THIS SYMBOL "\*" APPEARS.  
 # = LEAVE JUMPER WIRES IN WHERE THIS SYMBOL "#" APPEARS.

The above table illustrates the fact that the Video Generator P.C. Board used in the MCR II System has 8 jumper wires, the SUPER C.P.U. P.C. Board used in the MCR II System has 19 jumper wires, and the Sound I/O P.C. Board used in the MCR II System has 2 jumper wires.

All of the above Boards can be used with a variety of different **SETS of EPROM chips**. However, these EPROMS are not all made by the same manufacturer

and do have some internal differences. So, in order to make them function properly in their respective P.C. Boards, certain jumper wires on these Boards have to be cut.

The above table tells you which jumpers to cut (depending on which EPROM set you're going to use) by showing a "\*" under that jumper wire's number. If there is **NO** "\*" under a jumper wire's number, **THAT PARTICULAR JUMPER WIRE IS NOT TO BE CUT.**

**PLEASE NOTE:**

THE INFORMATION CONTAINED IN THIS SECTION IS TOLD IN AN EASY TO UNDERSTAND MANNER AND IS INTENDED TO AID THOSE WITHOUT AN ELECTRONICS DEGREE IN TROUBLESHOOTING AND REPAIRING THEIR GAMES T.V. MONITOR.

IF YOU READ THROUGH THIS SECTION AND STILL HAVE QUESTIONS, PLEASE CONTACT YOUR DISTRIBUTOR OR MIDWAY MANUFACTURING COMPANY AT THE TOLL FREE NUMBER PROVIDED WITH YOUR GAMES PAPERS.

**OUR STAFF AND OUR DISTRIBUTORS STAND READY TO HELP YOU!**

**THANK YOU**

## **VI. T.V. Monitor Manual**

### **Introduction:** (How to use this section of your manual.)

This section has been designed to simply familiarize you with one of the more mystical components in your game — the T.V. monitor. If you are an electronics technician who is quite knowledgeable on the subject, you may decide to just go to the schematics and start troubleshooting the defective monitor. But if you are like most people, a monitor is a T.V. set, and that means a complex doo-dad that means big buck repairs. This isn't necessarily so. This section of the manual will acquaint you with the monitor and could just help you repair it if you feel adventurous enough to give it a try. If you have any knowledge of electronics, especially the use of a voltmeter, the repairs you can make are astonishing. Just keep in mind that **ELECTRICITY CAN BE VERY DANGEROUS, SO BE CAREFUL!!**

If you want to understand how a monitor works, just read the "THEORY OF OPERATION" subsection. If you wish, you can follow along with the schematics. The information is presented in a very basic manner but a more complete treatment of the subject can be found in the technical sections of bookstores.

If you want to attempt to repair your monitor, it would be a good idea to read this whole section beginning to end before starting. **Pay attention to all warnings**

**and take them seriously.** The more equipment you have the better, but a low cost Volt-Ohm-Milliameter can often do the trick. Here are the steps to take:

1. Find the symptom that matches the problems your monitor has in the "SYMPTOM — DIAGNOSIS" subsection. The diagnosis tells the circuit or area the problem may be in and possibly even the actual component causing it.
2. Once you have the circuit that is causing the trouble, read the "TROUBLESHOOTING" subsection to learn the procedure for finding the bad part.
3. Next, go to the schematic section and find the schematic that matches your monitor. It may be helpful to read the "DIFFERENCES BETWEEN MONITORS" subsection if you are unsure of which monitor you have. Use the schematic to see what parts are in the offending circuit.

That really is all there is to it. Just remember that there are some bizarre or rare symptoms not covered, or that a monitor may have two or more different problems that only a genius, the experienced, or an experienced genius can figure out. But be patient, follow safety precautions, and remember that there is also literature available from the monitor companies through your distributor or from Bally Midway Manufacturing Company on request. (There is a toll free number on the back side of the front cover of this manual.)

# Symptom Diagnosis

## 1. Insufficient width or height:

- A. Horizontal line (due to VERTICAL CIRCUIT DEFECT).
  - Bad yoke.
  - Bad vertical output section.
  - Open fusible resistor in vertical section.
  - Bad height control.
  - Bad flyback.
- B. Vertical line (due to HORIZONTAL CIRCUIT DEFECT).
  - Bad yoke.
  - Open width coil.
  - Open part in horizontal output section.

## 2. Picture spread out too far or crushed in certain areas:

- A. Horizontal or vertical output transistor.
- B. Bad Component in output circuitry.
- C. Vertical linearity or damper control needs adjustment.

## 3. Line too close with black spacing:

- A. Problem in vertical section causing poor linearity.

## 4. Poor focus and convergence:

- A. Bad high voltage transformer ("flyback") or control.
- B. Focus voltage wire not connected to neck-board terminal.

## 5. Colors missing; check:

- A. Interface color transistors.
- B. Color output transistors.
- C. Cracked printed circuit board (neck Board).
- D. Color circuits.
- E. Video input jack.
- F. Defective picture tube.

## 6. Picture not bright enough:

- A. Weak emission from picture tube.

## 7. Silvery effect in white areas; check:

- A. Beam current transistors.
- B. Weak picture tube emission.

## 8. Too much brightness with retrace lines; check:

- A. Beam limiter transistors.
- B. Brightness and/or color blanking control set too high.

## 9. Increasing brightness causes an increase in size and poor focus.

- A. Weak high voltage rectifier or regulation (high voltage unit).
- B. Bad component in monitor's power supply.

## 10. Small picture and/or poor focus:

- A. Low B+ voltage (power supply trouble).

## 11. Vertical rolling:

- A. Vertical oscillator in the IC, vertical sync transistor, or circuit.
- B. No sync from logic board.
- C. Three pin sync. jack is loose or plugged in wrong.

## 12. Horizontal line across center:

- A. Vertical output circuit is dead (see symptom No. 1. A.).
- B. Vertical oscillator is not putting out the right wave form.

## 13. Picture bends:

- A. Horizontal sync needs adjusting.
- B. Magnetic or electromagnetic interference.

## 14. Flashing picture, visible retrace lines:

- A. Broken neck board.
- B. Internal short circuit in the picture tube (arcing).

## 15. Unsymmetrical picture or sides of picture:

- A. Defective yoke.

## 16. No brightness, power supply operating — No high voltage for the picture tube; check:

- A. Horizontal oscillator.
- B. Horizontal amplifier and output.
- C. Flyback transformer (high voltage unit).

## 17. No brightness, high voltage present; check:

- A. Heater voltage to the tube at the neck board.
- B. Screen-grid voltage for the tube.
- C. Focus voltage.
- D. Grid to cathode picture tube bias.

## 18. No high voltage; check:

- A. For AC input to the "flyback".
- B. Horizontal deflection stages.
- C. Flyback transformer.
- D. Yoke.
- E. Power supply.

## 19. No horizontal and vertical hold; check:

- A. Sync transistors and circuit.
- B. Wires and jack from logic board to the monitor.

## 20. Wavy picture — (power supply defect); check:

- A. Transistors, diodes, electrolytic capacitors in the power supply.

**21. Moving bars in picture:**

- A. Ground connector off between monitor and logic boards.
- B. Defect in the power supply (see wavy picture symptom).

**22. Washed out picture (see picture not bright enough):**

- A. Check video signal at the cathode pins with an oscilloscope. If there is about 80 volts peak to peak, the picture tube has weak emission.

**23. Monitor won't turn on:**

- A. Problem in the power supply: Check fuse, transistors, open fusible resistor.
- B. Shorted horizontal output transistor.

- C. Defective high voltage disabling circuit.
- D. Crack(s) somewhere on main chassis board.


**24. Can't adjust purity or convergence:**

- A. Use a degausser to demagnetize the picture tube carefully following your degausser's instructions.
- B. Picture tube defective.
- C. Nearby equipment is electromagnetically interfering.
- D. The poles of the earth are pulling off the purity — see "A" above.
- E. Poor focus or width of picture.
- F. Make sure you have the correct CRT number for that brand of monitor.


---

---

## Guide To Schematic Symbols



**THERMISTOR**  
(POLARITY DOESN'T MATTER)




**IRON CORE TRANSFORMER**  
(SUCH AS A FLYBACK)




**INDUCTOR, COIL, CHOKE**  
(POLARITY DOESN'T MATTER)




**FUSE**  
(POLARITY DOESN'T MATTER)




**ZENER DIODE**



**DIODE**



**NPN TRANSISTOR**




**PNP TRANSISTOR**




**VARIABLE RESISTOR, POT, CONTROL**  
(POLARITY DOESN'T MATTER)




**RESISTOR**  
(POLARITY DOESN'T MATTER)




**LINES ARE CONNECTED**



**ELECTROLYTIC CAPACITOR**



**LINES ARE NOT CONNECTED**



**CAPACITOR**  
(POLARITY DOESN'T MATTER)



**GROUND**

# Troubleshooting

Troubleshooting monitors requires experience, patience, **and luck**. The first step is to match the symptom the monitor displays to the diagnosis next to it in the "SYMPTOM-DIAGNOSIS" subsection. This will pinpoint the circuit the problem is probably in, and often the parts to check. Next, the circuit should be visually inspected to see if there are any parts broken, burned, or if something is there that shouldn't be, like a loose screw, etc. Some parts go bad before others and should be checked first. In fact, following is the general order in which parts usually go bad:

1. Semiconductors (like transistors, diodes, and integrated circuits).
2. Fusible resistors.
3. Electrolytic capacitors.
4. Resistors.
5. Capacitors and coils.

Always remember that a monitor can bite like a snake. Even when it is turned off, capacitors hold voltage and will discharge it to you should you be touching chassis ground. The picture tube or CRT, itself, is a giant capacitor, so avoid the flyback anode plug hole. With the monitor on, the power supply circuit and/or the flyback, which puts out at least 23,000 volts, **CAN BE KILLERS!!** Avoid handling power transistors (usually output transistors) or ICs, yoke terminals, and other high power components when the monitor is on.

## **WARNING: That picture tube is a bomb!**

When it breaks, first it implodes, then it explodes. Large pieces of glass have been known to fly in excess of 20 feet in all directions. **DO NOT** carry it by the long, thin neck. Discharge its voltage to ground by shorting the anode hole to ground. Use a plastic handled screwdriver, connect one end of a wire with an alligator clip at each end to chassis ground and the other end to the metal shaft of the screwdriver. Using **ONE HAND ONLY** (put the other in your pocket) and touching **ONLY** the plastic handle of the screwdriver (**DO NOT TOUCH THE METAL SHAFT**) stick the blade of the screwdriver into the anode hole.

**IMPORTANT!** The side brackets of the monitor are chassis ground as is the aquadag, the picture tube's dark conductive coating. **BUT**, on the **ZENITH MONITOR** there are metallic mounting parts which **ARE NOT** chassis ground. Discharging the CRT to these will damage the monitor!

Be prepared for a fairly loud pop and a flash. The longer the monitor has been turned off, the smaller the pop and dimmer the flash. But **BE CAREFUL**, picture tubes will hold a very healthy charge for at least a **week** if not longer. Even after you've discharged it once, it may still carry a residual charge. It's better to be too careful than dead, which is why electronic equipment always carries stickers referring servicing to qualified personnel. Handle the side with the viewing screen against your chest when changing it. **ALWAYS** wear safety goggles when handling the picture tube.

To maintain the safety and performance of the monitor, always use exact replacement parts. For instance, the wrong components in the power supply can cause a fire, or the wrong color transistor may give a funny color to the picture. Service your monitor on a nonconductive firm table like wood, **NOT METAL**, and take off all of your jewelry just in case. With all this in mind, you are ready to begin troubleshooting.

Observe the picture carefully. Try to vary the appropriate control that would most likely affect your particular symptom. For example, if there is poor brightness or no picture, try turning up the brightness or contrast control. If the controls have no effect at all, chances are there is trouble with the control itself, the circuit it controls, or a nearby circuit that may be upsetting voltages. Go to the list of symptoms and determine with the schematic where the bad circuit is.

### **CAUTION:**

**Keep in mind that capacitors hold a charge as can the picture tube (for at least a week and usually longer), and could shock you.**

First, check for obvious visual defects such as broken or frayed wires, solder where it is not supposed to be, missing components, burned components, or cracked printed circuit boards. If everything looks good up to this point, make sure that diodes, electrolytic capacitors, and transistors have their leads connected in the right polarity as shown on the schematic and the circuit board.

Turn on the power and measure the voltages at the leads of the active devices such as tubes, transistors, or integrated circuits. Any voltage that does not come within at least 10% to 15% of the voltage specified on the schematic indicates either a problem with that device or a component connected with it in the circuit. The next step is to use the ohmmeter to narrow down the field of possible offenders.

To test a transistor, one lead of the ohmmeter is placed on the base; and the other lead placed just on the emitter, then on the collector. A normal transistor will read either high resistance (infinite), or little resistance (400 to 900 ohms), depending on the polarity of this type transistor. Then the leads should be switched, one remaining on the base, and the other switched from the emitter to the collector. Now the opposite condition should result: the resistance should be infinite if it was lower when the other lead was on the base. Consistently infinite readings indicate an open, and a short is demonstrated by 0-30 ohms on most of these test readings. Finally, place one lead on the collector, then the other on the emitter. No matter which lead is used, there should be infinite resistance. Any lower reading, such as 50 ohms (which is typical on a bad transistor), indicates a short.

This all sounds pretty confusing, but a little experience on a good transistor will make you an expert in no time. Usually, the lowest ohmmeter setting is used for testing transistors. Once in a great while a transistor may check out good on this test, but may actually be "leaky" or break down only on higher voltages. If in doubt, change it. It is also wise to check the transistor out of the circuit just in case some component in the circuit is affecting the ohmmeter reading.

A diode is tested like a transistor except it only has two leads. Again, there should be high resistance one

way and little resistance the other. If it tests bad, take one lead out of the circuit in case some component is messing up the ohmmeter reading.

**NOTE: DO NOT** leave soldering equipment on the leads too long since all semiconductors, especially integrated circuits, are easily destroyed by heat.

Without special equipment, integrated circuits are checked by verifying the proper DC voltage on the pins and the correct AC wave form using an oscilloscope. **BE CAREFUL:** Shorting their pins can easily destroy them.

Resistors are checked with an ohmmeter and should usually be within ten percent of the value stated on them and on the schematic. You may have to desolder one lead from the printed circuit board. If you wreck the foil on the board, carefully solder a small wire over the break to reconnect the conductive foil.

Capacitors are tricky. Their resistance goes up when checked with an ohmmeter which shows a charging action. As they suck up current from the meter, the voltage goes up and so does the resistance. If you are sure a particular circuit is giving you a problem and everything else checks out O.K., Electrolytic capacitors are prime suspects. Substitute a new one and keep your fingers crossed.

---

## Theory of Operation

To understand what goes on inside the monitor, large general groups of circuits will be examined instead of laboriously analyzing the branches and small circuits that make up these groups. This will help avoid confusion and aid in a basic, concrete, knowledge of what makes up a monitor.

### THE POWER SUPPLY —

The AC going to the monitor from the game transformer is just like the voltage and current from your wall outlet. It jumps up and down going positive and negative sixty times a second. But a monitor needs nice, smooth DC; direct current, not alternating. So diodes chop up the AC and a big electrolytic capacitor filters it out to make it even smoother. Since the monitor is a big piece of electronic equipment, with many circuits demanding a lot of power from the power supply, there are also zener diodes and transistors to help maintain a nice, constant, smooth voltage so that the monitor circuits don't jump around. And this is what happens when you see a wavy picture. There is AC creeping

through the power supply, so it must be malfunctioning. If the voltage from the power supply is too low, the other circuits will be starved for power and you may see a small, wavy picture, or none at all.

Some circuits receive voltages that are higher than what the power supply should put out. But they come from the flyback transformer which will be discussed later.

### THE INTERFACE SECTION OF THE CHASSIS —

The interface section of the chassis is fairly easy to identify. It is right by the place where the video jack(s) from the logic board(s) plug into. There are sets of transistors that receive the separate red, green, blue, and sync information from the cables that come from the logic boards. The circuits jack up the voltage and match impedances, or in other words, prepare the logic board outputs for the circuits that will really amplify them for the output devices such as the yoke in the case of the sync, or the picture tube that shows the colors.



An interesting aside is that our sync is composite negative sync. That means two things:

1. The sync is a negative going wave form.
2. There are two pulses going at different speeds over the same wire:
  - a. Vertical wave forms at 60 times per second (or Hertz) and
  - b. Horizontal wave forms at about 15,750 times per second (Hz).

The sync is amplified by a sync amplifier transistor and sent on its way to the oscillators. The sync or timing information will be explained along with the oscillator shortly.

The color information is sent via wires to the neck board where the main amplification occurs. This will also be discussed later.

## **VERTICAL AND HORIZONTAL DEFLECTION—**

After the sync signal is amplified by the sync amp, it goes to two different sections, the vertical and horizontal circuits. Basically, the sync signals are for timing so the picture doesn't mess up since it is assembled like an orderly jigsaw puzzle, but so fast that you can't see the electron beams for each color painting the picture on the screen. This will all become clear soon. For now, we will follow the 60 cycle component of the sync as it goes on its journey to the deflection yoke.

The 60 cycle pulse goes to the vertical oscillator to make sure this circuit goes back and forth (or oscillates) at 60 times a second. Without this pulse keeping the circuit at the correct speed, it may get lazy and oscillate at 58 cycles or lower, or get ambitious and oscillate at 62 cycles or higher. At the wrong speed, the picture will start to roll up or down.

A Wells Gardner 13" (K4806) or 19" (K4906, K4956) color monitor uses an integrated circuit for its sync section. An Electrohome 13" or 19" color monitor uses an integrated circuit IC501 for its sync section. The Zenith monitor (CD19MXRF06) also uses an IC for the sync processing. Wells Gardner uses HA11423, Electrohome uses HA11244, and Zenith uses 221-175 (their part number). **These ARE NOT interchangeable!** The idea is all the same. The output to the vertical amplifying transistors for all monitors must form a sawtooth wave form, sort of like a bunch of pyramids, racing through the yoke's vertical coils at 60 times a second.

Along the way to the output transistors, the 60 cycle pulse is shaped and amplified to do the job: the yoke magnetically pushes the electron beam to fill the screen out sideways looking at the screen with the greatest length going up and down. Or viewing the screen sitting like a home television set, the amplified vertical output fills the screen up and down. Watching a monitor like this, seeing only a horizontal line means a problem with the vertical coils of the yoke or

anything from the vertical output section on back to the oscillator.

The horizontal section is very similar with a few exceptions. The horizontal wave shape is more like a square and has a frequency of 15,750 cycles a second. Both Wells Gardner and Electrohome use the other side of their respective integrated circuits for the horizontal circuitry. If the oscillator isn't going at the correct speed, the picture may move sideways, start to slant, or tear up with slanted thin figures. With both the vertical and horizontal of all monitors, there are variable resistors that change the speed of the oscillators up and down. This way you have controls that can make the correct frequencies to keep the electronic jigsaw puzzle nicely locked in place. If you're driving in a car and next to you someone else is driving their car at exactly the same speed, it will appear that they are not moving. And this is why the sync frequency and the oscillator's frequency must match, so the picture doesn't appear to move.

The correct wave form is shaped and amplified in the circuitry just like in the vertical section. But the horizontal output transistor is a large power transistor and not only serves to give current to the horizontal yoke windings, it also feeds the flyback transformer.

## **THE FLYBACK TRANSFORMER (OR HIGH VOLTAGE UNIT) —**

The picture tube needs high voltage to light up, and the power supply can't meet this demand. The flyback transformer receives current alternating at about 15,750 times per second from the horizontal output transistor. The "flyback" jacks up its input voltage and puts out a higher voltage alternating at the same speed. But, in your "flyback" there are diodes that chop up the alternating voltage to make it a smooth DC output just like in the power supply. This is what goes through that thick red wire to your picture tube. **THIS AREA HAS ABOUT 24,000 VOLTS ON IT AND IT CAN KILL YOU!!**

The "flyback" may be dangerous, but it is also generous. It has extra output windings which give voltage to the heater pins of the picture tube, voltage for the vertical deflection circuits, and picture tube screen-grid voltage. So in a way, the high voltage "flyback" is like a second power supply.

## **COLOR CIRCUITS —**

The color circuits are pretty straight forward. The signals go into the interface section where some amplification and impedance matching occurs. These circuits are pretty sparse and simple. Each color just has two transistors and a diode with some resistors and capacitors. From here, the AC color signal is sent by wires to the neck board.

The color output circuits are on the neck board. The color signals going to the transistors are controlled by two variable resistors called drive controls. There are only two, one for the red and one for the green on

Wells Gardner and Electrohome monitors. Zenith monitors have all three: red, blue and green.

The Wells Gardner and Electrohome monitor have another variable resistor in their emitter part of their color output transistors. These "cutoff controls" vary the amount of A.C. signal that the transistor amplifies and sends to the cathodes of the picture tube. The Zenith monitor has its cutoff controls in the interface section to vary the amount of signal going to the output transistors. The more signal, the more color.

If you think this is confusing, here is another little hitch. The Electrohome and Zenith monitors both have the actual A.C. picture information signal going through the emitters of the color output transistors. The Wells Gardner has the A.C. signal going to the base of the transistors. The blanking and beam limiting signals which come from the blanking and beam limiting transistors in the interface section go into the color output transistor base in the Electrohome and Zenith monitors, but enters into the emitter of the Wells Gardner monitor's color output transistor. Should you feel adventurous enough to look at this signal on an oscilloscope, it should look like a square.

The beam limiter helps control the brightness level, and the blanking transistor rapidly turns the picture tube on and off so that retrace lines don't show up on the screen. By turning up the brightness on a good monitor, these four to six retrace lines can be seen slanting diagonally across the picture.

### PROTECTION CIRCUIT —

To protect the high voltage section against voltages that are too high coming from the power supply which could cause X-rays to be emitted from the "flyback", a circuit senses the higher power supply voltage and turns off the horizontal oscillator. Since the horizontal oscillator doesn't work, the horizontal output transistor has nothing to feed the "flyback" which in turn has nothing to feed the picture tube. The monitor will be silent, have no picture, and will appear to be off. **But don't be fooled.** There is still that excessive amount of voltage coming from the power supply. To find out, check at pin two of Wells Gardner's IC501 and emitter of X04 for the Electrohome monitor. Check the 95 volt test point (located near the "flyback") for the Zenith monitor. The Wells Gardner monitor doesn't use this circuit, but an open in the horizontal section could cause the monitor to appear off, yet still have power supply voltage flying around. Here are the voltages you should receive:

Wells Gardner	=	130VDC
Electrohome	=	120VDC
Zenith	=	95VDC

The best place to measure this voltage on an Electrohome monitor is at a pin marked B1 on the chassis. This is because a 13 inch color Electrohome monitor, The G07-FB0 or G07-902, has an integrated circuit and very little else in the power supply. Still, there should be 120VDC at B1.

## THE PICTURE TUBE (OR CRT) —

**ATTENTION!** For information on picture tube replacement types, go to the last section, "PICTURE TUBE INTERCHANGEABILITY".

The picture tube or CRT is an output device. In other words, the end result of the circuit's work is displayed by this part. Actually, the output of other circuits is in the neck of the picture tube.

First, there is the heater. The heater boils off electrons from the cathodes so that they (the electrons) shoot up to the screen to excite the phosphors so that the three phosphors emit three colors of light.

The cathodes are next, and again they emit electrons to turn on the tube phosphors, making it glow. A defective cathode may cause the particular color it handles to be missing.

Next come the grids. The first grid is grounded. The following grid is the screen grid which receives about 300VDC depending on the brightness setting. The next grid closest to the picture tube screen is the focus grid which gets about one fifth the amount of voltage that is applied to the picture tube anode.

After jetting from the cathode through all these grids, the electrons speed through a mask, a sheet of material with tiny holes, and then excite the tiny dots of phosphor in the inside surface of the picture tube screen. The green electron gun (or cathode and circuitry) spits out electrons which head for the green phosphors only. The same goes for the red and blue guns. The way the phosphor light blends determines the color seen. Should these electron beams become too intense, they may burn the phosphor. With the monitor off, this can be seen as a dark permanent image of the video information on the tube screen.

---

---

## Differences Between Monitors

The easiest way to identify the brand of monitor you are working with is to find the manufacturer's name or model number printed on the chassis or chassis base. But what if the monitor was in a Texas dust storm or buried in volcanic ash and this information is no longer there? Fear not! Each monitor has its own peculiarities and the following should help to identify them:

The **ELECTROHOME** G07-904 (19") and G07-902 (13") have their horizontal and vertical processing IC hidden under a silver can. A shiny metal top behind the "VERTICAL HEIGHT" and "HORIZONTAL FREQUENCY" control prove this is an Electrohome monitor.

The **WELLS GARDNER** K4906 (19") and K4806 (13") have their horizontal and vertical processing IC out in the open directly behind the "VERTICAL HOLD" control.

The **ZENITH** C019MXRF06 (19") monitor has its horizontal and vertical processing IC way in back by the picture tube. The monitor also has large white cables going from the main board to the neck board.

**K4906 (1st TYPE)** — This monitor's identifying tags have **BLACK** ink printed on a white background. There is **NO** Vertical Damping Control. (This Control would be next to the Vertical Hold Control but this area is jumpered with a small wire instead.

**K4906 (2nd TYPE)** — This monitor's identifying tags have **RED** ink printed on a white background. There **IS** a Vertical Damping Control next to the Vertical Hold Control. The Damping Control provides a few more lines on the top of the monitor screen (monitor viewed as a normal T.V. would be) for any video game that may need these lines to fit the picture on the screen. Moving the Control may distort the top part of your picture (or the side, depending on the game and how the monitor is mounted) so go ahead and move it if you are having this type of problem. To accommodate this new feature, there are a few circuit changes.

ONE MAJOR DIFFERENCE BETWEEN THESE TWO VERSIONS OF THE K4906 IS THE YOKE. They look the same but notice the part numbers:

K4906 **WITHOUT** the Damper Control: 2021111201

K4906 **WITH** the Damper Control: 2021111258

Since the companies like to change part numbers at the drop of a hat, the best thing to do is to request whatever part number is written on your yoke. If you should get the wrong yoke, the results will be:

Picture distortion.

Excessive brightness.

Too much or too little vertical picture size.

## CONTROLS YOU MAY NOT TOUCH

Basically, on the Electrohome monitor, you can move any control you want **EXCEPT** for the B1 control. This sets the power supply voltage (ideally at 120 VDC) and is located right behind VERTICAL HOLD. The 13" Electrohome **DOES NOT** have this control. It may also be wise not to move the VERTICAL LINEARITY since this distorts the picture and is hard to reset perfectly. If you do move it, turn on the Cross Hatch Test Pattern of your game and try to get the squares to the point where they are equal in size by readjusting this Linearity Control.

On the Wells Gardner monitor, brightness is adjusted by the "BLACK LEVEL" Control which is right next to the Horizontal Frequency Control. Under the Focus Control is the "SCREEN" Control which you **DO NOT** touch. Yes, this control does adjust the brightness,

but it is used to set the CRT bias and is adjusted at the factory. When Wells Gardner sets it, they mark the position with a black mark on the knob. If you move it, be sure to realign the mark and **THEN** set the **BLACK LEVEL** Control to the brightness you desire. So, other than the **SCREEN** control, you may adjust any of the controls.

The Zenith monitor has a 95 volt adjustment control. It is green and located behind the jack labeled 3D3. To discourage you from moving it, Zenith has placed a little glue on top of this control.

---

# Parts Interchangeability

Some parts can be interchanged on all of the monitors. Here are the rules:

1. You **CAN** swap any resistor between monitors that has the same resistance, wattage rating, and tolerance.
2. You **CAN** swap any capacitor between monitors that has the same capacitance and voltage rating.
3. You **CAN** swap many of the parts between the 19" and the 13" versions of each manufacturer's monitor. **BUT**, be certain to compare the manufacturers' part numbers to be positive the parts you want to interchange are identical. **BE SURE** you have read the section **DIFFERENCES BETWEEN MONITORS** which was covered earlier.
4. You **MAY BE ABLE** to swap picture tubes between monitors. In the past you could swap any picture tube, but due to rampant engineering changes and new monitor models being introduced, you would need a computer to keep track of what could be swapped. For more information on this subject, go to "PICTURE TUBE INTERCHANGEABILITY".
5. You **CANNOT** change any part that is a **safety part**, one that is shaded in gray on the schematic; it **MUST** be **IDENTICAL** to the original. **To do otherwise IS DANGEROUS.** For instance, the 13 inch Electrohome (G07-902) monitor "flyback" looks identical to the 19 inch Electrohome (G07-904) monitor "flyback". In fact, there is even a 19 inch Electrohome (G07-905) monitor (which is an obsolete model) with a similar looking "flyback". **NONE OF THESE ARE INTERCHANGEABLE!!**
6. You **CAN** change any of the parts between the G07-904 and G07-907. They're essentially the same monitor except that the G07-907 has a vertically mounted picture tube.

If there is any doubt about what parts can be swapped between each manufacturer's 19 inch and 13 inch models, compare the manufacturer's part number between each one. If they match up, they are the same part.

---

# Picture Tube Interchangeability

## 13" MONITORS

There are currently two 13" monitors being used: the Wells Gardner K4806 and the Electrohome G07-902. The picture tubes used are NOT interchangeable. The pins on the neck of the CRT will not fit in the socket should you use the wrong CRT.

Here is a chart for all the 13" color monitors Bally Midway uses.

ELECTROHOME	G07-902	—	370ESB22
WELLS GARDNER	K4806	—	370KSB22

The factory recommended CRT type could change in the future for one reason or another, but the listed picture tubes will work. As a matter of fact, you can call another picture tube company to see if they have a replacement number to recommend...but caveat emptor — let the buyer beware.

## 19" MONITORS

Here it gets a little tricky. All of the picture tubes will fit no matter which is used. But if you use the wrong one, you will have problems with purity and/or dynamic convergence.

Purity trouble means that the color won't be true. If you turn up the color control for one color, instead of seeing that solid color it will show blotches or blobs of other colors on the screen.

Trouble with dynamic convergence means that there will be color fringing around solid lines at the edges of the screen.

The only way to ensure that you avoid these problems is to get the right picture tube or the right substitute.

Here is a list of the 19" monitors and the **CORRECT** CRT numbers.

**ALL ELECTROHOME G07-904 —**  
19VMNP22 RCA  
19VMJP22 RAULAND  
510UJB22 HITACHI

**WELLS GARDNER K4906 —**  
19VLTP22 RCA  
19VMLP22 ZENITH  
19VMKP22 PHILLIPS

**ZENITH CD19MXRF06 —**  
19VMLP22 ZENITH  
19VLTP22 RCA  
19VMKP22 PHILLIPS

**Notes**

**Monitor  
Schematics**

# 19" COLOR MONITOR SCHEMATIC DIAGRAM

## MODELS 19K4901, 19K4906, 19K4951, 19K4956

Power Supply Voltage and Symbols

Symbol	Voltage	Operating Circuit
	15V	Vert. Osc. Sync Blanking CRT Cut-Off
	130V	Horiz. Osc. Horz. Drive Horz. Output Vert. Output
	175V	Video Output



### SERVICE TECHNICIAN WARNING X-RAY RADIATION PRECAUTION:

THIS PRODUCT CONTAINS CRITICAL ELECTRICAL AND MECHANICAL PARTS ESSENTIAL FOR X-RAY RADIATION PROTECTION.  
FOR REPLACEMENT PURPOSES, USE ONLY TYPE PARTS SHOWN IN THE PARTS LIST.





**CAUTION: FOR CONTINUED SAFETY, REPLACE SAFETY CRITICAL COMPONENTS ONLY WITH MANUFACTURER'S RECOMMENDED PARTS.**  
**AVERTISSEMENT: POUR MAINTENIR LE DEGRE DE SECURITE DE L'APPAREIL NE REMPLACER LES COMPOSANTS DONT LE FONCTIONNEMENT EST CRITIQUE POUR LA SECURITE QUE PAR DES PIECES RECOMMANDEES PAR LE FABRICANT.**

### OSCILLOSCOPE WAVEFORM PATTERN


The waveforms shown are as observed on the wide band oscilloscope with the monitor turned to a reasonably strong signal and a normal picture. The voltages shown on each waveform are the approximate peak amplitudes.

If the waveforms are observed on the oscilloscope with a poor high frequency response, the corner of the pulses will tend to be more rounded than those shown and the amplitude of any high frequency pulse will tend to be less.



★ K4901D, K4906D, K4951D 5833  
K4956B





**Schematic Notes**  
 Unless otherwise specified  
 Resistance: (Ω) (K→KΩ, M→MΩ), 1/4 (W) carbon resistor  
 Capacitance: 1 or higher → (pF), less than 1 → (μF)  
 working voltage → 50 (V)  
 ceramic capacitor  
 Inductance: (μH)  
 Electrolytic Cap: Capacitance Value (μF)/working voltage (V),  
 NP → non-polar (or bipolar) electrolytic cap.  
 Refer to the parts list for additional component information.

⊙ indicates test point connection  
 ⚡ indicates chassis ground unless otherwise specified  
 Hz indicates cycles per second


For **safety** purposes (and continuing reliability)  
 ⚠ replace all components marked with safety symbol with identical type.  
 NOTE: FR → fusible resistor

00-4147-04  
 G07-CB0

Parts identification on circuit boards:  
 e.g. SU1126A (R107 = R1107)  
 SU3030A (R113 = R3113)







**Schematic Notes**

Unless otherwise specified  
 Resistance: (Ω) (K→KΩ, M→MΩ), 1/4 (W) carbon resistor  
 Capacitance: 1 or higher → (pF), less than 1 → (μF)  
 working voltage → 50 (V)  
 ceramic capacitor  
 Inductance: (μH)  
 Electrolytic Cap: Capacitance Value (μF)/working voltage (V),  
 NP → non-polar (or bipolar) electrolytic cap.  
 Refer to the parts list for additional component information.

⊕ indicates test point connection  
 ⏏ indicates chassis ground unless otherwise specified  
 Hz indicates cycles per second  
 For **safety** purposes (and continuing reliability)  
 ⚠ replace all components marked with safety symbol with identical type.  
 NOTE: FR → fusible resistor (—⏏—)

G07-FBO  
 00-4147-03

Parts identification on circuit boards:  
 e.g. SU1126A (R107 = R1107)  
 SU3030A (R113 = R3113)

## REPLACEMENT PARTS LIST—ELECTROHOME 13" MONITOR

Components identified by the  $\Delta$  symbol in the PARTS LIST and on the Schematic have special characteristics important to safety.

DO NOT degrade the safety of the set through improper servicing.

### Abbreviations for Resistors and Capacitors

Resistor		Capacitor	
C R	: Carbon Resistor	C Cap.	: Ceramic Capacitor
Comp. R	: Composition Resistor	M Cap.	: Mylar Capacitor
OM R	: Oxide Metal Film Resistor	E Cap.	: Electrolytic Capacitor
V R	: Variable Resistor	BP E Cap.	: Bi-Polar (or Non-Polar) Electrolytic Capacitor
MF R	: Metal Film Resistor	MM Cap.	: Metalized Mylar Capacitor
CMF R	: Coating Metal Film Resistor	PP Cap.	: Polypropylene Capacitor
UNF R	: Nonflammable Resistor	MPP Cap.	: Metalized PP Capacitor
F R	: Fusible Resistor	PS Cap.	: Polystyrol Capacitor
		Tan. Cap.	: Tantal Capacitor

NOTE: When ordering replacement parts please specify the part number as shown in this list including part name, and model number. Complete information will help expedite the order.

Use of substitute replacement parts which do not have the same safety characteristics as specified, may create shock, fire or other hazards. For maximum reliability and performance, all parts should be replaced by those having identical specifications.

### SERVICE REPLACEMENT PARTS LIST

Symbol	Description	Part Number
	Main P.C.B. Ass'y	SU-1103A
	CRT Socket P.C.B. Ass'y	SU-3016A
Outside of the P.C.B. Ass'y		
Symbol	Description	Part Number
$\Delta$ V01	$\Delta$ Picture Tube 13"	370ESB22(E)
$\Delta$ DY01	$\Delta$ Deflection Yoke	C29123-V
	PC Magnet	A76366-A
	Wedge	C30006
	$\Delta$ Flyback Transf.	A19183-A
$\Delta$ R11	$\Delta$ Focus V R	A46606-A
$\Delta$ R05	UNF Resistor 220 $\Omega$ ,25W. K	QRF258K-221
$\Delta$ C04	$\Delta$ C Capacitor 150pF, A C1.5KV	QCZO101-005
X01	Si. Transistor	2SD869
IC01	IC Regulator	STR383
L01	Degaussing Coil	21-1007-31
	Degaussing Coil Pin Terminal (2)	34-708-01
	Degaussing Coil Pin Terminal Housing	34-709-01
	Groundstrap Ass'y	34-697-04
	Groundstrap Wire Terminal	34-228-03
	Groundstrap Spring (2)	35-3560-01
BR	Support Bracket RH	35-3919-01
BR	Support Bracket LH	35-3919-02
SC	SCREW 10- $\frac{1}{2}$ Pix Tube Mtg. (4)	31-631018-08
WA	Pyramidal Lockwasher (4)	33-255-01
	Clip P.C.B. Support (2)	33-629-02
	Ground Lug	34-33-04
CH	Chassis Base	38-452-01

### Main P.C.B. Ass'y (SU-1103A) Parts List

Symbol	Description	Part Number
R1406	V R 200 $\Omega$	QVZ3230-022
R1408	V R 200 $\Omega$	QVZ3230-022
R1410	CMF R 6.8 $\Omega$ 1W J	QRX019J-6R8
R1414	OM R 3.3K $\Omega$ 1W J	QRG019J-332
R1415	OM R 2.7K $\Omega$ 1W J	QRG019J-272
R1421	OM R 12K $\Omega$ 2W J	QRG029J-123
R1422	V R 10K $\Omega$	QVZ3224-014H
$\Delta$ FR1401	$\Delta$ F R 68 $\Omega$ 2W K	QRH024K-680M
$\Delta$ R1503	$\Delta$ CMF R 11.8 $\Omega$ $\frac{1}{2}$ W +1%	QRV142F-1182
R1504	V R 5K $\Omega$	QVZ3230-053
R1509	OM R 10K $\Omega$ 2W J	QRG029J-103
R1511	OM R 5.6K $\Omega$ 2W J	QRG029J-562
R1514	OM R 680 $\Omega$ 2W J	QRG029J-681
R1515	CMF R 8.2 $\Omega$ 1W J	QRX019J-8R2
R1522	CMF R 4.7 $\Omega$ 1W J	QRX019J-4R7
R1523	OM R 56 $\Omega$ 2W J	ORG029J-560
R1528	OM R 390 $\Omega$ 1W J	ORG019J-391
R1534	ZN R	ERZ-C05ZK471
VR1501	ZN R	ERZ-C05DK271
$\Delta$ R1703	$\Delta$ CMF R 39K $\Omega$ $\frac{1}{2}$ W +1%	QRV122F-3902
$\Delta$ R1704	$\Delta$ CMF R 7.68K $\Omega$ $\frac{1}{4}$ W +1%	QRV142F-7681
$\Delta$ R1901	$\Delta$ Posistor	A75414
R1902	UNF R 2 $\Omega$ 7W K	QRF076K-2R0
R1903	CMF R 5.6 $\Omega$ 3W J	QRX039J-5R6
R1904	OM R 10K $\Omega$ 2W J	QRG026J-103Z
$\Delta$ FR1901	$\Delta$ F R 220 $\Omega$ $\frac{1}{2}$ W K	QRH124K-221M

### Main P.C.B. Ass'y (SU-1103A) Parts List

Symbol	Description	Part Number
C1402	Tan. Cap. 2.2uF 16V K	QEE51CK-225B
C1411	E Cap. 100uF 160V A	QEW52CA-107
C1412	E Cap. 3.3uF 160V A	QEW52CA-335
C1508	PP Cap. 5600pF 50V J	QFP31HJ-562
C1511	E Cap. 47uF 160V A	QEW52CA-476S
$\Delta$ C1512	$\Delta$ PP Cap. 2000pF DC1500V J	QFZ0082-202
$\Delta$ C1513	$\Delta$ PP Cap. 2000pF DC1500V J	QFZ0082-202
$\Delta$ C1514	$\Delta$ PP Cap. 2500pF DC1500V J	QFZ0082-252
C1515	PP Cap. 0.53uF DC1200V K	QFZ0067-534
C1520	BPE Cap. 1uF 50V A	QEN61HA-105Z
C1524	M Cap. 0.1uF 200V K	QFM72DK-682M
C1904	E Cap.	QEY0034-001
C1905	E Cap. 10uF 250V A	QEW52EA-106
$\Delta$ C1907	$\Delta$ MM Cap. 0.1uF AC150V Z	QFZ9008-104

Symbol	Description	Part Number
L1501	Peaking Coil	A75360-6
L1502	Liniarty Coil	A39934
L1503	Width Coil	C30380-A
L1504	Heater Choke	C30333-A
L1901	Line Filter	A39475-J

Symbol	Description	Part Number
T1501	Hor. Drive Transf.	A46022-BM
T1503	Side Pin Transf.	C39050-A

Symbol	Description	Part Number
IC1501	I.C.	HA11244
X1101	Si. Transistor	2SC1685(R)
X1102	Si. Transistor	2SA673(C)
X1103	Si. Transistor	2SC1685(R)
X1104	Si. Transistor	2SA673(C)
X1105	Si. Transistor	2SC1685(R)
X1106	Si. Transistor	2SA673(C)
X1301	Si. Transistor	2SC1685(R)
X1302	Si. Transistor	2SC1685(R)
X1303	Si. Transistor	2SA673(C)
X1304	Si. Transistor	2SC1685(R)
X1305	Si. Transistor	2SC1685(R)
X1401	Si. Transistor	2SD478
X1402	Si. Transistor	2SD478
X1501	Si. Transistor	2SC2610BK
X1701	Si. Transistor	2SC1685(P-S)
D1101	Si. Diode	W06A
D1102	Si. Diode	W06A
D1103	Si. Diode	W06A
D1301	Si. Diode	1S2473H
D1401	Si. Diode	1S2473H
D1402	Zener Diode	RD10F(C)
D1503	Si. Diode	HF-1
D1504	Si. Diode	V09E
D1505	Zener Diode	RD11E(B)
D1506	Si. Diode	W06A
D1507	Si. Diode	1SS81
D1508	Si. Diode	1S2473H
$\Delta$ D1701	$\Delta$ Zener Diode	D20EV2
$\Delta$ D1901	$\Delta$ Si. Diode	1S1887A
$\Delta$ D1902	$\Delta$ Si. Diode	1S1887A
$\Delta$ D1903	$\Delta$ Si. Diode	1S1887A
$\Delta$ D1904	$\Delta$ Si. Diode	1S1887A

Symbol	Description	Part Number
$\Delta$ F1901	$\Delta$ Fuse 1A	QMF53U1-1ROS
$\Delta$ F1902	$\Delta$ UL Fuse 3A	QMF66U1-3ROS

### CRT Socket P.C.B. Ass'y (SU-3016A) Parts List



Symbol	Description	Part Number
R3105	V R 200 $\Omega$	QVZ3234-022
R3106	V R 200 $\Omega$	QVZ3234-022
R3113	V R 5K $\Omega$	QVZ3234-053
R3114	V R 5K $\Omega$	QVZ3234-053
R3115	V R 5K $\Omega$	QVZ3234-053
R3116	OM R 10K $\Omega$ 2W J	QRG029J-103
R3117	OM R 10K $\Omega$ 2W J	QRG029J-103
R3118	OM R 10K $\Omega$ 2W J	QRG029J-103
R3119	Comp. R 3.3K $\Omega$ $\frac{1}{2}$ W K	QRZ0039-332
R3120	Comp. R 3.3K $\Omega$ $\frac{1}{2}$ W K	QRZ0039-332
R3121	Comp. R 3.3K $\Omega$ $\frac{1}{2}$ W K	QRZ0039-332

Symbol	Description	Part Number
C3107	E Cap. 10uF 250V A	QEW52EA-106
C3108	C Cap. 1000pF DC1400V P	QCZ9001-102M

Symbol	Description	Part Number
L3101	Peaking coil	QQL043K-101

Symbol	Description	Part Number
X3101	Si. Transistor	2SC2611
X3102	Si. Transistor	2SC2611
X3103	Si. Transistor	2SC2611

Symbol	Description	Part Number
$\Delta$	CRT Socket	A75522



SCHEMATIC FOR  
9-186-03  
SWEEP BOARD  
RGB COLOR MONITOR

ZENITH RADIO CORP. CHICAGO, ILL.	ISSUE B	9-186
M051-00087-A021		


NOTES: (USED WITH CIRCUIT REFERENCE DESIGNATORS)  
1. ALL RESISTORS ARE 1/4 WATT FILM 5% TOLERANCE UNLESS OTHERWISE SPECIFIED.  
2. ALL CAPACITORS ARE IN MICROFARADS UNLESS OTHERWISE SPECIFIED.

NOTES: (USED WITH CIRCUIT REFERENCE DESIGNATORS)  
A. P/L - SEE PARTS LIST FOR APPLICABLE USAGE.  
R. - - - - JUMPER WIRE USED INSTEAD.  
C. - - - - PROVISION ON PRINTED CIRCUIT BOARD.

**ZENITH MONITOR — SWEEP BOARD  
REPLACEMENT PARTS LIST**

**SWEEP BOARD (9-186-03)**

Ref. No.	Part No.	Description	Ref. No.	Part No.	Description
<b>CAPACITORS</b>			<b>TRANSFORMERS &amp; COILS</b>		
C2131	22-7508	47 MF, 35V, ±20% Electrolytic	L3207	149-454	Core, Ferrite Bead
C2152	22-7508-01C	22 MF, 35V, ±20% Electrolytic	L3220	F-13834	Core & Sleeving Assy. (149-509-01)
C3201	22-7410-05	10 MF, 100V, ±20% Electrolytic	LX3261	20-3976	Coil Width
CX3202	22-7710-01C	1 MF, 50V, +50%–10% Electrolytic	LX3262	20-3975	Coil, Linearity, with 205-271 Hot Melt
C3203	22-7711-08C	47 MF, 63V, +50%–10% Electrolytic	T3205	95-3344	Transformer, Horizontal Driver
CX3204	22-7773-24A	0.1 MF, 100V, ±5% Polyester	TX3204	95-3581-01	Transformer, Sweep
CX3205	22-7523-01	0.01 MF, 2KV, ±20% Disc	<b>RESISTORS</b>		
C3206	22-7708-04C	4.7 MF, 25V, +50%–10% Electrolytic	R2105	63-9921-94	8.2K Ohm, ±5% 1/4W Film
C3207	22-5665	330 PF, 1000V, ±10% Disc	R2110	63-9921-64	470K Ohm, ±5% 1/4W Film
C3209	22-7242	0.0018 MF, 200V, ±10% Disc	R2111	63-9919-83	3K Ohm, ±2% 1/4W Film
C3211	22-7777-20B	0.047 MF, 200V, ±10% Polyester	R2112	63-9919-96	10K Ohm, ±2% 1/4W Film
C3212	22-7234	560 PF, 500V, ±10% Disc	RX3204	63-9921-80	2.2K Ohm, ±5% 1/4W Film
C3213	22-7775-16A	0.022 MF, 100V, ±20% Polyester	RX3206	63-7805	3.3K Ohm, ±5% 1/2W Carbon
C3214	22-7775-10A	0.0068 MF, 100V, ±20% Polyester	RX3207	63-9921-32	22 Ohm, ±5% 1/4W Film
C3216	22-5684	470 PF, 500V, ±20% Disc	RX3208	63-10235-80	2.2K Ohm, ±5% 1/4W Film
C3217	22-5684	470 PF, 500V, ±20% Disc	RX3209	63-10235-72	1K Ohm, ±5% 1/4W Film
C3218	22-7774-15C	0.018 MF, 100V, ±10% Polyester	RX3210	63-7805	3.3K Ohm, ±5% 1/2W Carbon
C3222	22-7742-10	0.001 MF, 50V, ±10% Axial	RX3211	63-10810-07	3K Ohm, ±1% 1/2W Film
CX3228	22-6466	530 PF, 3KV, ±10% Disc	RX3214	63-10233-81	2.4K Ohm, ±2% 1/4W Film
CX3229	22-7672-07	0.013 MF, 1.6KV, ±5% Polypropylene	RX3216	63-10810-06	1.2K Ohm, ±1% 1/2W Film
C3233	22-7728	0.68 MF, 200V, ±10% Polyester	RX3217	63-7760	270 Ohm, ±5% 1/2W Carbon
C3244	22-7566-24	0.1 MF, 250V, ±10% Polyester	RX3215	63-10235-98	12K Ohm, ±5% 1/4W Film
C3261	22-7683-01	0.68 MF, 200V, ±5% Polypropylene	RX3218	63-10235-82	2.7K Ohm, ±5% 1/4W Film
<b>SEMICONDUCTORS</b>			RX3219	63-10235-88	4.7K Ohm, ±5% 1/4W Film
CR3202	103-142-01	Diode, Low Voltage	R3224	63-9946-88	4.7K Ohm, ±5% 1/2W Film
CR3203	103-330A	Diode, Low Voltage	R3225	63-10836-68	680 Ohm, ±5% 2W Wire Wound
CRX3204	103-308A	Diode, Zener	R3226	63-10235-74	1.2K Ohm, ±5% 1/4W Film
CR3205	103-305	Diode, Damper	R3227	63-10235-80	2.2K Ohm, ±5% 1/4W Film
CR3206	103-284A	Diode, Low Voltage	RX3235	63-10810-06	1.2K Ohm, ±1% 1/2W Film
CR3207	103-295-01A	Diode, Low Voltage (used with 149-454)	RX3240	53-10657-04	10 Meg Ohm, ±20% 1/2W Carbon
CR3208	103-295-01A	Diode, Low Voltage	R3242	63-10243-80	2.2K Ohm, ±5% 1/2W Film
CR3209	103-142-01	Diode, Low Voltage	R3243	63-10243-80	2.2K Ohm, ±5% 1/2W Film
CR3210	103-142-01	Diode, Low Voltage	R3244	63-7868	100K Ohm, ±5% 1/2W Carbon
CR3211	103-142-01	Diode, Low Voltage	R3261	63-10444-86	390 Ohm, ±10% 5W Wire Wound
QX3202	121-975	Transistor, NPN	R3262	63-10565-65	510 Ohm, ±10% 1/2W Film
QX3204	121-973	Transistor, PNP, Shutdown	R3263	63-10565-65	510 Ohm, ±10% 1/2W Film
Q3206	121-1037	Transistor, NPN, Forward Driver	R3282	63-10235-96	10K Ohm, ±5% 1/4W Film
QX3207	121-975	Transistor, NPN, Shutdown			
Q3209	121-1040	Transistor, NPN, Reverse Driver			



SCHEMATIC FOR  
9-227-01  
RGB COLOR MONITOR  
(MAIN BOARD)

**ZENITH  
RADIO CORP.** C 9-227  
CHICAGO, ILL.

M051-00087-A024



**ZENITH MONITOR — CRT SOCKET BOARD  
REPLACEMENT PARTS LIST**


**MAIN BOARD (Continued)**

Ref. No.	Part No.	Description
<b>SEMICONDUCTORS</b>		
CR2104	103-142-01	Diode, Low Voltage
CR2105	103-254-01	Diode, Low Voltage
CR2106	103-254-01	Diode, Low Voltage
CR2107	103-254-01	Diode, Low Voltage
CR2501	103-142-01	Diode, Low Voltage
CR2502	103-142-01	Diode, Low Voltage
CR2503	103-142-01	Diode, Low Voltage
CR3202	103-330A	Diode, Low Voltage
CR3205	103-309-01	Diode, Zener 10V 1W
CR3206	103-254-01	Diode, Low Voltage
CR3208	103-326A	Diode, Low Voltage
CR3210	103-254-01	Diode, Low Voltage
CR3211	103-254-01	Diode, Low Voltage
CR3214	103-284-A	Diode, Low Voltage
CR3217	103-326A	Diode, Low Voltage
CR3219	103-330A	Diode, Low Voltage
CR3223	103-330A	Diode, Low Voltage
CR3224	103-330A	Diode, Low Voltage
CR3231	103-315-06A	Diode
CR3232	103-315-06A	Diode
CR3233	103-315-06A	Diode
CR3234	103-315-06A	Diode
CR3235	103-284A	Diode, Low Voltage
CR3401	103-142-01	Diode, Low Voltage
CR3404	103-143-01	Diode, Low Voltage
CR3405	103-142-01	Diode, Low Voltage
CR3406	103-142-01	Diode, Low Voltage
CR3408	103-279-14	Diode, Zener 6.8V 1/2W
Q2101	F-10896	Transistor & Heat Sink Assy.
Q2102	F-10896	Transistor & Heat Sink Assy.
Q2103	121-975	Transistor NPN
Q2104	121-1064	Transistor PNP
Q2501	121-1019	Transistor PNP
Q2502	121-895	Transistor NPN
Q2502	121-551	Transistor NPN
(on -01 version)		
Q2503	121-1019	Transistor PNP
Q2504	121-895	Transistor NPN
Q2504	121-551	Transistor NPN
(on -01 version)		
Q2505	121-1019	Transistor PNP
Q2506	121-895	Transistor NPN
Q2506	121-551	Transistor NPN
(on -01 version)		
Q2507	121-1019	Transistor
Q2508	121-1019	Transistor
Q2509	121-1019	Transistor
Q3200	F-12737	Transistor & Heat Sink Assy.
Q3201	121-499-01	Transistor NPN Regular Feed Back
Q3202	121-1034	Transistor NPN
Q3203	121-1059	Transistor PNP
Q3401	121-895	Transistor NPN
Q3402	121-986	Transistor PNP
Q3403	121-985	Transistor NPN
Q3404	121-895	Transistor NPN
Q3405	121-895	Transistor NPN
<b>TRANSFORMERS &amp; COILS</b>		
L2502	20-3887-01	Coil Peaking 1.2 UH
L2503	20-3887-01	Coil Peaking 1.2 UH
L2504	20-3887-01	Coil Peaking 1.2 UH
L3201	20-2021	Coil Peaking 100 UH
LX3202	95-3501-01	Transformer Choke 60 UH
L3401	20-3831	Coil Peaking 663 UH
L3402	20-3998	Coil Peaking 39 UH
L3402	20-4026	Coil Turnable 39 UH
(on -01 version)		

**CRT SOCKET (9-155-10)**



Ref. No.	Part No.	Description
<b>CAPACITORS</b>		
C5101	22-4671	0.01 MF, 1.5KV, +80%—20% Disc
C5102	22-3512	0.01 MF, 1KV, +40%—10% Disc
<b>TRANSFORMERS &amp; COILS</b>		
L5102	20-3887-28E	220 MH Peaking
L5103	20-3887-28E	220 MH Peaking
L5104	20-3887-28E	220 MH Peaking
<b>SEMICONDUCTORS</b>		
Q5101	F7510	Transistor, NPN, Video Out, Blue
Q5102	F7510	Transistor, NPN, Video Out, Red
Q5103	F7510	Transistor, NPN, Video Out, Green
<b>RESISTORS</b>		
R5101	63-10840-88	4.7K Ohm, ±5%, 3W Film
R5102	63-7785	1K Ohm, ±10%, 1/2W Carbon
R5103	63-7785	1K Ohm, ±10%, 1/2W Carbon
R5104	63-10235-54	180 Ohm, ±5%, 1/4W Film
R5105	63-10235-48	100 Ohm, ±5%, 1/4W Film
R5106	63-7785	1K Ohm, ±10%, 1/2W Carbon
R5107	63-7785	1K Ohm, ±10%, 1/2W Carbon
R5108	63-7785	1K Ohm, ±10%, 1/2W Carbon
R5109	63-7785	1K Ohm, ±10%, 1/2W Carbon
R5110	63-7785	1K Ohm, ±10%, 1/2W Carbon
R5111	63-7799	2.2K Ohm, ±10%, 1/2W Carbon
R5112	63-10840-88	4.7K Ohm, ±5%, 3W Carbon
R5113	63-10840-88	4.7K Ohm, ±5%, 3W Carbon
R5114	63-10235-54	180 Ohm, ±5%, 1/4W Film
R5115	63-10235-54	180 Ohm, ±5%, 1/4W Film
<b>MISCELLANEOUS</b>		
5A2	86-799	Stake Connector 4/.156
5C2	86-799	Stake Connector 4/.156
5H3	86-799	Stake Connector 2/.156
5X7	86-799	Stake Connector 1/.312
	A-10008	CRT Socket





9-155-10  
(204-960)

.156 CENTERS




NOTE:  
1. ALL RESISTORS ARE 1/2WATT UNLESS OTHERWISE SPECIFIED.

NOTES: (USED WITH CIRCUIT REFERENCE DESIGNATORS)  
A. P/L = SEE PARTS LIST FOR APPLICABLE USAGE.  
B. —●—●— = JUMPER WIRE USED INSTEAD.  
C. —●●—●●— = PROVISION ON PRINTED CIRCUIT BOARD.





M051-00087-A022

SCHEMATIC FOR 9-155-10 RGB COLOR MONITOR CRT SOCKET BOARD		
ZENITH RADIO CORP. CHICAGO, ILL.	ISSUE	9-155



M051-00087-A023

SCHEMATIC FOR A-10530 WIDTH STEP ASSY.		
ZENITH RADIO CORP. CHICAGO, ILL.	ISSUE B	A-10530



**IMPORTANT SAFETY NOTICE**

WHEN SERVICING THIS CHASSIS, UNDER NO CIRCUMSTANCES SHOULD THE ORIGINAL DESIGN BE MODIFIED OR ALTERED WITHOUT PERMISSION FROM THE ZENITH RADIO CORPORATION. ALL COMPONENTS SHOULD BE REPLACED ONLY WITH TYPES IDENTICAL TO THOSE IN THE ORIGINAL CIRCUIT, AND THEIR PHYSICAL LOCATION, WIRING AND LEAD DRESS MUST CONFORM TO ORIGINAL LAYOUT UPON COMPLETION OF REPAIRS.

SPECIAL CIRCUITS ARE ALSO USED TO PREVENT SHOCK AND FIRE HAZARD. THESE AREAS ARE SHADED ON THE SCHEMATIC FOR EASY IDENTIFICATION. THE LETTER "X" INCLUDED IN THE ITEM NUMBER DESIGNATES SPECIAL FAILSAFE COMPONENTS IN THESE AREAS WHICH ARE REQUIRED TO MAINTAIN SAFE PERFORMANCE. NO DEVIATIONS ARE ALLOWED WITHOUT PRIOR APPROVAL BY THE PRODUCT SAFETY ENGINEERING DEPARTMENT.

THIS CIRCUIT DIAGRAM MAY OCCASIONALLY DIFFER FROM THE ACTUAL CIRCUIT USED. THIS WAY, IMPLEMENTATION OF THE LATEST SAFETY AND PERFORMANCE IMPROVEMENT CHANGES INTO THE SET IS NOT DELAYED UNTIL THE NEW SERVICE LITERATURE IS PRINTED.

M051-00087-A025

INTERCONNECT FOR VIDEO GAME MONITOR

ZENITH RADIO CORP. CHICAGO, ILL.

ISS:JE

# VII. Coin Door Maintenance

**SPECIAL NOTE:** If you have any questions about the coin acceptors in your game(s), please feel free to contact their manufacturers. Each manufacturer's name is **PROMINENTLY** imprinted on every acceptor mechanism.

Metal mechanisms only:  
**COIN MECHANISMS, INC.**  
817 Industrial Drive  
Elmhurst, IL 60126  
Phone (312) 279-9150

Metal and Plastic mechanisms:  
**COINCO COIN ACCEPTORS, INC.**  
860 Eagle Drive  
Bensenville, IL 60106  
Phone (312) 766-6781

## COIN DOOR MAINTENANCE

### METAL COIN ACCEPTOR MECHANISMS

Periodically, the metal coin acceptor mechanism(s) must be removed from the coin door and cleaned.

1. **Make sure the power to the game is off.**
2. Unlock and open the coin door.

3. Remove the coin acceptor mechanism as shown in Figure 5-1.

- Push down on the two spring loaded latches.
- While holding the latches down, pull the top of the coin acceptor mechanism toward you.
- Release the latches and lift out the coin acceptor mechanism.




Figure 5-1 Removing and Replacing the Coin Acceptor

4. Clean the magnet of all foreign particles. See Figure 5-2.
  - This may be accomplished by swinging the gate open as shown in the above figure.
5. Remove the cradles and undersize levers and clean the bushings. (A pipe cleaner makes a good bushing cleaner.)
  - Also clean the pivot pin.
6. Whenever needed, the coin acceptor should be cleaned with hot water and cleanser in the following manner:
  - Place the coin acceptor in boiling water for about ten minutes.

**CAUTION: BE CAREFUL NOT TO BURN YOURSELF.**

- Next, use a brush and kitchen cleaner to remove all remaining foreign matter from the unit.
- Rinse the coin acceptor in clean boiling water.
- Dry the coin acceptor thoroughly by using filtered compressed air to blow it dry.

**NOTE:** The reason we recommend using boiling water is that it evaporates faster than cold water and speeds drying time.




Figure 5-2 Cleaning the Metal Coin Acceptor

7. To lubricate the coin acceptor:
  - Use **ONLY** powdered graphite and put it **ONLY** on the moving parts of the coin acceptor. These parts are called out in Figure 5-3.
  - Be extremely careful to keep the powdered graphite away from paths that are traveled by the coins.

**— WARNING —  
DO NOT USE OIL  
TO LUBRICATE THE  
COIN ACCEPTOR.**

8. Check the coin chute for obstructions such as: paper, gum, etc.
9. Reinstall the coin acceptor to the coin door. See Figure 5-1.
  - Place the two pegs at the coin acceptor's base into their retaining slots.
  - Now push the top of the coin acceptor toward the coin door until it snaps in place and is held there by the two spring loaded latches.
10. Close and lock the coin door.




Figure 5-3 Lubricating the Metal Coin Acceptor





Figure 5-4 Opening the Plastic Coin Acceptor

### PLASTIC COIN ACCEPTOR MECHANISMS

The plastic coin acceptor mechanism(s) must be removed periodically from the coin door and cleaned.

1. **Make sure the power to the game is off.**
2. Unlock and open the coin door.
3. Remove the coin acceptor mechanism(s) as shown in Figure 5-1.
  - Push down on the two spring loaded latches.
  - While holding the latches down, pull the top of the acceptor mechanism toward you.
  - Release the latches and lift out the mechanism.
4. Squeeze the two pins indicated in Figure 5-4 together to open the mechanism and break it down into its three basic parts.
  - Clean the mechanism in hot soapy water. It never rusts.
  - Rinse the mechanism in clean hot water and allow it to dry.
5. Check the coin chute for obstructions such as: paper, gum, etc.
6. Reinstall the coin acceptor to the coin door. See Figure 5-5.
  - Place the two pegs at the coin acceptor's base into their retaining slots.
  - Now push the top of the coin acceptor toward the coin door until it snaps in place and is held there by the two spring loaded latches.
7. Close and lock the coin door.


**NOTE:** See Figure 5-6 for instructions on how to set the plastic coin acceptor mechanisms to either accept or reject Canadian quarters.



**Figure 5-5 Changing the Plastic Coin Acceptor to Accept American or Canadian Quarters**

## **VIII. Schematics & Wiring Diagrams**






3-1-81  
 MOD: 00639-A003  
 Karna Kooft  
 Billy Midway  
 JOSO W Belmont  
 Plank: Park, D SOLCH

Notes:  
 \* = 18 AWG WIRE  
 \* = 22 AWG 40V WIRE

DESIGNATION LIST

DESIGNATION	DESCRIPTION	DESIGNATION	DESCRIPTION
C101	4700uf AX. ELECT.	R117	560ohm 1/4W 5%
C102	470uf AX. ELECT.	R118	150ohm 2W
C103	.1uf AX. CER.	R201	270ohm 1/4W 5%
C104	47uf AX. CER.	R202	1.2K 1/4W 5%
C105	470uf AX. ELECT.	R203	1.1M 1/4W 5%
C106	470uf AX. ELECT.	R204	3.3M 1/4W 5%
C107	100uf RD. TANT.	R205	10M 1/4W 5%
C108	1uf RD. TANT.	R206	100K 1/4W 5%
C109	4.7uf RD. TANT.	R207	33K 1/4W 5%
C110	.1uf AX. CER.	R208	2M 1/4W 5%
C111	.1uf AX. CER.	R209	1M 1/4W 5%
C201	.01uf MYLAR	R210	1.2M 1/4W 5%
C202	.03uf MYLAR	R211	75K 1/4W 5%
C203	.01uf MYLAR	R212	75K 1/4W 5%
C204	.047uf MYLAR	R213	220K 1/4W 5%
C205	820uf AX. CER.	R214	3.9K 1/4W 5%
C206	.01uf AX. CER.	R215	1.2K 1/4W 5%
C207	0.082uf MYLAR	R216	82ohm 1W 10%
		R217	270ohm 1/4W 5%
		R218	110K 1/4W 5%
		R219	68ohm 1/2W 5%
		VR101,102	100ohm POT
CP1	.1uf AX. CER.	D101	A15F
R101	.18ohm 5W W/RES. SPACER	D102	A15F
R102	68ohm 1/2W 5%	D103	A15F
R104	10ohm 5W W/RES. SPACER	D104	A15F
R105	27ohm 1/4W 5%	D105	A15F
R106	270ohm 1/4W 5%	D106	1N4001
R107	6.2K 1/4W 5%	D201	1N4148
		D202	1N4148
		D203	1N4148
		D204	1N4001
		D205	1N4001
R109	1K 1/4W 5%	O102	2N2905
R110	.16ohm 15W W/RES. SPACER	O105	2N2905
R111	6.8ohm 1/2W 5%	O201	2N4401
R112	6.8ohm 1/2W 5%	U1	LM305 REG.
R113	1.2K 1/4W 5%	U2	LM305 REG.
R114	47ohm 1/4W 5%	U3	LM3900
R115	160ohm 1/4W 5%	U4	4N28
		U6	555
		L101	22uH INDUCTOR
		B101	BATTERY 3.6VDC 60DEG C
		F1	3 RA S BLO FUSE
		FC1A,1B	FUSE CLIP
		FF1,2	FERRITE BEAD
		TW1	TIE WRAP
		J3	9PIN P.C. MOUNT CONN (MALE)
		J4	15PIN P.C. MOUNT CONN (FEMALE)
		J5	15PIN P.C. MOUNT CONN (MALE)
		J6	3PIN P.C. MOUNT CONN (MALE)
		LB1	FUSE TAG
		LB2	SYSTEM TAG
		HSA1	HEAT SINK ASS'Y 1
		MHSA1	MOUNTING HARD WARE (HEAT SINK)
			2 SCREW
			4 WASHER
			2 HEXNUT
		JW1,5	JUMPER WIRE
		FBMH1,2	FERRITE BEAD MOUNTING HARDWARE



FROJ. ENG. L. DEKKER

MIDWAY MFG. CO.

ASSEMBLY DRAWING 125VA PWRSPLY


A082-90412-D000

M051-00945-B006

5/14/82

CROSS REFERENCE LIST

DESCRIPTION	Q'ty	DESIGNATION	PART #
47uf AX. CER.	1	C105	0945-00811-0100
820uf AX. CER.	1	C205	0945-00816-0400
.01uf AX. CER.	2	C206,208	0945-00816-0100
.01uf MYLAR	2	C201,203	0945-00816-0200
.03uf MYLAR	1	C202	0945-00816-0500
.047uf MYLAR	1	C204	0945-00816-0300
0.082uf AX. CER.	1	C207	0945-00816-1900
.1uf AX. CER.	5	C103,104,110,111, CP1	0945-00811-0200
1uf RAD. TANT.	1	C108	0911-00811-0300
4.7uf RAD. TANT.	1	C109	0945-00811-0400
100uf RAD. TANT.	1	C107	0915-00811-0500
470uf AX. ELECT.	2	C102,106	0945-00816-0600
470uf AX. ELECT.	1	C101	0945-00811-0700
.16ohm 15W 5%	1	R110	0945-00815-0100
.18ohm 5W 5%	1	R101	0945-00815-0200
6.8ohm 1/2W 5%	1	R111	0062-04703-1XXX
10ohm 5W 5%	1	R104	0945-00812-0100
27ohm 1/4W 5%	1	R105	0062-068B3-1XXX
47ohm 1/4W 5%	1	R114	0062-068B3-1XXX
68ohm 1/2W 5%	3	R102,112,219	0062-098D3-1XXX
82ohm 1W 10%	1	R216	0062-104F5-1XXX
150ohm 2W 5%	1	R118	0945-00812-0200
160ohm 1/4W 5%	1	R115	0062-124B3-1XXX
270ohm 1/4W 5%	3	R106,201,217	0062-138B3-1XXX
560ohm 1/4W 5%	1	R117	0062-162B3-1XXX
1K 1/4W 5%	1	R109	0062-179B3-1XXX
1.2K 1/4W 5%	3	R113,202,215	0062-183B3-1XXX
3.9K 1/4W 5%	1	R214	0062-207B3-1XXX
6.2K 1/4W 5%	1	R107	0062-217B3-1XXX
33K 1/4W 5%	1	R207	0062-251B3-1XXX
75K 1/4W 5%	2	R211,212	0062-269B3-1XXX
100K 1/4W 5%	1	R206	0062-275B3-1XXX
110K 1/4W 5%	1	R218	0062-277B3-1XXX
220K 1/4W 5%	1	R213	0062-291B3-1XXX
1M 1/4W 5%	1	R209	0062-323B3-1XXX
1.1M 1/4W 5%	1	R203	0062-325B3-1XXX
1.2M 1/4W 5%	1	R210	0062-327B3-1XXX
2M 1/4W 5%	1	R205	0062-337B3-1XXX
3.3M 1/4W 5%	1	R204	0062-347B3-1XXX
10M 1/4W 5%	1	R205	0062-371B3-1XXX
100ohm POT	2	VR101,102	0945-00814-0000
LM305 REG.	2	U1,2	0945-00813-0100
555	1	U6	0929-00810-4500
LM3900	1	U3	0945-00813-0200
4N28	1	U4	0945-00813-0300
A15F RECTIFIER	5	D101-105	0945-00804-0200
1N4001	3	D106,204,205	0945-00804-0300
1N4148	3	D201-203	0945-00804-0500
2N2905	2	O102,105	0945-00808-0300
2N4401	1	O201	0945-00804-0400
BATTERY 3.6VDC 60DEG-C	1	B101	0017-00003-0377
FUSE 3/8A S-BLO	1	F1	0945-00808-0400
FUSE CLIP	2	FC1A,1B	0017-00003-0214
TIE WRAP	1	TW1	0945-00814-0300
FERRITE BEAD	2	FB1,2	0017-00009-0224
FERRITE MOUNTING HDW.	2	FBMH1,2	0017-00033-0139
22uH INDUCTOR	1	L101	0945-00814-0200
FUSE TAG	1	LB2	M051-00945-A004
SYSTEM TAG	1	LB1	M051-00945-A009
P.C.B.	1		A080-90412-U000
HEAT SINK ASS'Y	1	HSA1	A945-00008-0000
(SEE HS ASS'Y DRAWING "HW NOTE")			
4-40X10 SLT RND	2	MHSA1A,2A	0017-00101-00727
4-40 HEX NUT	2	MHSA1E,2E	0017-00103-0002
WSH 4-120-.250-018	4	MHSA1B,1D	0017-00104-0071
MHSA2B,2D			
3PIN P.C. MOUNT CONN. (MALE)	1	J6	0017-00021-0443
9PIN P.C. MOUNT CONN.(MALE)	1	J3	0017-00021-0425
15PIN P.C. MOUNT CONN.(FEMALE)	1	J4	0017-00021-0441
15PIN P.C. MOUNT CONN.(MALE)	1	J5	0017-00021-0440
22 AWG T & R BARE 2.5"	5	JW1-5	0151-00087-0000




PROJECT ENG. L. DEKKER		DRAWN BY SATAN/PULLOW		MIDWAY MFG. CO.	
DO NOT SCALE DRG.		FULL		FRANKLIN PK. ILL.	
DATE TOLERANCES		NO REVD. 1 PER.		PART NO.	
BY M.M.		POWER SUPPLY 125VA		M051-00945-0007	
DATE 5/3/82		W/CKT SUPPORT		A082-90412-0000	

## DESIGNATION LIST

DESIGNATION	DESCRIPTION
C1,C2	4.7mf 25v rd.tant.
C3,C4	22mf 6v " "
C5,C6	470mf 6v ax.elect.
C7-C10	.1mf 50v ax.cr.
CP1	220mf 25v ax.elect.
CP2,CP3	.1mf 50v ax.cr.
R1,R2	2.7K $\Omega$ 1/4w 5% CRBN.
R3,R4	27 $\Omega$ " " " "
R5-R8	1 $\Omega$ 1/2w " " " "
U1,U2	MB3730
J1	3 PIN STRT.KKI56
J2	2 PIN STRT.KKI56
HSA1,2	HEATSINK ASSY.
MH1-MH4	HEYCO BUSHING

## CROSS REFERENCE LIST

DESCRIPTION	QTY	DESIGNATION	PART NO
.1mf 50v ax.cr.	6	C7-C10, CP2,CP3	0986-00800-1100
4.7mf 25v rd.tant.	2	C1,C2	0986-00800-3100
22mf 6v " "	2	C3,C4	0986-00800-1600
220mf 25v ax.elec.	1	CP1	0986-00800-3200
470mf 6v " "	2	C5,C6	0986-00800-1700
1 $\Omega$ 1/2w 5%	4	R5-R8	0062-026D3-1XXX
27 $\Omega$ 1/4w " "	2	R3,R4	0062-068B3-1XXX
2.7K " " " "	2	R1,R2	0062-199B3-1XXX
MB3730	2	U1,U2	0066-188XX-XX4X
2 PIN STRT.KKI56	1	J2	3000-16367-0200
3 " " " "	2	J1,J2	3000-16367-0300
4 " " " "	1	J1	3000-16367-0400
HEATSINK ASSY.	2	HSA1, HSA2	A986-00010-E000
HEYCO BUSHING	4	MH1-MH4	0017-00042-0014
PC BOARD	1		A080-90910-E000




PROJECT ENG. C. MEDNICK



THIS DWG IS CONFIDENTIAL & PROPERTY OF MIDWAY MFG. CO.

<b>DIM. TOLERANCES</b> UNLESS OTHERWISE SPEC CONCENTRICITY T.I.R. .002 FRACTIONAL ± 1/64 DECIMAL ± .005 HOLE DIA. + .002 - .000 ANGLE ± 1/2° DO NOT SCALE DWG	FIRST USED ON	TRON		<b>MIDWAY MFG. CO.</b> FRANKLIN PK., IL. 60131 A BALLY CO	<b>REVISIONS</b> PART NO <b>M051-00986-E010</b>	
	DRN	TJK	DATE			9-1-82
	MECH. CHK		MAT'L			
	ELEC. CHK		FINISH			
<b>DUAL PWR. AMP. ASSY</b> A080-90910-E000						

- J1
- PIN 1 — N.C.
  - 2 — L. AUDIO
  - 3 — L. SHIELD
  - 4 — KEY
  - 5 — V AUDIO RETURN
  - 6 — R. AUDIO
  - 7 — R. SHIELD
  - 8 — V AUDIO




- J2
- PIN 1 — R+
  - 2 — R-
  - 3 — KEY
  - 4 — L+
  - 5 — N.C.
  - 6 — L-



REVISIONS		MIDWAY MFG. CO.	
		FRANKLIN PK. ILL.	
USED ON TRON		PART NO. M051-00986-E011	
SCALE NONE		SCHEMATIC, DUAL POWER AMP, A082-90910-E000	
HEAT TREAT		MATERIAL FINISH	
DO NOT SCALE DWG.		DATE 9/1/82	
DIM TOLERANCES UNLESS SPECIFIED		DRN SKL	
CONCENTRICITY T I R .003		CKD	
FRACTIONAL .1/64			
DECIMAL .005			
HOLE DIA +.002 .000			

**DESIGNATION LIST**

DESIGN. NO.	DESCRIPTION
C101	4.7 $\mu$ f TANT 16V RAD.
CP 1	.01 $\mu$ f 50V AX. CER.
CP 2	10 $\mu$ f 16V AX. ELECT.
CP 3	.01 $\mu$ f 50V AX. CER.
CP 4	.01 $\mu$ f 50V AX. CER.
CP 5	10 $\mu$ f 16V AX. ELECT.
CP 6	.01 $\mu$ f 50V AX. CER.
R101	4.7K 1/4W 5%
R102	4.7K 1/4W 5%
R103	200K 1/4W 5%
R104	200K 1/4W 5%
R105	6.2K 1/4W 5%
R106	120 ohm 1/4W 5%
R107	30 K 1/4W 5%
R108	91 K 1/4W 5%
R109	200K 1/4W 5%
R110	200K 1/4W 5%
R111	4.7 K 1/4W 5%
R112	6.2 K 1/4W 5%
OPT 1	OPTICAL SENSOR
U 1	74LS491
U 2	LM 339
J 1	13 PIN KK-156 RT. ANGLE (PIN 11 OMITTED)
MHOPT 1A,1B	PLASTIC RIVET RND. HD.
A082-91482-A000 P.C.B.	




**CROSS REFERENCE LIST**

DESCRIPTION	QTY	DESIGN. NO.	PART NO.
.01 $\mu$ f 50V AX. CER.	4	CP1,3,4,6.	0628-00800-0100
4.7 $\mu$ f 16V RAD. TANT.	1	C101	0628-00800-0200
10 $\mu$ f 16V AX. ELECT.	2	CP 2,5	0628-00800-0300
120 ohm 1/4W 5%	1	R106	0062-116B3-1XXX
4.7K 1/4W 5%	3	R101,102,111.	0062-211B3-1XXX
6.2K 1/4W 5%	2	R105,112	0062-217B3-1XXX
30 K 1/4W 5%	1	R107	0062-249B3-1XXX
91 K 1/4W 5%	1	R108	0062-273B3-1XXX
200K 1/4W 5%	4	R103,104,109,110.	0062-289B3-1XXX
74LS491	1	U 1	0628-00803-2700
LM 339	1	U 2	0628-00803-2900
OPTICAL SENSOR	1	OPT 1	0628-00804-0100
13 PIN KK-156 (RT. ANGLE PIN 11 OMITTED)	1	J 1	3000-16387-1311
PLASTIC RIVET RND. HD.	2	MH OPT 1A,1B.	0017-00072-0091
P.C.B.	1		A082-91482-A000

REVISIONS		

PROJECT ENG: JOHN BOYDSTON		USED ON KOZMIK KROOZ'R		Bally / MIDWAY MFG. CO. FRANKLIN PK. ILL.	
DO NOT SCALE DWG.	HEAT TREAT	SCALE	NO. REQ'D 1 PER		
DIM. TOLERANCES UNLESS SPECIFIED	DRN. <i>C.L.</i>	MAT'L.	ASSY DRAWING		PART NO.
CONCENTRICITY T.I.R. 003	CKD. <i>QBB</i>	FINISH	OPTICAL SENSOR		M051-00114-A022
FRACTIONAL 1/64	DATE 2/17/83		A082-91482-A000		
DECIMAL .005			A084-91482-A000		
HOLE DIA. +.002-.000					



REVISIONS	

PROJECT ENG: JOHN BOYDSTON		USED O KOZMIK KROOZ'R		Bally / MIDWAY MFG. CO. FRANKLIN PK. ILL.	
DO NOT SCALE DWG.		HEAT TREAT	SCALE	NO. REQ'D 1 PER	
DIM. TOLERANCES UNLESS SPECIFIED		MAT'L.	SCHEMATIC DRAWING OPTICAL SENSOR A082-91482-A000 A084-91482-A000	PART NO. M051-00114-A023	
CONCENTRICITY TYP 0.03	DRR. C.L.	FINISH			
FRACTIONAL 1/64	CKD. JBB				
DECIMAL 0.005	DATE 2/17/83				
HOLE DIA +0.02 0.00					

DESIGNATION LIST

Table with columns: DESIGNATION, DESCRIPTION, DESIGNATION, DESCRIPTION, DESIGNATION, DESCRIPTION. Lists various components like resistors, capacitors, and integrated circuits.





Table with columns: DESCRIPTION, QTY, DESIGNATION, PART NOS, DESCRIPTION, QTY, DESIGNATION, PART NOS. Lists components and their quantities for the assembly.


Table containing project information: PROJECT ENG (A GOSH), USED ON KOZMIK KROOZE, SCALE (FULL), NO. RECD (1 PER), PART NO. (M051 - 00639 - A036), and DATE (02/18/83).





DESIGNATION LIST


DESIGNATION	DESCRIPTION	DESIGNATION	DESCRIPTION	DESIGNATION	DESCRIPTION
CI, 2	100 μf AX. ELECT	IC D 1	EPROM	IC L 1	74 LS 20
CI01	100 pf AX. CER.	IC D 2	74 LS194	IC L 2	7408
		IC D 3	74 LS194	IC L 3	7474
CP1-3, 5-10		IC D 4	74 LS273	IC L 4	74 LS283
CP12-20,22-27,		IC D 5	74 LS157	IC L 5	422
CP29-33,35,36,		IC D 6	74 LS157	IC L 6	2114-2
CP38-41,43-47, 0.01μf AX. CER.		IC D 7	74 LS273	IC L 7	74 LS157
CP49-54,56-61,					
CP63-67,69-71.		IC E 2	74 LS194	IC M 1	7430
		IC E 3	74 LS194	IC M 2	7432
		IC E 4	74 LS374	IC M 3	74 S 74
CP4,11,21,28,34,		IC E 5	74161	IC M 4	74161
CP37,42,48,55, 10μf 25V AX. TANT.		IC E 6	74 LS157	IC M 5	422
CP62,68.				IC M 7	74 LS157
		IC F 2	7400		
		IC F 3	74 S04	IC N 1	7430
RI01-119,201,202, 1 K 1/4W 5%		IC F 4	74 LS374	IC N 2	7427
		IC F 5	74 LS157	IC N 3	74 LS273
		IC F 6	74 LS157	IC N 4	74 LS283
				IC N 5	74 LS245
				IC N 6	7404
				IC N 7	74 LS157
RM1,2	8PIN 1K SIP	IC G 1	74 LS 86		
RM 3	10PIN 1K SIP	IC G 2	74 LS 20	ICSA1,B1,C1,D1.	28PIN IC SOCKET
		IC G 3	74 LS293		
		IC G 4	74 LS283	IC H 1	74 LS86
		IC G 5	74 LS283	IC H 2	74174
		IC G 6	74 LS157	IC H 3	74 S 74
				IC H 4	74175
				IC H 5	74174
				IC H 6	74 LS157
IC A 1	EPROM	IC J 2	7430	ICSB5,6,C5,6,	22PIN IC SOCKET
IC A 2	74 LS157	IC J 3	7430	J5,K5,L5,M5.	
IC A 3	74 LS157	IC J 4	74 LS273		
IC A 4	74 LS157	IC J 5	422	ICSK6,L6.	18PIN IC SOCKET
IC A 5	74 LS157	IC J 6	74 LS157	J3,4,5	24 PIN RIGHT ANGLE CONN.
IC A 6	74 LS157			JW1-JW8	JUMPER WIRE
IC A 7	74 LS157			BB1,2	BUSS BAR
				PCMHI-4	PC BDSPACER
				PCMH5-8	PC MTG SCREW
				A080-91399-H000	VID. GEN. PC
IC B 1	EPROM	IC K 1	74161		
IC B 2	74 LS194	IC K 2	7430		
IC B 3	74 LS194	IC K 3	7474		
IC B 4	74 LS32	IC K 4	74161		
IC B 5	422	IC K 5	422		
IC B 6	422	IC K 6	2114-2		
IC B 7	74 LS32				
IC C 1	EPROM				
IC C 2	74 LS194				
IC C 3	74 LS194				
IC C 4	74 LS32				
IC C 5	422				
IC C 6	422				
IC C 7	74 LS32				



CROSS REFERENCE LIST

DESCRIPTION	Q'TY	DESIGNATION	PART NO.
100 PF 50V AX. CER.	1	CI01	0986-00800-1000
.01 μf 50V AX. CER.	60	CP1-3, CP5-10, CP12-20, CP22-27, CP29-33, CP35, 36, CP38-41, CP43-47, CP49-54, CP56-61, CP63-67, CP69-71.	0986-00800-2500
10 μf 25 V AX. TANT.	11	CP4,11,21,28,34,37, CP42,48,55,62,68. CI, 2.	0986-00800-2400
100 μf 25V AX. ELECT.	2		0986-00800-1800
1 K 1/4 W CRBN. FLM.	21	RI01-119, 201, 202.	0062-17983-1XXX
1 K 8 PIN SIP	2	RM1, 2.	0986-00804-1100
1 K 10 PIN SIP	1	RM 3	0986-00804-1000
2114-2	2	K 6, L 6.	0986-00803-2300
7400	1	F 2	0986-00803-2800
7404	1	N 6	0986-00803-8300
74 S04	1	F 3	0986-00803-3100
7408	1	L 2	0986-00803-3200
74LS20	2	G 2, L 1	0986-00803-3400
7427	1	N 2	0986-00803-3500
7430	5	J2, J3, K2, MI, NI	0986-00803-3600
7432	1	M 2	0986-00803-4400
74LS32	4	B 4,7, C 4,7,	0986-00803-3700
7474	2	K 3, L 3	0986-00803-4500
74S74	2	H 3, M 3	0986-00803-4100
74LS86	2	G 1, H 1	0986-00803-4200
74LS157	18	A 2, 3, 4, 5, 6, 7, D5, 6, E 5, 6, F 5, 6, G 6, H 6, J 6, L 7, M 7, N 7.	0986-00803-2400
74161	3	K 1, K 4, M 4.	0986-00803-2500
74174	2	H 2, 5	0986-00803-2600
74175	1	H 4	0986-00803-2700
74LS194	8	B 2,3, C 2,3, D 2,3, E 2,3.	0986-00803-2900
74LS245	1	N 5	0986-00803-3000
74LS273	4	D 4,7, J 4, N 3	0986-00803-3800
74LS283	5	G 3,4,5, L 4, N 4,	0986-00803-3900
74LS374	2	E 4, F 4	0986-00803-4000
93422	4	J 5, K 5, L 5, M 5	0986-00804-0800
93422	4	B 5, B 6, C 5, C 6	0986-00803-1010
EPROM	1	A1 (VG A)	ROM/EPROM OPTIONS KIT 0639-00803-0009
EPROM	1	B1 (VG B)	
EPROM	1	C1 (VG C)	
EPROM	1	D1 (VG D)	
JUMPER WIRE	8	JW1-8	0986-00805-0200
BUSS BAR	2	BB1, 2	0986-00804-0900
P.C. BOARD	1		A080-91399-E000
24 PIN RIGHT ANGLE CONN.	3	J 3,4,5	0986-00804-4700
28 PIN SOCKET	4	ICSA1,B1,C1,D1	0986-00804-0300
22 PIN SOCKET	8	ICSB5,6,C5,6,J5,K5,L5,M5	0986-00804-0700
18 PIN SOCKET	2	ICSK6 L6	0986-00804-0600
PC BDSPACER	4	PCMHI-PCMHI4	0986-00701-00XF
PC MTG SCREW	4	PCMH5-PCMH8	0017-00101-0339

PROJECT ENG: A. GOSH	USED ON KOZMIK KROOZ'R	REVISIONS:
DO NOT SCALE DWG	HEAT TREAT	SCALE FULL
DIM. TOLERANCES UNLESS OTHERWISE SPECIFIED	NO REQ'D ONE PER	NO REQ'D ONE PER
DATE 02/18/83	VIDEO GENERATOR P.C. ASSY DWG	PART NO. M051-00639-A034
	A082-91399-H000	




- J3 124 PIN RIBBON CABLE:
- 1 +5V
- 2 GND
- 3 CLK
- 4 HCLK
- 5 +5SENCE
- 6 MOVE BUF
- 7 DVI
- 8 DVI
- 9 DVI
- 10 DVI
- 11 DVI
- 12 DVI
- 13 DVI
- 14 DVI
- 15 DVI
- 16 DVI
- 17 DVI
- 18 DVI
- 19 DVI
- 20 DVI
- 21 DVI
- 22 DVI
- 23 DVI
- 24 DVI
- J4 124 PIN RIBBON CABLE:
- 1 GND
- 2 GND
- 3 GND
- 4 GND
- 5 RDI1
- 6 RDI2
- 7 RDI3
- 8 RDI4
- 9 RDI5
- 10 RDI6
- 11 RDI7
- 12 RDI8
- 13 RDI9
- 14 RDI10
- 15 RDI11
- 16 RDI12
- 17 RDI13
- 18 RDI14
- 19 RDI15
- 20 RDI16
- 21 RDI17
- 22 RDI18
- 23 RDI19
- 24 RDI20
- J5 124 PIN RIBBON CABLE:
- 1 GND
- 2 GND
- 3 H1
- 4 H2
- 5 H3
- 6 H4
- 7 H5
- 8 H6
- 9 H7
- 10 H8
- 11 H9
- 12 H10
- 13 H11
- 14 H12
- 15 H13
- 16 H14
- 17 H15
- 18 H16
- 19 H17
- 20 H18
- 21 H19
- 22 H20
- 23 H21
- 24 H22
- J6 72 PIN TEST CONN. (EDGE):
- 1 GND
- 2 +5V
- 3 RND
- 4 +5V
- 5 MOVE USEO
- 6 DVI
- 7 RDI1
- 8 RDI2
- 9 RDI3
- 10 RDI4
- 11 RDI5
- 12 RDI6
- 13 RDI7
- 14 RDI8
- 15 RDI9
- 16 RDI10
- 17 RDI11
- 18 RDI12
- 19 RDI13
- 20 RDI14
- 21 RDI15
- 22 RDI16
- 23 RDI17
- 24 RDI18
- 25 RDI19
- 26 RDI20
- 27 RDI21
- 28 RDI22
- 29 RDI23
- 30 RDI24
- 31 RDI25
- 32 RDI26
- 33 RDI27
- 34 RDI28
- 35 RDI29
- 36 RDI30
- 37 RDI31
- 38 RDI32
- 39 RDI33
- 40 RDI34
- 41 RDI35
- 42 RDI36
- 43 RDI37
- 44 RDI38
- 45 RDI39
- 46 RDI40
- 47 RDI41
- 48 RDI42
- 49 RDI43
- 50 RDI44
- 51 RDI45
- 52 RDI46
- 53 RDI47
- 54 RDI48
- 55 RDI49
- 56 RDI50
- 57 RDI51
- 58 RDI52
- 59 RDI53
- 60 RDI54
- 61 RDI55
- 62 RDI56
- 63 RDI57
- 64 RDI58
- 65 RDI59
- 66 RDI60
- 67 RDI61
- 68 RDI62
- 69 RDI63
- 70 RDI64
- 71 RDI65
- 72 RDI66

DESIGNED BY A. GHOSH  
 DATE 03/1/83  
 FULL NAME A. GHOSH  
 NO. OF DES. 1 PER  
 SCHEMATIC VIDEO GEN.  
 A084-91399-H941  
 MOORE MFG. CO.  
 PART NO. MO51-00986-H005

NOTE ALL Pk +5V


DESIGNATION LIST

Table with columns: DESIGNATION, DESCRIPTION, DESIGNATION, DESCRIPTION. Lists various components like resistors, capacitors, ICs, and connectors.



CROSS REFERENCE LIST. Table with columns: DESCRIPTION, QTY, DESIGNATION, PART NOS., DESCRIPTION, QTY, DESIGNATION, PART NOS. Lists cross-references for various components.

Project information form including: PROJECT ENG: C. MEDNICK, USED ON KOZMIK KROOZ'R, REVISIONS, DATE: 02/21/83, PART NO: M051 - 00639 - A 035.



- 72 PIN TEST CONN
- 1 - L GND
  - 2 - +5
  - 3 - L GND
  - 4 - +5
  - 5 - +12
  - 6 - A GND
  - 7 - +12
  - 8 - NOT USED
  - 9 - B GND
  - 10 - B GND
  - 11 - B GND
  - 12 - B GND
  - 13 - B GND
  - 14 - B GND
  - 15 - B GND
  - 16 - B GND
  - 17 - B GND
  - 18 - B GND
  - 19 - B GND
  - 20 - B GND
  - 21 - B GND
  - 22 - B GND
  - 23 - B GND
  - 24 - B GND
  - 25 - B GND
  - 26 - B GND
  - 27 - B GND
  - 28 - B GND
  - 29 - B GND
  - 30 - B GND
  - 31 - B GND
  - 32 - B GND
  - 33 - B GND
  - 34 - B GND
  - 35 - B GND
  - 36 - B GND
  - 37 - B GND
  - 38 - B GND
  - 39 - B GND
  - 40 - B GND
  - 41 - B GND
  - 42 - B GND
  - 43 - B GND
  - 44 - B GND
  - 45 - B GND
  - 46 - B GND
  - 47 - B GND
  - 48 - B GND
  - 49 - B GND
  - 50 - B GND
  - 51 - B GND
  - 52 - B GND
  - 53 - B GND
  - 54 - B GND
  - 55 - B GND
  - 56 - B GND
  - 57 - B GND
  - 58 - B GND
  - 59 - B GND
  - 60 - B GND
  - 61 - B GND
  - 62 - B GND
  - 63 - B GND
  - 64 - B GND
  - 65 - B GND
  - 66 - B GND
  - 67 - B GND
  - 68 - B GND
  - 69 - B GND
  - 70 - B GND
  - 71 - L GND
  - 72 - +5

USED ON VERSION W/PANNING  
NOT USED ON VERSION W/PANNING

NOT USED ON VERSION W/PANNING  
USED ON VERSION W/PANNING


NOTE

HOW JUMPER OPTIONS	JW1	JW2
2752 COMPATIBILITY		X
2752 COMPATIBILITY	X	

DESIGNED BY	J. JERON	DATE	03/1/78
DRAWN BY	J. JERON	DATE	03/1/78
CHECKED BY	J. JERON	DATE	03/1/78
APPROVED BY	J. JERON	DATE	03/1/78
TITLE	SUPER SOUND UO KOZMIK KROOZ'R		
SCHEMATIC DWG	MOSI - 06639-A020		
REV	A020 - 06639-A020		

DESIGNATION LIST

<u>DESIGNATION NO.</u>	<u>DESCRIPTION</u>
C1, C2	100 pf AX. CER 50V
CPI	10 µf AX. ELECT. 16V
CP2 - CP10	.01 µf AX. CER. 50V
R1	43 ohm 1/4 W 5%
R2	1.3 K " " 2%
R3, R4	2.7 K " " 5%
R5	43 " " 5%
R6	1.3 K " " 2%
R7	2.7 K " " 5%
VR1, VR2	100 ohm POT 1/8 W
IC 2A	74 LS 244
" 3A	74393
" 4A	4040 B
" 1B	74 LS 244
" 2B	74393
" 3B	4040 B
" 4B	74 SC240
L1, L2	10 - 40 µH COIL
J1	23 PIN KK-100 RT. ANGLE PIN 18 OMITTED
A080-91458-E000	ANALOG JOYSTIC P.C.




CROSS REFERENCE LIST

<u>DESCRIPTION</u>	<u>QTY</u>	<u>DESIG. NO.</u>	<u>PART NO.</u>
100 pf AX. CER. 50V	2	C1, C2	0639-00800-0003
.01 µf AX. CER. 50V	9	CP2 - CP10	0628-00800-0100
10 µf AX. ELECT. 16V	1	CPI	0628-00800-0300
43 ohm 1/4 W 5%	2	R1, R5	0062-083B3-1XXX
1.3 K " " 2%	2	R2, R6	0062-185B2-1XXX
2.7 K " " 5%	3	R3, R4, R7	0062-199B3-1XXX
100 " POT 1/8 W	2	VR1, VR2	0639-00804-0004
74 LS 244	2	IC 1B, 2A	0639-00803-0003
74393	2	" 2B, 3A	0639-00803-0005
4040 B	2	" 3B, 4A	0639-00803-0004
74 SC 240	1	" 4B	0639-00803-0006
10 - 40 µH COIL	2	L1, L2	0639-00804-0003
23 PIN KK-100 RT. ANGLE PIN 18 OMITTED	1	J1	3000-16366-2302
ANALOG JOYSTIC P.C. 1			A080-91458-E000

REVISIONS	


PROJECT ENG: J. BOYDSTON		USED ON KOZMIK KROOZ'R		Bally / MIDWAY MFG. CO. FRANKLIN PK. ILL.	
DO NOT SCALE DWG.		HEAT TREAT	SCALE FULL	NO. REQ'D 1 PER	
DIM. TOLERANCES UNLESS SPECIFIED		DRAWN 132	ASSY. DWG., ANALOG JOYSTIC P.C.		PART NO.
CONCENTRICITY T.R. .003		CHKD. 988	A082-91458-E000		M051 - 00986 - E023
FRACTIONAL .001 1/64		DATE 03/02/83	A084-91458-E000		



PROJECT ENG: JOHN BOYDSTON		USED ON KOZMIK KROOZ'R		Bally / MIDWAY MFG. CO. FRANKLIN PK. ILL.	
DO NOT SCALE DWG.		HEAT TREAT	SCALE FULL	NO. REQ'D 1 PER	
DIM. TOLERANCES UNLESS SPECIFIED		DRAWN: C.C.	SHEMATIC DWG, ANALOG JOYSTIC P.C.		PART NO.
CONCENTRICITY TYP .003		CHEK: JBB	A082-91458-E000		M051-00986-E024
FRACTIONAL .1/64		DATE: 2/17/83	A084-91458-E000		
DECIMAL .005					
HOLE DIA. +.002 .000					

DESIGNATION LIST

<u>DESIGNATION NO.</u>	<u>DESCRIPTION</u>
C1	.01 $\mu$ f AX CER. 50V
R1	1.5 K ohm 1/4 W 5%
RE1	SOLID STATE RELAY
J1	4 PIN KK-156 STR. CONN. PIN 3 OMITTED
J2	CABLE CONNECTION
PCMH1-PCMH4	P.C. MTG HDRW
A080-90509-C000	P.C. BOARD




CROSS REFERENCE LIST

<u>DESCRIPTION</u>	<u>QTY</u>	<u>DESIGNATION NO.</u>	<u>PART NO.</u>
.01 $\mu$ f AX CER 50V	1	C1	0628-00800-0100
1.5 K ohm 1/4 W 5%	1	R1	0062-187B3-1XXX
SOLID STATE RELAY	1	RE1	0639-00804-0002
4 PIN KK-156 STR.CONN. PIN 3 OMITTED	1	J1	3000-16367-0410
CABLE CONNECTION	1	J2	A639-00024-0000
P.C. MTG HDRW	4	PCMH1-PCMH4	0017-00042-0320
P.C. BOARD	1		A080-90509-C000

REVISIONS	

PROJECT ENG: J. BOYDSTON		USED ON KOZMIK KROOZ' R		<b>MIDWAY MFG. CO.</b> <small>FRANKLIN PK ILL</small>	
DO NOT SCALE DWG.		HEAT TREAT	SCALE FULL		
DIM. TOLERANCES UNLESS SPECIFIED		DRK. <i>TBB</i>	MAT'L.	ASSEMBLY DWG SOLID STATE RELAY P.C. A082-90509-C000 A084-90509-C000	
CONCENTRICITY TYP. .005		CKD.	FINISH		
FRACTIONAL .1/64		DATE 02/28/83			
DECIMAL .005				PART NO. M051-00114-C019	
HOLE DIA. +.002 .000					






REVISIONS		

PROJECT ENG: J. BOYDSTON		USED ON KOZMIK KROOZ'R		<b>Bally / MIDWAY MFG. CO.</b> FRANKLIN PK. ILL	
DO NOT SCALE DWG.	HEAT TREAT	SCALE FULL	NO. REQ'D 1 PER		
DIM. TOLERANCES UNLESS SPECIFIED CONCENTRICITY T.R. .003 FRACTIONAL .001 1/64 DECIMAL .005 HOLE DIA. +.002 .000	DRN. <i>JB</i>	MAT'L.	SCHEMATIC DWG S.S. RELAY P.C. A082-90509-C000 A084-90509-C000		PART NO. M051-00114-C018
	CKD.	FINISH			
	DATE 02/28/83				

DESIGNATION LIST


DESIGNATION NO.	DESCRIPTION
CP 1	10µf 16V AX. ELECT.
CP 2	.01µf 50V AX. CER.
CP 3	10µf 16V AX. ELECT.
CP 4-6	.01µf 50V AX. CER.
R 1	390 Ω 1/2W 5% CRBN FILM
R 2	100K 1/4W " "
R 3	20K " " "
R 4-6	3.3K " " "
R 7-12	1M " " "
R 13-16	10K " " "
R 17	1.3K " " "
R 18	10K " " "
R 19	1.3K " " "
R 20	3.3K " " "
Q 1,2	2N2222A TRANSISTOR
U 1	LM339
U 2	7407
OPT01-3	OPTICAL SENSOR
J 1	KK-100 VERT 12 PIN
_____	PLASTIC RIVET
A080-91434-D639	P.C. BOARD




CROSS REFERENCE LIST

DESCRIPTION	Q'ty	DESIGNATION NO.	PART NO.
.01µf 50V AX. CER.	4	CP 2, 4-6.	0639-00800-0002
10µf 16V AX. ELECT.	2	CP 1, 3.	0639-00800-0001
390 Ω 1/2W 5% CRBN FILM	1	R 1	0062-150D3-1XXX
1.3K 1/4W " "	2	R 17, 19.	0062-185B3-1XXX
3.3K " " "	4	R 4-6, 20.	0062-203B3-1XXX
10K " " "	5	R 13-16, 18.	0062-227B3-1XXX
20K " " "	1	R 3	0062-241B3-1XXX
100K " " "	1	R 2	0062-275B3-1XXX
1M " " "	6	R 7-12.	0062-323B3-1XXX
2N2222A TRANSISTOR	2	Q 1, 2.	0639-00802-0001
LM339	1	U 1	0639-00803-0002
7407	1	U 2	0639-00803-0001
OPTICAL SENSOR	3	OPT0 1-3.	0639-00804-0001
KK-100 VERT 12 PIN	1	J 1	3000-16364-1201
PLASTIC RIVET RND.HD	6	_____	0017-00072-0091
P C BOARD	1	_____	A080-91434-D639

PROJECT ENG: JOHN BOYDSTON		USED ON KOZMIK KROOZ'R		Bally / MIDWAY MFG. CO. FRANKLIN PK. ILL.	
DO NOT SCALE DWG.		HEAT TREAT	SCALE FULL	NO. REQ'D 1 PER	
DIM. TOLERANCES UNLESS SPECIFIED		MAT'L.	ASSY DRAWING		PART NO.
CONCENTRICITY TYP. .003		FINISH	SENSOR P.C.		M051-00639-D006
FRACTIONAL: 1/64			A084-91434-D639		
DECIMAL: .005					
HOLE DIA. +.002 0.00		DATE 03/02 /83			



PROJECT ENG: JOHN BOYDSTON		USED ON MOTHER SHIP		REVISIONS	
DO NOT SCALE DWG.		HEAT TREAT	SCALE	NO. REQ'D   PER	
DIM. TOLERANCES UNLESS SPECIFIED		MAT'L.	SOLDER PADS		
CONCENTRICITY TYP. .003	DRW. <i>CL</i>	FINISH	CL1		
FRACTIONAL . . . . . 1/64	CRD. <i>JOB</i>		CL2		
DECIMAL . . . . . .005	DATE 02/28/83		CL3		
HOLE DIA. . . . . +.002-.000					
SCHEMATIC DRAWING SENSOR P.C. A084-91434-D639			PART NO. M051-00639-D007		
			Bally / MIDWAY MFG. CO. FRANKLIN PK. ILL.		



NOTES:  
 1. A\* = WHEN USED  
 2. B\* = BOTTOM TERMINAL  
 3. S\* = SIDE TERMINAL  
 4. TS-1-5 = TERMINAL BARRIER STRIP POSITIONS  
 5. \* = CHASSIS EARTH GND.  
 6. (---) = ALTERNATE COLOR  
 7. TERMINATION ON CAPACITOR POST  
 8. NOT AVAILABLE ON MT-101A

POWER CHASSIS  
 125 VA, 115V, 60 Hz.  
 • A945-00020-0000

MIDWAY MFG CO.  
 10601 W. BELMONT AVE.  
 FRANKLIN PARK, ILL. 60131